

Caméra Rapide JAI SP-5000-PMCL-C

(A utiliser avec Station d'Acquisition RD Vision et les logiciels Camera Tool et Hirisx64)

A/ PRESENTATION :

1. La caméra

- Capteur CMOS 2560*2048 pixels, 12.8*10.24mm (pixel = 5.5µm)
- 138 im/s à pleine résolution (690 Mo/sec), durée max d'acquisition à pleine vitesse et pleine résolution : ~40 sec (~ 29 Go pour 32 Go de RAM)
- Possibilité de synchroniser en externe par un GBF (par ex pour enregistrer pendant 1s toutes les 10 sec à pleine vitesse. Pour cela il manque un cable BNC/caméra à acheter)
- Alimentation Power Over Camera Link (alimentée via les cartes Camera Link). La caméra peut être branchée une fois le PC allumé. Il y a 2 cartes CL à brancher de A/B (sur PC) vers 1/2 (sur caméra).

2. Objectifs et zoom Macro

3 systèmes de grossissement ont été achetés

- CVO GMHR41614MCN

Angle de vue 45°(H)

Par exemple à 300mm --> champ de 475mm x 350mm

- CVO GMHR48014MCN

Angle de vue 80°(H)

Par exemple à 300mm --> champ de 150mm x 110mm

- **Zoom Macro SCHNEIDER APO-COMPONON 12 45/4,0** (solution UNIFOC)

Permet d'avoir un champ de 20mmx15mm à 100mm

Position 100 à 140

SCHNEIDER UNIFOC 12 CAM-C (Adaptateur système Macro Schneider UNIFOC 12)

50 **SCHNEIDER UNIFOC 12 TUBUS 10** (Bague allonge pour système Macro Schneider Unifoc 12)

60 **SCHNEIDER UNIFOC 12 TUBUS 6** (Bague allonge pour système Macro Schneider Unifoc 12)

70 **SCHNEIDER UNIFOC 12 HELICAL MOUNT** (Système Macro pour Schneider UNIFOC 12) pour réglage de mise au point (sur 12mm d'allonge)

3. La station d'Acquisition

La station d'acquisition est un PC avec 32Go de RAM. Les programmes sont sur le disque C:\, les données sont à sauvegarder sur E:\ (de temps en temps, penser à formater le disque E:\ pour bien le nettoyer).

Clé Godemeter : clé logiciel (cout 300 Euros si on doit la racheter), à mettre avant de démarrer le PC. **Attention, si pas de clé, l'image est floue !**

2 Applications :

- Camera tool : gère le 'hardware' de la caméra, permet de brancher plusieurs caméras sur la carte CL
- Hirisx64 : logiciel d'acquisition

B/ UTILISATION :

1. Réglages dans Camera Tool

Quand on ouvre dans l'arborescence choisir le fichier de config avec la taille du capteur. pour une utilisation optimale : Freerun_2560*2048_1018.cfg (avec les 3 objectifs 2560*2048)

Doubler cliquer, après quelques seconde le voyant devient vert : connected !

On peut sauver les fichiers de config avec des paramètres modifiables :

- Freerun=sans trigger/ Trigger = avec ! ***ne pas changer***
- Taps : 10 canaux de transit des données en sortie du capteur, ***à ne pas changer***
- Fréquence d'acquisition en fps (max = 138 im/s à pleine résolution)
- Exposure : ajuste le max % au nombre d'im/s. Par défaut 7146µs à 138 fps, mais on peut diminuer jusqu'à qlq µs si on augmente la lumière et/ou ouvre l'objectif. *Par exemple 1000µs (avec gain 500) pour chute de goutte.*
- Gain : 100 = le minimum.
- Offset : 256, ***à ne pas changer***

Quand tous les paramètres ont été changés, on appuie sur 'set' , si OK 'sync=true'

Pour changer la taille du capteur : cette action a pour effet d'augmenter la fréquence d'acquisition d'images maximum, uniquement si on réduit la taille dans la direction verticale.

NB : si on est intéressé par réduire le capteur dans la direction horizontale pour augmenter la fréquence d'acquisition, alors il faut tourner la caméra de 90° !

2. Utilisation de Hirisx64

- Visualisation : On lance Hiris, puis clic sur l'icône 'Caméra', puis 'live'.

- Acquisition : mode acquisition, choisir en secondes ou en frames.

Pour faire l'acquisition d'images correctement, vérifier dans 'set-up' si l'option choisi est : RAM (l'option 'direct to disk' n'est pas recommandé pour des acquisitions rapides >20 im/s). Si perte d'images, un message prévient quand on ouvre la séquence que des images sont manquantes.

Si la séquence enregistrée n'a pas été sauvegardée quand on valide pour un nouvel enregistrement, un message prévient : 'effacer de la RAM et recommencer ?'

- Sauvegarde : On peut sauver la séquence en .avi, ou en stock d'images (les formats ; raw, bmp sont compatibles pour une lecture dans Image J).

Le format « séquence » est destiné à être relu dans 'Hiris'. ainsi après sauvegarde, on pourra facilement réexporter le film sous un autre format.

On peut sélectionner une partie des images avec les outils:

- LUT
- Calibration

Permet de calibrer l'échelle pixels↔microns à l'aide d'un étalon de longueur.

- Fonction trigger

3. Divers

- Pour changer la taille du capteur, aller dans Camera Tool, Advanced, Mode : User (à la place de 'full'). Si on change la taille du capteur, il faut ensuite dans Hiris faire 'Reset Grabber'.

SP-5000 family

5-megapixel CMOS global shutter



- Large format 5 MP CMOS imager (global shutter)
- Up to 250 fps at full resolution (CoaXPress x4)
- 5.0 μm square pixels in a 5:4 aspect ratio
- 60 dB linear dynamic range with 100 dB piece-wise HDR mode
- On-chip 4-channel analog gain for individual R, G1, G2, + B control
- Binning 2X and 4X on-chip for increased sensitivity and maximum performance
- ROI and decimation modes for flexible readout, windowing, or increasing frame rate
 - 980 fps at 1280 x 1024 pixels, 1845 fps at 640 x 480 pixels
- Monochrome or color models with raw Bayer or in-camera RGB/YUV interpolation
- Multiple interface options including CoaXPress (x2/x4), Mini Camera Link, GigE Vision (LAG), and USB 3.0
- C-mount or F-mount lens mounts
- Automatic Level Control (ALC) for dynamic lighting conditions
- Programmable 3-axis control for motorized lenses, pan/tilt heads, and other analog accessories


Specifications for SP-5000 family

PRELIMINARY


Specifications		SP-5000 family
Sensor	1" CMOS global shutter	
Pixel Clock	70.5 MHz	
Frame rate, full frame	250 frames/sec.*	
Active area	12.8 mm (h) x 10.2 mm (v)	
Cell size	5.0 μm (h) x 5.0 μm (v)	
Active pixels	2560 (h) x 2048 (v)	
Horizontal output frequency	TBD	
Read-out modes	Full	2560 (h) x 2048 (v) 250 fps*
	ROI (mono)	Any start line, any height in 1 line steps, with X offset and width in 16 pixel steps
	ROI (color)	Any start line, any height, in 2L steps with X offset and width in 16 pixel steps
Binning	2x and 4x, H and V	
Sensitivity (SP-5000M)	2.5 Lux (shutter off, max. gain, f1.4, 50% video)	
Sensitivity (SP-5000C)	4.8 Lux (shutter off, max. gain, f1.4, 50% green)	
S/N ratio	mono	>57 dB. (0 dB gain)
	color	>55 dB. (0 dB gain, green)
Video signal output	mono	8/10/12-bit monochrome
	color	8/10/12-bit Bayer
in-camera interpolation	24/30-bit RGB, YUV411, or YUV422	
Auto-iris lens video output	0.7Vp-p, with 0.3V horiz. sync.	
Gain	Monochrome	Manual/automatic -3 dB to +24 dB
	Color	Manual/automatic 0 dB to +24 dB
White balance (SP-5000C)	Manual, one-push auto, or continuous (3200K to 9000K)	
Gamma	0.45-1.0 (16 steps) or 256-point LUT	
Synchronization	Internal	
Inputs/Outputs	GPIO in/out through Hirose 12-pin connector	
Trigger input	Line1, Line2, PG1, PG2, Software1	
Trigger modes	EPS, PIV, Trigger Width, RCT (with ALC)	
Electronic shutter		
Timed exposure	10 μs to 8 sec in 1 μs steps	
Auto shutter	1/44 to 1/100,000 sec.	
Auto level control (ALC)	Shutter range from 1/44 to 1/100,000, gain range from 0 dB to +24 dB, auto iris control Tracking speeds and max values adjustable	
Pre-processing functions	Flat field correction, color shading correction (SP-5000C), blemish compensation (>512 pixels)	
3-axis control	Programmable control of motorized lenses, pan/tilt heads, and other analog accessories	
Operating temperature	-5° C to +45° C	
Storage temperature	-25° C to 60° C	
Humidity	20 - 80% non-condensing	
Vibration	10G (20 Hz to 200 Hz XYZ)	
Shock	80 G	
Regulations	CE (EN 61000-6-2, EN 61000-6-3), FCC part 15 class B, RoHS/WEEE	
Power	12V to 24V DC \pm 10%. 5.3W typical (full frame @ 12V)	
Lens mount	F-mount, C-mount	
Dimensions (H x W x L)	F-mount	62 mm x 62 mm x 84.5 mm
	C-mount	62 mm x 62 mm x 55 mm
Weight	F-mount	TBD g
	C-mount	TBD g

*CoaXPress x4, 8-bit

Spectral Response




Dimensions



Drawings and dimensions are for Mini Camera Link model and F-mount. Consult JAI for other configurations.

Connector pin-out

DC In / Trigger



HIROSE HR10A-10R-12PB-01


Connector Pin-out

Pin 1	GND	
2	+12V to +24V DC input	
3	Opto in 2(-)*/GND	
4	Opto in 2(+)*/Auto iris lens	
5	Opto in 1(-)	
6	Opto in 1(+)	
7	Opto out 1(-)	
8	Opto out 1(+)	
9	Opto out 2(-)	
10	Opto out 2(+)	
11	+12V to +24V DC input	
12	GND	

* Pins 3 and 4 can be configured by internal switch selection

Mini-CL interface

Interface 1



Pin	Signal	Function
1	GND	
13	GND	
14	GND	
26	GND	
2	-/+ TxOUT 0	CL Video Channel X
3	-/+ TxOUT 1	
4	-/+ TxOUT 2	
5	-/+ TxClk	
6	-/+ TxOUT 3	
7	+/ - RXD	Serial in
8	-/+ TXD	Serial out
9	CC1-/CC1+	Ext. trig
10	CC2+/CC2-	Not used
11	CC3-/CC3+	Not used
12	CC4+/CC4-	Not used

For Medium or Full implementations a second Mini-CL interface is provided. Video channel Y is on pin pairs (2,15), (3,16), (4,17), (5,18), and (6,19). Video channel Z is on pin pairs (8,21), (9,22), (10,23), (11,24) and (12,25). Consult manual for specific bit depths and pin assignments.

Interfaces

Mini Camera Link (full)	133 fps (8-bit)
CoaXPress (x1)	119 fps (8-bit)
CoaXPress (x2)	209 fps (8-bit)
CoaXPress (x4)	250 fps (8-bit)
GigE Vision (LAG)	44 fps (8-bit)
USB 3.0	72 fps (8-bit)

Ordering Information

SP-5000M-MCL	Monochrome camera with Mini Camera Link
SP-5000C-MCL	Color camera with Mini Camera Link
SP-5000M-CX2	Monochrome camera with CoaXPress x1/x2
SP-5000C-CX2	Color camera with CoaXPress x1/x2
SP-5000M-CX4	Monochrome camera with CoaXPress x4
SP-5000C-CX4	Color camera with CoaXPress x4
SP-5000M-USB	Monochrome camera with USB 3.0
SP-5000C-USB	Color camera with USB 3.0

Note: Add -C to model number for C-mount or -F for F-mount

Europe, Middle East & Africa
Phone +45 4457 8888
Fax +45 4491 3252

Asia Pacific
Phone +81 45 440 0154
Fax +81 45 440 0166

Americas
Phone (Toll-Free) 1 800 445 5444
Phone +1 408 383 0300

Visit our web site on www.jai.com



See the possibilities



See the possibilities

Spark Series

User Manual

SP-5000M-PMCL ***SP-5000C-PMCL***

*5M CMOS Digital Progressive Scan
Monochrome and Color Camera*

Document Version: Ver.1.1
SP-5000-PMCL_Ver.1.1_Oct2013

Notice

The material contained in this manual consists of information that is proprietary to JAI Ltd., Japan and may only be used by the purchasers of the product. JAI Ltd., Japan makes no warranty for the use of its product and assumes no responsibility for any errors which may appear or for damages resulting from the use of the information contained herein. JAI Ltd., Japan reserves the right to make changes without notice.

Company and product names mentioned in this manual are trademarks or registered trademarks of their respective owners.

Warranty

For information about the warranty, please contact your factory representative.

Certifications

CE compliance

As defined by the Directive 2004/108/EC of the European Parliament and of the Council, EMC (Electromagnetic compatibility), JAI Ltd., Japan declares that SP-5000M-PMCL and SP-5000C-PMCL comply with the following provisions applying to its standards.

EN 61000-6-3 (Generic emission standard part 1)
EN 61000-6-2 (Generic immunity standard part 1)

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning

Changes or modifications to this unit not expressly approved by the party responsible for FCC compliance could void the user's authority to operate the equipment.

Supplement

The following statement is related to the regulation on "Measures for the Administration of the control of Pollution by Electronic Information Products", known as "China RoHS". The table shows contained Hazardous Substances in this camera.

 mark shows that the environment-friendly use period of contained Hazardous Substances is 15 years.

重要注意事项

有毒，有害物质或元素名称及含量表

根据中华人民共和国信息产业部『电子信息产品污染控制管理办法』，本产品《有毒，有害物质或元素名称及含量表》如下。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PPB)	多溴二苯醚 (PBDE)
螺丝固定座	×	○	○	○	○	○
连接插头	×	■	■	■	■	■
电路板	×	■	■	■	■	■
.....

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006规定的限量要求以下。
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006规定的限量要求。
(企业可在此处、根据实际情况对上表中打“×”的技术原因进行进一步说明。)



环保使用期限

电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变、电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对基人身、财产造成严重损害的期限。

数字「15」为期限15年。

Supplement

The following statement is related to the regulation on “Measures for the Administration of the control of Pollution by Electronic Information Products”, known as “China RoHS”. The table shows contained Hazardous Substances in this camera.

 mark shows that the environment-friendly use period of contained Hazardous Substances is 15 years.

重要注意事项

有毒，有害物质或元素名称及含量表

根据中华人民共和国信息产业部『电子信息产品污染控制管理办法』，本产品《有毒，有害物质或元素名称及含量表》如下。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PPB)	多溴二苯醚 (PBDE)
螺丝固定座	×	○	○	○	○	○
光学滤色镜	×	○	×	○	○	○
连接插头	×	○	○	○	○	○
电路板	×	○	○	○	○	○
.....

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006规定的限量要求以下。
×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363-2006规定的限量要求。
(企业可在此处、根据实际情况对上表中打“×”的技术原因进行进一步说明。)



环保使用期限

电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变、电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对基人身、财产造成严重损害的期限。

数字「15」为期限15年。

- Contents -

Before using this camera	6 -
1. General	7 -
2. Camera composition	7 -
3. Key features	8 -
4. Parts locations and their functions.....	9 -
4.1 Parts locations and their functions	9 -
4.2 Rear Panel.....	10 -
5. Input and output	11 -
5.1 Connector and its pin configuration	11 -
5.1.1 12-Pin connector.....	11 -
5.1.1.1 Figure	11 -
5.1.1.2 Pin configuration	11 -
5.1.2 Camera Link Connector.....	11 -
5.1.2.1 Figure	11 -
5.1.2.2 Pin assignment	12 -
5.1.3 AUX Standard Hirose 10-Pin connector	12 -
5.1.3.1 Figure and pin configuration	12 -
5.1.4 AUX Type 2 HIROSE 10-Pin connector (factory option)	13 -
5.1.5 AUX Type 3 HIROSE 10-Pin connector (factory option)	13 -
5.2 Camera Link interface	14 -
5.2.1 Camera Link Interface	14 -
5.2.2 Camera Link pixel clock frequency.....	15 -
5.3 Digital IN/OUT interface.....	16 -
5.3.1 Line Selector	16 -
5.3.2 Line Source	16 -
5.3.3 Line Mode	16 -
5.3.4 Line Inverter.....	16 -
5.3.5 Line Status	16 -
5.3.6 Line Format.....	17 -
5.3.7 GPIO.....	17 -
5.3.7.1 Basic block diagram.....	17 -
5.3.7.2 Input and output matrix table	18 -
5.4 Pulse Generator	18 -
5.4.1 Clock Pre-scaler.....	19 -
5.4.2 Pulse Generator Selector.....	19 -
5.4.3 Pulse Generator Length	20 -
5.4.4 Pulse Generator Start Point	20 -
5.4.5 Pulse Generator End Point	20 -
5.4.6 Pulse Generator Repeat Count	20 -
5.4.7 Pulse Generator Clear Activation	20 -
5.4.8 Pulse Generator Clear Sync Mode	20 -
5.4.9 Pulse Generator Clear Source	22 -
5.4.10 Pulse Generator Inverter	23 -
5.4.11 Pulse Generator Setting table	23 -
6. Sensor layout, output format and timing	24 -
6.1 Sensor layout	24 -
6.1.1 Monochrome sensor	24 -
6.1.2 Bayer sensor	24 -
6.2 Camera output format (Tap Geometry)	25 -
6.2.1 1X2-1Y	25 -
6.2.2 1X4-1Y	26 -
6.2.3 1X8-1Y	26 -

6.3 Output timing and output image	- 27 -
6.3.1 Horizontal timing	- 27 -
6.3.2 Vertical timing	- 35 -
Table 28. Continuous Trigger / Vertical timing 1X4-1Y (2/3)	- 40 -
Camera Settings	- 40 -
Table 29. Continuous Trigger / Vertical timing 1X2-1Y (3/3)	- 41 -
Camera Settings	- 41 -
6.3.3 ROI (Region Of Interest) setting	- 41 -
6.4 Digital output bit allocation	- 42 -
7. Operating modes	- 43 -
7.1. Acquisition control (change the frame rate)	- 43 -
7.1.1 Acquisition control	- 43 -
7.2. Exposure setting	- 47 -
7.2.1 Mode	- 47 -
7.2.2 ExposureTime	- 47 -
7.2.3 ExposureAuto	- 48 -
7.3. Trigger control	- 48 -
7.3.1 Trigger Selector	- 48 -
7.3.2 Trigger Mode	- 48 -
7.3.3 TriggerSource	- 48 -
7.3.4 TriggerActivation	- 49 -
7.3.5 Triggeroverlap	- 49 -
7.4. Normal continuous operation (Timed Exposure Mode/Trigger Mode OFF)	- 49 -
7.5. Timed mode (EPS operation)	- 49 -
7.5.1 If Overlap setting is OFF	- 50 -
7.5.2 If Overlap setting is Readout	- 50 -
7.6 Trigger width mode (PWC)	- 51 -
7.6.1 If Overlap setting is OFF	- 51 -
7.6.2 If Overlap setting is Readout	- 52 -
7.7. RCT mode	- 53 -
7.8 PIV (Particle Image Velocimetry)	- 54 -
7.9 Sequence Mode	- 55 -
7.9.1 Video send mode	- 55 -
7.9.2 Sequence mode	- 55 -
7.9.3 Sequence mode timing	- 55 -
7.9.4 Sequence ROI setting parameters	- 56 -
7.10 Multi ROI function	- 58 -
7.10.1 Multi ROI setting parameters	- 58 -
7.11. Operation and function matrix	- 61 -
Exposure	- 61 -
8. Other functions	- 62 -
8.1 Black level control	- 62 -
8.1.1 Black Level Selector	- 62 -
8.1.2 Black Level	- 62 -
8.2 Gain control	- 62 -
8.2.1 Gain Selector	- 63 -
8.2.2 Gain	- 63 -
8.2.3 Gain Raw	- 63 -
8.2.4 Gain Auto	- 63 -
8.3. LUT	- 64 -
8.3.1 LUT Enable	- 64 -
8.3.2 LUT Index	- 64 -
8.3.3 LUT Value	- 64 -
8.4 Gamma	- 65 -
8.5 Shading Correction	- 65 -
8.6 Blemish compensation	- 66 -

8.7 ALC	- 67 -
8.8 HDR (High Dynamic Range) (SP-5000M-PMCL only).....	- 67 -
8.9. Lens	- 68 -
8.9.1 About P-Iris	- 69 -
8.9.2 Setting for P-iris lens being used	- 69 -
8.9.2.1 P-Iris lens select	- 69 -
8.9.2.2 Step max.	- 69 -
8.9.2.3 Position.....	- 69 -
8.9.2.4 Current F value	- 69 -
8.9.2.5 P-Iris Auto min. / P-Iris Auto max.	- 69 -
8.9.3 Motorized lens.....	- 69 -
8.9.3.1 Iris.....	- 69 -
8.9.3.2 Zoom.....	- 70 -
8.9.3.3 Focus+	- 70 -
9. Camera control.....	- 71 -
10. External appearance and dimensions	- 72 -
11. Specifications.....	- 73 -
11.1. Camera spectral response	- 73 -
11.2. Specification table	- 74 -
Appendix 1 Short ASCII Command Communication Protocol	- 77 -
1 Communication setting	- 77 -
2 Protocol (Short ASCII Command)	- 77 -
2.1 Transmit the setting command to camera	- 77 -
2.2 Transmit the request command to camera	- 77 -
2.3 Switching baud rate between PC and camera	- 77 -
2.4 Command list (Short ASCII command).....	- 78 -
2.4.1 GenCP Bootstrap Register	- 78 -
2.4.2 Technology Specific Bootstra Register.....	- 78 -
2.4.3 Device Control	- 79 -
2.4.4 Image Format Control	- 79 -
2.4.5 Acquisition Control	- 80 -
2.4.6 Digital I/O Control.....	- 81 -
2.4.7 Analogue Control	- 82 -
2.4.8 LUT Control	- 82 -
2.4.9 Transport Layer Control	- 83 -
2.4.10 User Set Control	- 83 -
2.4.11 JAI-Custom	- 83 -
Appendix 2	- 101 -
1. Precautions	- 101 -
2. Typical Sensor Characteristics.....	- 101 -
3. Caution when mounting a lens on the camera	- 101 -
4. Caution when mounting the camera	- 101 -
5. Exportation	- 102 -
6. References	- 102 -
Manual change history	- 103 -
User's Record	- 104 -

Before using this camera

EMVA 1288

With regard to signal to noise ratio in this manual, specifications measured by EMVA 1288 are used together with specifications by a traditional measurement method.

EMVA 1288 is a more complete measurement that considers multiple noise sources, including random noise, pattern noise, and shading. Additionally, EMVA 1288 incorporates temporal variances in pixel output by capturing 100 frames of data and computing the RMS variations over the captured frames. Because of the comprehensive nature of the noise analysis and the additional consideration for RMS variances over time, EMVA 1288 SNR measurements are inherently lower than the traditional SNR measurements given by manufacturers. However, the comprehensive nature combined with rigid test parameters, means that all manufacturers' are measuring their products equally and EMVA 1288 tested parameters can be compared among different manufacturers' products.

In order to learn more about EMVA 1288, please visit <http://www.emva.org>

Frame grabber board

The SP-5000M-PMCL and SP-5000C-PMCL comply with “Power over Camera Link” which enables power to be supplied to the camera through the Camera Link cable(s). Because the power requirements of the camera exceed the amount of power which can be provided over a single PoCL connection, power must be supplied via both Camera Link cables in order to utilize the PoCL capabilities. If you plan to use this function, please be sure that the frame grabber board you are using also complies with this specification. Alternatively, the camera can be powered via a separate power supply connected to the 12-pin Hirose connector.

The SP-5000M-PMCL and SP-5000C-PMCL employ output formats which comply with the GenICam® standard. They are 1X10-1Y (10-Tap output), 1X8-1Y (8-Tap output), 1X4-1Y (4-Tap output) and 1X2-1Y (2-Tap output). 1X10-1Y is available for 8-bit output, 1X8-1Y is available for 8-bit and 10-bit output, and 1X4-1Y and 1X2-1Y are available for 8-bit, 10-bit and 12-bit output. Please check if the frame grabber used in the system complies with the mentioned formats.

Camera control tool

The SP-5000M-PMCL and SP-5000C-PMCL are designed to use the JAI SDK and Control Tool software to control camera functions. All controllable functions are stored in the camera's XML file. The JAI SDK can be downloaded from www.jai.com.

A camera control tool for using the Short ASCII command protocol is not available on the JAI website. Please contact your local JAI representative if this is required.

1. General

The SP-5000M-PMCL and SP-5000C-PMCL are among the first new “Spark Series” cameras to be introduced. They provide both high resolution and a high frame rate with excellent image quality for machine vision applications. The SP-5000M-PMCL is a monochrome progressive scan COMS camera and the SP-5000C-PMCL is the equivalent Bayer mosaic progressive scan CMOS camera. Both are equipped with CMOS sensors offering a 1-inch image format, a resolution of 5 million pixels, and a 5:4 aspect ratio. They provide a maximum of 134 frames per second for continuous scanning with 2560 x 2048 full pixel resolution in 1x10-1Y output format.

8-bit, 10-bit or 12-bit output can be selected for both monochrome and raw Bayer formats. The new cameras feature a Mini Camera Link interface supporting a “Power over Camera Link” capability. A full pixel readout or partial scan readout mode can be selected depending on applications. The readout format is available for 10-tap, 8-tap, 4-tap or 2-tap output.

The SP-5000M-PMCL and SP-5000C-PMCL have various comprehensive functions needed for automated optical inspection applications, such as solid state device inspection or material surface inspection. They incorporate video processing functions such as a look-up table, flat field shading compensation and blemish compensation in addition to fundamental functions such as trigger, exposure setting and video level control.

The latest version of this manual can be downloaded from: www.jai.com

The latest version of the JAI SDK for the SP-5000M-PMCL and SP-5000C-PMCL can be downloaded from: www.jai.com

For camera revision history, please contact your local JAI distributor.

2. Camera composition

The standard camera composition is as follows.

Camera body	1
Sensor protection cap	1
Dear Customer (sheet)	1

The following optional accessories are available.


Tripod base	MP-42
Power supply unit	PD-12 series

3. Key features

- New Spark Series 1-inch CMOS 5-megapixel progressive scan camera
- Utilizes Mini Camera Link interface in Medium or Full configurations
- Aspect ratio 5:4, 2560 (H) x 2048 (V) - 5 million effective pixels
- 5 μm square pixels
- S/N 55dB for monochrome and 53dB for color (traditional measurement method)
- 8-bit, 10-bit or 12-bit output for monochrome and Bayer
- 134 frames/second with full resolution in continuous operation for 10-tap output, 120 frames/second for 8-tap output
- Supports ROI (Region Of Interest) modes for faster frame rate
- 0dB to +24dB gain control for both SP-5000M-PMCL and SP-5000C-PMCL
- 10 μs (1/100,000) to 8 seconds exposure control in 1 μs step
- Auto exposure control
- Timed and trigger width exposure control
- RCT and PIV trigger modes for specific applications
- ALC control with combined function of AGC, Auto Shutter and Auto Iris
- Various pre-processing circuits are provided
 - Programmable LUT
 - Gamma correction from 0.45 to 1.0
 - Shading correction
 - Bayer white balance with manual or one-push auto (SP-5000C-PMCL only)
 - Blemish compensation
 - HDR (High Dynamic Range) function (SP-5000M-PMCL only)
- Auto iris lens video output with H-sync
- New Hirose 10P connector for motorized lenses and P-iris lens control as standard and video/DC iris or TTL IN and OUT and LVDS IN interfaces as options
- C-mount for lens mount
- Accepts power over Mini Camera Link or via 12-pin connector
- Setup by Windows XP/Vista/7/8 via serial communication

4. Parts locations and their functions

4.1 Parts locations and their functions



*1) Note: Rear protrusion on C-mount lens must be less than 10.0 mm.

*2) Note: When a Camera Link cable is connected to the camera, please do not excessively tighten screws by using a driver. The Camera Link receptacle on the camera might be damaged. For security, the strength to tighten screws is less than 0.147 Newton meter (Nm). Tightening by hand is sufficient in order to achieve this.

*3) Note: The part number for the tripod adapter plate (with 1/4"-20 thread) is MP-42 (option).

Fig. 1 Locations

4.2 Rear Panel

The rear panel mounted LED provides the following information:

- Amber: Power connected - initiating
This light goes OFF after initiating.
- Steady green: Camera is operating in Continuous mode
- Flashing green: The camera is receiving external triggering

Note: The interval of flashing does not correspond with external trigger duration.





Fig. 2 Rear panel

5. Input and output

5.1 Connector and its pin configuration

5.1.1 12-Pin connector

5.1.1.1 Figure



Type: HR-10A-10R-12PB(72) Hirose male or equivalent

Fig.3 Hirose 12-pin connector

5.1.1.2 Pin configuration

Table 1 12-pin configuration

Pin no.	Signal	Remarks
1	GND	
2	DC input	+12V ~ +24V (note 3)
3	GND	
4	Video Iris	Video signal output for lens auto iris
5	NC	
6	NC	
7	NC	
8	NC	
9	TTL out 1	Line1 (note 1)
10	TTL In 1	Line4 (note 2)
11	DC input	+12V ~ +24V (note 3)
12	GND	

Note 1) Factory default setting is Exposure Active and negative

Exposure Active inside the camera is positive but for the output, it is inverted to negative.

Note 2) Factory default setting is trigger input.

Note 3) See page 6 for notes about power options for these cameras

5.1.2 Camera Link Connector

5.1.2.1 Figure

Type: 26-pin Mini Camera Link connector (Honda HDR-EC26FYTG2-SL+) See page 6 for notes about Power over Camera Link (PoCL) options for this camera.




Fig.4 Camera Link connector

5.1.2.2 Pin assignment

Table-2 Camera link pin configuration - connector 1

Pin No	In/Out	Name	Note
1,26		Power	Power
2(-),15(+)	O	X_OUT0	Data output
3(-),16(+)	O	X_OUT1	
4(-),17(+)	O	X_OUT2	
5(-),18(+)	O	X_Clk	Clock for CL
6(-),19(+)	O	X_OUT3	Data output
7(+),20(-)	I	SerTC (RxD)	LVDS serial control
8(-),21(+)	O	SerTFG (TxD)	
9(-),22(+)	I	CC1 (Trigger)	Trigger input
10(+),23(-)		CC1 (Reserved)	
11,24		N.C	
12,25		N.C	
13,14		Shield	Power Return

Camera Link connector 2

Pin No	In/Out	Name	Note
1,26		Power	Power
2(-),15(+)	O	Y_OUT0	Data output
3(-),16(+)	O	Y_OUT1	
4(-),17(+)	O	Y_OUT2	
5(-),18(+)	O	Y_Clk	Clock for CL
6(-),19(+)	O	Y_OUT3	Data output
7(+),20(-)	I	N.C	
8(-),21(+)	O	Z_OUT0	Data output
9(-),22(+)	I	Z_OUT1	
10(+),23(-)		Z_OUT2	
11,24		Z_Clk	Clock for CL
12,25		Z_OUT3	Data output
13,14		Shield	Power Return

5.1.3 AUX Standard Hirose 10-Pin connector

5.1.3.1 Figure and pin configuration

Type : HIROSE 10-Pin Connector 3260-10S3(55)




Fig.5 Hirose 10-pin connector

Table -3 AUX Standard Hirose 10-pin connector pin assignment

No	I/O	Name	Note
1	O	DRIVE IRIS+	Motorized Lens
2	O	DRIVE FOCUS+	Motorized Lens
3	O	DRIVE ZOOM+	Motorized Lens
4	O	COMMON	Motorized Lens
5		GND	
6	O	P-IRIS OUT1A	P-Iris Lens
7	O	P-IRIS OUT1B	P-Iris Lens
8	O	P-IRIS OUT2A	P-Iris Lens
9	O	P-IRIS OUT2B	P-Iris Lens
10	O	GND	

5.1.4 AUX Type 2 HIROSE 10-Pin connector (factory option)

Type: HIROSE 10-Pin Connector 3260-10S3(55)

Table-4 10-pin pin configuration (option)

No	I/O	Name	Note
1	O	Video Signal	Video Iris Lens
2	O	Power DC+12V	Video Iris Lens
3		NC	
4		NC	
5		GND	
6	O	DC IRIS DAMP-	DC Iris
7	O	DC IRIS DAMP+	DC Iris
8	O	DC IRIS DRIVE+	DC Iris
9	O	DC IRIS DRIVE-	DC Iris
10		GND	

5.1.5 AUX Type 3 HIROSE 10-Pin connector (factory option)

HIROSE 10-Pin Connector 3260-10S3(55)

Table - 5 10-pin pin configuration (option)

No	I/O	Name	Note
1	O	TTL OUT2	Line8
2	O	TTL OUT3	Line9
3	I	TTL_IN2	Line10
4		NC	
5		GND	
6	I	LVDS_IN1+	Line11
7	I	LVDS_IN1-	
8		NC	
9		GND	
10		GND	

5.2 Camera Link interface

5.2.1 Camera Link Interface

Table-6 Camera Link interface

SP-5000M/C-PMCL							
Port	Camera Link Configuration		Base	Medium	Full	80bit	Full
	Camera Link port/bit		2Tap / 12bit	4Tap / 12bit	8 Tap / 8bit	8 Tap / 10bit	10 Tap / 8bit
	GenlCam Tap Geometry		1X2 - 1Y	1X4 - 1Y	1x8 - 1Y	1X8 - 1Y	1X10 - 1Y
D i g i t a l I / O -1	Port A0	TxIN 0	Tap1 D0	Tap 1 D0	Tap 1 D0	Tap 1 D2	Tap 1 D0
	Port A1	TxIN 1	Tap1 D1	Tap 1 D1	Tap 1 D1	Tap 1 D3	Tap 1 D1
	Port A2	TxIN 2	Tap1 D2	Tap 1 D2	Tap 1 D2	Tap 1 D4	Tap 1 D2
	Port A3	TxIN 3	Tap1 D3	Tap 1 D3	Tap 1 D3	Tap 1 D5	Tap 1 D3
	Port A4	TxIN 4	Tap1 D4	Tap 1 D4	Tap 1 D4	Tap 1 D6	Tap 1 D4
	Port A5	TxIN 6	Tap1 D5	Tap 1 D5	Tap 1 D5	Tap 1 D7	Tap 1 D6
	Port A6	TxIN 27	Tap1 D6	Tap 1 D6	Tap 1 D6	Tap 1 D8	Tap 4 D1
	Port A7	TxIN 5	Tap1 D7	Tap 1 D7	Tap 1 D7	Tap 1 D9	Tap 1 D5
	Port B0	TxIN 7	Tap1 D8	Tap 1 D8	Tap 2 D0	Tap 2 D2	Tap 1 D7
	Port B1	TxIN 8	Tap1 D9	Tap 1 D9	Tap 2 D1	Tap 2 D3	Tap 2 D0
	Port B2	TxIN 9	Tap1 D10	Tap 1 D10	Tap 2 D2	Tap 2 D4	Tap 2 D1
	Port B3	TxIN 12	Tap1 D11	Tap 1 D11	Tap 2 D3	Tap 2 D5	Tap 2 D4
	Port B4	TxIN 13	Tap2 D8	Tap 2 D8	Tap 2 D4	Tap 2 D6	Tap 2 D5
	Port B5	TxIN 14	Tap2 D9	Tap 2 D9	Tap 2 D5	Tap 2 D7	Tap 2 D6
	Port B6	TxIN 10	Tap2 D10	Tap 2 D10	Tap 2 D6	Tap 2 D8	Tap 2 D2
	Port B7	TxIN 11	Tap2 D11	Tap 2 D11	Tap 2 D7	Tap 2 D9	Tap 2 D3
	Port C0	TxIN 15	Tap2 D0	Tap 2 D0	Tap 3 D0	Tap 3 D2	Tap 2 D7
	Port C1	TxIN 18	Tap2 D1	Tap 2 D1	Tap 3 D1	Tap 3 D3	Tap 3 D2
	Port C2	TxIN 19	Tap2 D2	Tap 2 D2	Tap 3 D2	Tap 3 D4	Tap 3 D3
	Port C3	TxIN 20	Tap2 D3	Tap 2 D3	Tap 3 D3	Tap 3 D5	Tap 3 D4
	Port C4	TxIN 21	Tap2 D4	Tap 2 D4	Tap 3 D4	Tap 3 D6	Tap 3 D5
	Port C5	TxIN 22	Tap2 D5	Tap 2 D5	Tap 3 D5	Tap 3 D7	Tap 3 D6
	Port C6	TxIN 16	Tap2 D6	Tap 2 D6	Tap 3 D6	Tap 3 D8	Tap 3 D0
	Port C7	TxIN 17	Tap2 D7	Tap 2 D7	Tap 3 D7	Tap 3 D9	Tap 3 D1
	-	TxIN 24	LVAL	LVAL	LVAL	LVAL	LVAL
	-	TxIN 25	FVAL	FVAL	FVAL	FVAL	FVAL
	(Port I0)	TxIN 26	DVAL	DVAL	DVAL	Tap 1 D0	Tap 4 D0
	(Port I1)	TxIN 23	Exposure Active	Exposure Active	Exposure Active	Tap 1 D1	Tap 3 D7

SP-5000M/C-PMCL							
Port	Camera Link Configuration		Base	Medium	Full	80bit	Full
	Camera Link port/bit		2Tap / 12bit	4Tap / 12bit	8 Tap / 8bit	8 Tap / 10bit	10 Tap / 8bit
	GenlCam Tap Geometry		1X2 - 1Y	1X4 - 1Y	1x8 - 1Y	1X8 - 1Y	1X10 - 1Y
D i g i t a l I / O -2	Port D0	TxIN 0	—	Tap 4 D0	Tap 4 D0	Tap 4 D2	Tap 4 D2
	Port D1	TxIN 1	—	Tap 4 D1	Tap 4 D1	Tap 4 D3	Tap 4 D3
	Port D2	TxIN 2	—	Tap 4 D2	Tap 4 D2	Tap 4 D4	Tap 4 D4
	Port D3	TxIN 3	—	Tap 4 D3	Tap 4 D3	Tap 4 D5	Tap 4 D5
	Port D4	TxIN 4	—	Tap 4 D4	Tap 4 D4	Tap 4 D6	Tap 4 D6
	Port D5	TxIN 6	—	Tap 4 D5	Tap 4 D5	Tap 4 D7	Tap 5 D0
	Port D6	TxIN 27	—	Tap 4 D6	Tap 4 D6	Tap 4 D8	LVAL
	Port D7	TxIN 5	—	Tap 4 D7	Tap 4 D7	Tap 4 D9	Tap 4 D7
	Port E0	TxIN 7	—	Tap 3 D0	Tap 5 D0	Tap 5 D2	Tap 5 D1
	Port E1	TxIN 8	—	Tap 3 D1	Tap 5 D1	Tap 5 D3	Tap 5 D2
	Port E2	TxIN 9	—	Tap 3 D2	Tap 5 D2	Tap 5 D4	Tap 5 D3
	Port E3	TxIN 12	—	Tap 3 D3	Tap 5 D3	Tap 5 D5	Tap 5 D6
	Port E4	TxIN 13	—	Tap 3 D4	Tap 5 D4	Tap 5 D6	Tap 5 D7
	Port E5	TxIN 14	—	Tap 3 D5	Tap 5 D5	Tap 5 D7	Tap 6 D0
	Port E6	TxIN 10	—	Tap 3 D6	Tap 5 D6	Tap 5 D8	Tap 5 D4
	Port E7	TxIN 11	—	Tap 3 D7	Tap 5 D7	Tap 5 D9	Tap 5 D5
	Port F0	TxIN 15	—	Tap 3 D8	Tap 6 D0	Tap 6 D2	Tap 6 D1
	Port F1	TxIN 18	—	Tap 3 D9	Tap 6 D1	Tap 6 D3	Tap 6 D4
	Port F2	TxIN 19	—	Tap 3 D10	Tap 6 D2	Tap 6 D4	Tap 6 D5
	Port F3	TxIN 20	—	Tap 3 D11	Tap 6 D3	Tap 6 D5	Tap 6 D6
	Port F4	TxIN 21	—	Tap 4 D8	Tap 6 D4	Tap 6 D6	Tap 6 D7
	Port F5	TxIN 22	—	Tap 4 D9	Tap 6 D5	Tap 6 D7	Tap 7 D0
	Port F6	TxIN 16	—	Tap 4 D10	Tap 6 D6	Tap 6 D8	Tap 6 D2
	Port F7	TxIN 17	—	Tap 4 D11	Tap 6 D7	Tap 6 D9	Tap 6 D3
	-	TxIN 24	—	LVAL	LVAL	LVAL	Tap7 D2
	(Port I2)	TxIN 25	—	FVAL	FVAL	Tap 2 D0	Tap7 D3
	(Port I3)	TxIN 26	—	DVAL	DVAL	Tap 2 D1	Tap7 D4
	(Port I4)	TxIN 23	—	Exposure Active	Exposure Active	Tap 3 D0	Tap7 D1

SP-5000M/C-PMCL							
Port	Camera Link Configuration		Base	Medium	Full	80bit	
	Camera Link port/bit		2Tap / 12bit	4Tap / 12bit	8 Tap / 8bit	8 Tap / 10bit	
	GenICam Tap Geometry		1X2 - 1Y	1X4 - 1Y	1x8 - 1Y	1X8 - 1Y	
Digital I/O	Port G0	TxIN 0	—	—	Tap 7 D0	Tap 7 D2	Tap7 D5
	Port G1	TxIN 1	—	—	Tap 7 D1	Tap 7 D3	Tap7 D6
	Port G2	TxIN 2	—	—	Tap 7 D2	Tap 7 D4	Tap7 D7
	Port G3	TxIN 3	—	—	Tap 7 D3	Tap 7 D5	Tap8 D0
	Port G4	TxIN 4	—	—	Tap 7 D4	Tap 7 D6	Tap8 D1
	Port G5	TxIN 6	—	—	Tap 7 D5	Tap 7 D7	Tap8 D3
	Port G6	TxIN 27	—	—	Tap 7 D6	Tap 7 D8	LVAL
	Port G7	TxIN 5	—	—	Tap 7 D7	Tap 7 D9	Tap8 D2
	Port H0	TxIN 7	—	—	Tap 8 D0	Tap 8 D2	Tap8 D4
	Port H1	TxIN 8	—	—	Tap 8 D1	Tap 8 D3	Tap8 D5
	Port H2	TxIN 9	—	—	Tap 8 D2	Tap 8 D4	Tap8 D6
	Port H3	TxIN 12	—	—	Tap 8 D3	Tap 8 D5	Tap 9 D1
	Port H4	TxIN 13	—	—	Tap 8 D4	Tap 8 D6	Tap 9 D2
	Port H5	TxIN 14	—	—	Tap 8 D5	Tap 8 D7	Tap 9 D3
	Port H6	TxIN 10	—	—	Tap 8 D6	Tap 8 D8	Tap8 D7
	Port H7	TxIN 11	—	—	Tap 8 D7	Tap 8 D9	Tap 9 D0
	(Port I5)	TxIN 15	—	—		Tap 3 D1	Tap 9 D4
	(Port I6)	TxIN 18	—	—		Tap 4 D0	Tap 9 D7
	(Port I7)	TxIN 19	—	—		Tap 4 D1	Tap10 D0
	(Port K0)	TxIN 20	—	—		Tap 5 D0	Tap10 D1
	(Port K1)	TxIN 21	—	—		Tap 5 D1	Tap10 D2
	(Port K2)	TxIN 22	—	—		Tap 6 D0	Tap10 D3
	(Port K3)	TxIN 16	—	—		Tap 6 D1	Tap 9 D5
	(Port K4)	TxIN 17	—	—		Tap 7 D0	Tap 9 D6
	-	TxIN 24	—	—	LVAL	LVAL	Tap10 D5
	(Port K5)	TxIN 25	—	—	FVAL	Tap 7 D1	Tap10 D6
	(Port K6)	TxIN 26	—	—	DVAL	Tap 8 D0	Tap10 D7
	(Port K7)	TxIN 23	—	—	Exposure Active	Tap 8 D1	Tap10 D4

Note

- In this table, not all tap geometry items are described. For instance, 1X4-1Y shows only 12-bit. In case of 10-bit, upper 2 bits (D10 and D11) are not used and in case of 8-bit, upper 4 bits (D8 through D11) are not used.
- Please check whether the frame grabber complies with those formats if you use 80-bit (8-tap/10-bit) camera configuration.
- If you use 80-bit (8-tap/10-bit) camera configuration, DVAL and Exposure Active (JAI custom) are not output through the Camera Link interface. FVAL is only output via Digital I/O-1 connector.

5.2.2 Camera Link pixel clock frequency

In the SP-5000M-PMCL and SP-5000C-PMCL, the Camera Link pixel clock can be selected from 82.3 MHz, 75.4 MHz and 61.7 MHz. If the 61.7 MHz clock is used, the transfer length through the camera link cable will be extended to 10m. On the other hand, the frame rate will be reduced. The default setting is 82.3 MHz.

Camera Link Pixel Clock	Maximum length	1X2-1Y	1X4-1Y	1X8-1Y	1X10-1Y
61.7 MHz	10 m	23 fps	—	—	—
	7 m		46 fps	93 fps	115 fps
75.4 MHz	7 m	28 fps	56 fps	112 fps	—
	5 m				134 fps
82.3 MHz	5 m	30 fps	61 fps	120 fps	134 fps

Note: The maximum lengths shown in the above table are guidelines. Operating at these lengths may generate bit noise, depending on the cable used.

5.3 Digital IN/OUT interface

In the SP-5000M-PMCL and SP-5000C-PMCL, the software control tool can assign the necessary signals used in the system to digital inputs and outputs (see Section 5.3.7.1 for block diagram).

5.3.1 Line Selector

In the Line Selector, the following input and output signals can be assigned.

Table-7 Line selector

Line Selector item	Description
Line 1 TTL 1 Out	TTL 1 output from Hirose 12P #9 pin
Line 8 TTL 2 OUT	TTL 2 output from AUX Hirose 10P #1 pin
Line 10 TTL 3 OUT	TTL 3 output from AUX Hirose 10P #2 pin
NAND 0 IN 1	No. 1 input to the first NAND gate
NAND 0 IN 2	No. 2 input to the first NAND gate
NAND 1 IN 1	No. 1 input to the second NAND gate
NAND 1 IN 2	No. 2 input to the second NAND gate

5.3.2 Line Source

Line source signal can be selected from the following table to connect it to the line item which is selected in the line selector.

Table-8 Line Source

Line Source item	Description
Low	Connect Low Level signal to line item selected in Line Selector, Default setting
High	Connect High Level signal to line item selected in Line Selector
Frame Trigger Wait	Connect Frame Trigger Wait signal to line item selected in Line Selector
Frame Active	Connect Frame Active signal to line item selected in Line Selector
Exposure Active	Connect Exposure Active signal to line item selected in Line Selector
FVAL	Connect FVAL signal to line item selected in Line Selector
LVAL	Connect LVAL signal to line item selected in Line Selector
PulseGenerator0 Out	Connect Pulse Generator 0 signal to line item selected in Line Selector
PulseGenerator1 Out	Connect Pulse Generator 1 signal to line item selected in Line Selector
PulseGenerator2 Out	Connect Pulse Generator 2 signal to line item selected in Line Selector
PulseGenerator3 Out	Connect Pulse Generator 3 signal to line item selected in Line Selector
TTL 1 In	Connect TTL 1 IN signal to line item selected in Line Selector
CL CC1 In	Connect CL CC1 IN signal to line item selected in Line Selector
NAND 0 Out	Connect NAND 0 signal to line item selected in Line Selector
NAND 1 Out	Connect NAND 1 signal to line item selected in Line Selector
Line 10 TTL 2 In	Connect TTL 2 IN signal to Line 10 (Option)
Line 11 LVDS 1 In	Connect LVDS 1 IN signal to Line 11 (Option)
Note]	
As for LVAL, some line items cannot be connected. Refer to "5.3.7.2 GPIO matrix table"	

5.3.3 Line Mode

Indicates the status of the item selected in Line Selector. (INPUT or OUTPUT)

5.3.4 Line Inverter

Inverts the signal polarity for the item selected in Line Selector.
(False=Positive, True=Negative)

5.3.5 Line Status

Indicates the status of the selected signal (input or output) (True=High, False=Low)

5.3.6 Line Format

Indicates the interface information of the input and output lines.

Not connected, TTL, LVDS or Opto-coupled

Note: In the SP-5000-PMCL, Opto-coupled interface is not available.

5.3.7 GPIO

GPIO is a general interface for input and output and controls the I/O for trigger signals and other valid signals and pulse generators. By using this interface you can control an external light source, make a delay function for an external trigger signal, or make a precise exposure setting together with a PWC trigger.

5.3.7.1 Basic block diagram

The basic block diagram is as follows.

In the SP-5000-PMCL, the pixel clock is 48 MHz.




Fig.6 GPIO interface

Note: Items written in blue letters are available if the AUX Type 3 option is selected.

5.3.7.2 Input and output matrix table

The relation between input and output is as follows.

Table-9 GPIO matrix table

Selector (Cross point switch output)	Trigger Selector	Line Selector						Pulse Generator Selector			
		Trigger Source (Frame Start)	Line 1 - 12P TTL Out	Line 8 - TTL 2 Out	Line 9 - TTL 3 Out	NAND 1 In 1	NAND 1 In 2	NAND 2 In 1	NAND 2 In 2	Pulse Generator 0	Pulse Generator 1
Source signal (Cross point switch input)											
Low	○	○	○	○	○	○	○	○	○	○	○
High	○	○	○	○	○	○	○	○	○	○	○
Soft Trigger	○	×	×	×	×	×	×	×	×	×	×
Exposure Active	×	○	○	○	○	○	○	○	○	○	○
Frame Trigger Wait	×	○	○	○	○	○	○	○	○	○	○
Frame Active	×	○	○	○	○	○	○	○	○	○	○
FVAL	×	○	○	○	○	○	○	○	○	○	○
LVAL	×	×	×	×	×	×	×	×	○	○	○
Pulse Generator 0	○	○	○	○	○	○	○	○	×	○	○
Pulse Generator 1	○	○	○	○	○	○	○	○	○	×	○
Pulse Generator 2	○	○	○	○	○	○	○	○	○	○	×
Pulse Generator 3	○	○	○	○	○	○	○	○	○	○	○
Line 4 - TTL In1	○	○	○	○	○	○	○	○	○	○	○
Line 7 - CL CC1 in	○	○	○	○	○	○	○	○	○	○	○
NAND 0 Out	○	○	○	○	×	×	○	○	○	○	○
NAND 1 Out 1	○	○	○	○	○	○	×	×	○	○	○
Line 10 - TTL 2 In	○	○	○	○	○	○	○	○	○	○	○
Line 11 - LVDS 1 In	○	○	○	○	○	○	○	○	○	○	○
	Trigger Source	Line Source						Pulse Generator Clear Source			

Note: In the above table, TTL 2 IN, LVDS IN, TTL 2 Out and TTL 3 Out are available only if AUX Type 3 option is used.

5.4 Pulse Generator

The SP-5000-PMCL has a frequency divider using the sensor clock as the basic clock and four pulse generators. In each Pulse Generator, various Clear settings are connected to GPIO. The following shows Pulse Generator default settings.

Table - 10 Pulse Generator default settings

Display Name	Value								
Clock Pre-scaler	1								
Pulse Generator Selector	Pulse Generator								
	Length	Start Point	End Point	Repeat Count	Clear Source	Clear Inverter	Clear Activation	Clear Sync Mode	
	- Pulse Generator 0	1	0	1	0	Off	True	Off	Async Mode
	- Pulse Generator 1	1	0	1	0	Off	True	Off	Async Mode
	- Pulse Generator 2	1	0	1	0	Off	True	Off	Async Mode
	- Pulse Generator 3	1	0	1	0	Off	True	Off	Async Mode

Note:]

When Pulse Generator Repeat Count is set to "0", the camera is operating in free-running mode. However, based on the above default settings, Length=1, Start Point=0 and End Point=1, Pulse Generator stops at High output. Therefore, if Start Point=0 and End Point=1 are configured, Length should be "2" as the minimum active width.

5.4.1 Clock Pre-scaler

Clock pre-scaler (Divide Value) can set the dividing value of the frequency divider (12-bit length) and the sensor clock is used for this. Four built-in pulse generators work by the same clock. In the SP-5000-PMCL, the sensor clock is 48 MHz.

5.4.2 Pulse Generator Selector

This is where you select one of the 4 pulse generators in order to set or modify its parameters.

Table - 11 Pulse Generator setting

Trigger Selector item	Description
Pulse Generator 0	If Pulse Generator 0 is selected, Length, Start Point, End Point, Repeat Count, Clear Source, Clear Inverter, Clear Activation and Clear Sync Mode of Pulse Generator 0 are displayed under the selector.
Pulse Generator 1	If Pulse Generator 1 is selected, Length, Start Point, End Point, Repeat Count, Clear Source, Clear Inverter, Clear Activation and Clear Sync Mode of Pulse Generator 1 are displayed under the selector.
Pulse Generator 2	If Pulse Generator 2 is selected, Length, Start Point, End Point, Repeat Count, Clear Source, Clear Inverter, Clear Activation and Clear Sync Mode of Pulse Generator 2 are displayed under the selector.
Pulse Generator 3	If Pulse Generator 3 is selected, Length, Start Point, End Point, Repeat Count, Clear Source, Clear Inverter, Clear Activation and Clear Sync Mode of Pulse Generator 3 are displayed under the selector.




Fig.7 Pulse Generator pulse construction

5.4.3 Pulse Generator Length

Set the counter up value for the selected pulse generator. If Repeat Count value is “0” and if Pulse Generator Clear signal is not input, the pulse generator generates the pulse repeatedly until reaching this counter up value.

5.4.4 Pulse Generator Start Point

Set the active output start count value for the selected pulse generator. However, please note that a maximum 1 clock jitter for the clock which is divided in the clock pre-scaler can occur.

5.4.5 Pulse Generator End Point

Set the active output ending count value for the selected pulse generator.

5.4.6 Pulse Generator Repeat Count

Set the repeating number of the pulse for the selected pulse generator. After Trigger Clear signal is input, the pulse generator starts the count set in Repeat Count. Accordingly, an active pulse which has a start point and end point can be output repeatedly. However, if Repeat Count is set to “0”, it works as free-running counter.

5.4.7 Pulse Generator Clear Activation

Set the clear conditions of clear count pulse for the selected pulse generator.

5.4.8 Pulse Generator Clear Sync Mode

Set the count clear method for the selected pulse generator.

In case of Async Mode, if the clear signal is input during the length setting value, the counter will stop counting according to the clear signal input.

In case of Sync Mode, if the clear signal is input during the length setting value, the counter will continue to count until the end of the length setting value and then clear the count.

Both modes clear the repeat count when the counter is cleared.

(Example 1) Clear Activation = Rising Edge, Clear Sync Mode = Async Mode,
Clear Inverter = False




Fig.8 Counter clear in Async mode

(Example 2) Clear Activation = Rising Edge, Clear Sync Mode = Sync Mode,
Clear Inverter = False




Fig.9 Counter clear in Sync mode

5.4.9 Pulse Generator Clear Source

The following clear sources can be selected as the pulse generator clear signal.

Table - 12 Pulse generator clear source

Pulse Generator Clear Source item	Description
Low	Connect Low level signal to Clear Source for the selected pulse generator. Default setting
High	Connect High level signal to Clear Source for the selected pulse generator.
Frame Trigger Wait	Connect Frame Trigger Wait signal to Clear Source for the selected pulse generator.
Frame Active	Connect Frame Active signal to Clear Source for the selected pulse generator.
Exposure Active	Connect Exposure Active signal to Clear Source for the selected pulse generator.
FVAL	Connect FVAL signal to Clear Source for the selected pulse generator.
LVAL	Connect LVAL signal to Clear Source for the selected pulse generator.
PulseGenerator0 Out	Connect Pulse Generator 0 output to Clear Source for the selected pulse generator.
PulseGenerator1 Out	Connect Pulse Generator 1 output to Clear Source for the selected pulse generator.
PulseGenerator2 Out	Connect Pulse Generator 2 output to Clear Source for the selected pulse generator.
PulseGenerator3 Out	Connect Pulse Generator 3 output to Clear Source for the selected pulse generator.
TTL 1 In	Connect TTL 1 IN signal to Clear Source for the selected pulse generator.
CL CC1 In	Connect CL CC1 IN signal to Clear Source for the selected pulse generator.
Nand0 Out	Connect NAND 0 output signal to Clear Source for the selected pulse generator.
Nand1 Out	Connect NAND 1 output signal to Clear Source for the selected pulse generator.
Line 10 TTL 2 In	Connect TTL 2 IN signal to Line 10.
Line 11 LVDS 1 In	Connect LVDS 1 IN signal to Line 11.
<p>Note: The pulse generator output cannot be used as the clear input to the same pulse generator. Refer to “5.3.7.2.GPIO matrix table” .</p>	

5.4.10 Pulse Generator Inverter

Clear Source Signal can be have polarity inverted.

5.4.11 Pulse Generator Setting table

Table - 13 Pulse Generator setting parameters

Display Name	Value
Clock Pre-scaler	1 to 4096
Pulse Generator Clock (MHZ)	[Pixel Clock:48MHz]÷[Clock Pre-scaler]
Pulse Generator Selector	<ul style="list-style-type: none"> - Pulse Generator 0 - Pulse Generator 1 - Pulse Generator 2 - Pulse Generator 3
- Pulse Generator Length	1 to 1048575
- Pulse Generator Length (ms)	$([\text{Clock Source}] \div [\text{Clock Pre-scaler}])^{-1} \times [\text{Pulse Generator Length}]$
- Pulse Generator Frequency (Hz)	$[\text{Pulse Generator Length (ms)}]^{-1}$
- Pulse Generator Start Point	0 to 1048574
- Pulse Generator Start Point (ms)	$([\text{Clock Source}] \div [\text{Clock Pre-scaler}])^{-1} \times [\text{Pulse Generator Start Point}]$
- Pulse Generator End Point	1 to 1048575
- Pulse Generator End Point (ms)	$([\text{Clock Source}] \div [\text{Clock Pre-scaler}])^{-1} \times [\text{Pulse Generator End Point}]$
- Pulse Generator pulse-width (ms)	$[\text{Pulse Generator End Point (ms)}] - [\text{Pulse Generator Start Point (ms)}]$
- Pulse Generator Repeat Count	0 to 255
- Pulse Generator Clear Activation	<ul style="list-style-type: none"> - Off - High Level - Low level - Rising Edge - Falling Edge
Clear Mode for the Pulse Generators	
- Pulse Generator Clear Sync Mode	<ul style="list-style-type: none"> - Async mode - Sync mode
- Pulse Generator Clear Source	<ul style="list-style-type: none"> - Low - High - Frame Trigger Wait - Frame Active - Exposure Active - Fval - Lval - PulseGenerator0 - PulseGenerator1 - PulseGenerator2 - PulseGenerator3 - TTL_In1 - CL_CC1_In - Nand0 Out - Nand1 Out - Line 10 - TTL 2 In - Line 11 - LVDS 1 In
- Pulse Generator Inverter(Polarity)	- False
Pulse Generator Clear Inverter	- True

Note:

1. If Pulse Generator Repeat Count is set to "0", the pulse generator works in free-running mode.
2. The output of the same pulse generator cannot be connected to Clear input.

6. Sensor layout, output format and timing

6.1 Sensor layout

The CMOS sensors used in the SP-5000M-PMCL and SP-5000C-PMCL have the following pixel layout.

6.1.1 Monochrome sensor




Fig. 10 Monochrome sensor layout

6.1.2 Bayer sensor




Fig. 11 Color sensor layout

6.2 Camera output format (Tap Geometry)

Table - 14 Output format

Camera output format	Bit assignment	Refer to drawing
1X2-1Y	8-bit, 10-bit, 12-bit	6.2.1
1X4-1Y	8-bit, 10-bit, 12-bit	6.2.2
1X8-1Y	8-bit, 10-bit	6.2.3
1X10-1Y	8-bit	6.2.4

Note: The camera output description is based on GenICam SFNC Ver.1.5.1.

6.2.1 1X2-1Y

1X2-1Y is a 2-tap readout system specified in GenICam Tap Geometry and it outputs as the following.




Fig.12 1X2-1Y output format

6.2.2 1X4-1Y

1X4-1Y is a 4-tap readout system specified in GenICam Tap Geometry and it outputs as the following.




Fig. 13 1X4-1Y output format

6.2.3 1X8-1Y

1X8-1Y is an 8-tap readout system and outputs as follows.




Fig. 14. 1X8-1Y output format

6.2.4 1X10-1Y

1X10-1Y is a 10-tap readout system and outputs as follows.




Fig.15 1X10-1Y Output format

6.3 Output timing and output image

6.3.1 Horizontal timing

The horizontal frequency is changed by setting the Tap Geometry.

In the SP-5000M-PMCL and SP-5000C-PMCL, H-binning is available but the horizontal frequency is not changed. Therefore, the frame rate is not increased in H-Binning mode.




Fig. 16 Horizontal timing per 1 tap in Camera Link output

SP-5000M-PMCL / SP-5000C-PMCL

Table 15. Continuous Trigger / Horizontal timing 1X10-1Y (1/2)

Tap Geometry	Pixel Clock	Camera Link	Camera Settings						(a) LVAL Active	(b) LVAL Non-Active	(c) H-Offset	
			AOI				Binning 1: OFF 2*: ON	Horizontal	Vertical	[Unit: Clock]	[Unit: Clock]	[Unit: Clock]
Width	Offset X	Height	Offset Y	Horizontal	Vertical							
1X10 -1Y	82.3 MHz	2560	0	2048	0	1	1	256	256	27 to 30	0	
		1280	0	2048	0	2	1	128	128	155 to 158	0	
		2560	0	1024	0	1	2	256	256	27 to 30	0	
		1280	0	1024	0	2	2	128	128	155 to 158	0	
	75.4 MHz	2560	0	2048	0	1	1	256	256	4 to 6	0	
		1280	0	2048	0	2	1	128	128	132 to 134	0	
		2560	0	1024	0	1	2	256	256	4 to 6	0	
		1280	0	1024	0	2	2	128	128	132 to 134	0	
	61.7 MHz	2560	0	2048	0	1	1	256	256	4 to 6	0	
		1280	0	2048	0	2	1	128	128	132 to 134	0	
		2560	0	1024	0	1	2	258	258	4 to 6	0	
		1280	0	1024	0	2	2	128	128	132 to 134	0	

Table 16. Continuous Trigger / Horizontal timing 1X10-1Y (2/2)

Tap Geometry	Pixel Clock	Camera Link	Camera Settings						1Line Total Clock	Horizontal Frequency	Horizontal Period
			AOI				Binning 1: OFF 2: ON				
Width	Offset X	Height	Offset Y	Horizontal	Vertical				[Unit: Clock]	[Unit: kHz]	[Unit: us]
1X10 -1Y	82.3 MHz	2560	0	2048	0	1	1	a	283 to 286	290.763 to 287.713	3.439 to 3.476
			b						284.56	289.169	3.458
		1280	0	2048	0	2	1	a	283 to 286	290.763 to 287.713	3.439 to 3.476
			b						284.56	289.169	3.458
	75.4 MHz	2560	0	1024	0	1	2	a	283 to 286	290.763 to 287.713	3.439 to 3.476
			b						284.56	289.169	3.458
		1280	0	1024	0	2	2	a	283 to 286	290.763 to 287.713	3.439 to 3.476
			b						284.56	289.169	3.458
	61.7 MHz	2560	0	2048	0	1	1	a	260 to 262	290.112 to 287.897	3.447 to 3.473
			b						260.86	289.155	3.458
		1280	0	2048	0	2	1	a	260 to 262	290.112 to 287.897	3.447 to 3.473
			b						260.86	289.155	3.458
		2560	0	1024	0	1	2	a	260 to 262	290.112 to 287.897	3.447 to 3.473
			b						260.86	289.155	3.458
		1280	0	1024	0	2	2	a	260 to 262	290.112 to 287.897	3.447 to 3.473
			b						260.86	289.155	3.458

Note: a: Actual operating value b: Calculation value

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

Table 17. Continuous Trigger / Horizontal timing 1X8-1Y (1/2)

Tap Geometry	Camera Link Pixel Clock	Camera Settings						(a) LVAL Active [Unit: Clock]	(b) LVAL Non-Active [Unit: Clock]	(c) H-Offset [Unit: Clock]
		AOI			Binning					
Width	Offset X	Height	Offset Y	Horizontal	Vertical					
1X8 -1Y	82.3 MHz	2560	0	2048	0	1 (Off)	1 (Off)	320	4 to 7	0
		1280	0	2048	0	2 (On)	1 (Off)	160	164 to 167	0
		2560	0	1024	0	1 (Off)	2 (On)	320	4 to 7	0
		1280	0	1024	0	2 (On)	2 (On)	160	164 to 167	0
	75.4 MHz	2560	0	2048	0	1 (Off)	1 (Off)	320	4 to 7	0
		1280	0	2048	0	2 (On)	1 (Off)	160	164 to 167	0
		2560	0	1024	0	1 (Off)	2 (On)	320	4 to 7	0
		1280	0	1024	0	2 (On)	2 (On)	160	164 to 167	0
	61.7 MHz	2560	0	2048	0	1 (Off)	1 (Off)	320	3 to 5	0
		1280	0	2048	0	2 (On)	1 (Off)	164	164	0
		2560	0	1024	0	1 (Off)	2 (On)	320	3 to 5	0
		1280	0	1024	0	2 (On)	2 (On)	160	164	0

SP-5000M-PMCL / SP-5000C-PMCL

Table 18. Continuous Trigger / Horizontal timing 1X8-1Y (2/2)

Tap Geometry	Camera Link Pixel Clock	Camera Settings							1Line Total Clock [Unit: Clock]	Horizontal Frequency [Unit: kHz]	Horizontal Period [Unit: us]
		AOI				Binning					
Width	Offset X	Height	Offset Y	Horizontal	Vertical						
1X8 -1Y	82.3 MHz	2560	0	a b	0	1 (Off)	1 (Off)	a	324 to 327	253.969 to 252.639	3.937 to 3.974 3.958
		1280	0	a b	0	2 (On)	1 (Off)	a	324 to 327	253.969 to 252.639	3.937 to 3.974 3.958
		2560	0	a b	0	1 (Off)	2 (On)	a	324 to 327	253.969 to 252.639	3.937 to 3.974 3.958
		1280	0	a b	0	2 (On)	2 (On)	a	324 to 327	253.969 to 252.639	3.937 to 3.974 3.958
	75.4 MHz	2560	0	a b	0	1 (Off)	1 (Off)	a	324 to 327	232.806 to 230.670	4.295 to 4.335
		1280	0	a b	0	2 (On)	1 (Off)	b	325.29	231.882	4.313
		2560	0	a b	0	1 (Off)	2 (On)	a	324 to 327	232.806 to 230.670	4.295 to 4.335
		1280	0	a b	0	2 (On)	2 (On)	b	325.29	231.882	4.313
	61.7 MHz	2560	0	a b	0	1 (Off)	1 (Off)	a	323 to 325	191.065 to 189.889	5.234 to 5.266
		1280	0	a b	0	2 (On)	1 (Off)	b	324.00	190.475	5.250
		2560	0	a b	0	1 (Off)	2 (On)	a	328	188.152	5.315
		1280	0	a	0	2 (On)	2 (On)	b	324.00	190.475	5.250
		2560	0	a b	0	1 (Off)	2 (On)	a	323 to 325	191.065 to 189.889	5.234 to 5.266
		1280	0	a b	0	2 (On)	2 (On)	b	324.00	190.475	5.250
		2560	0	a b	0	1 (Off)	2 (On)	a	328	188.152	5.315
		1280	0	a	0	2 (On)	2 (On)	b	324.00	190.475	5.250

Note: a: Actual operating value b: Calculation value

Table 19. Continuous Trigger / Horizontal timing 1X4-1Y (1/2)

Tap Geometry	Pixel Clock	Camera Link	Camera Settings				(a) LVAL Active	(b) LVAL Non-Active	(c) H-Offset	
			AOI		Binning					
			Width	Offset X	Height	Offset Y	Horizontal	Vertical	[Unit: Clock]	
1X4-1Y	82.3 MHz	2560	0	2048	0	1 (Off)	1 (Off)	640	3 to 6	0
		1280	0	2048	0	2 (On)	1 (Off)	320	323 to 326	0
		2560	0	1024	0	1 (Off)	2 (On)	640	3 to 6	0
		1280	0	1024	0	2 (On)	2 (On)	320	323 to 326	0
	75.4 MHz	2560	0	2048	0	1 (Off)	1 (Off)	640	3 to 6	0
		1280	0	2048	0	2 (On)	1 (Off)	320	323 to 326	0
		2560	0	1024	0	1 (Off)	2 (On)	640	3 to 6	0
		1280	0	1024	0	2 (On)	2 (On)	320	323 to 326	0
	61.7 MHz	2560	0	2048	0	1 (Off)	1 (Off)	640	4 to 7	0
		1280	0	2048	0	2 (On)	1 (Off)	320	324 to 327	0
		2560	0	1024	0	1 (Off)	2 (On)	640	4 to 7	0
		1280	0	1024	0	2 (On)	2 (On)	320	324 to 327	0

SP-5000M-PMCL / SP-5000C-PMCL

Table 20. Continuous Trigger / Horizontal timing 1X4-1Y (2/2)

Tap Geometry	Camera Link Pixel Clock	Camera Settings					1Line Total Clock [Unit: Clock]	Horizontal Frequency [Unit: kHz]	Horizontal Period [Unit: us]
		AOI							
Width	Offset X	Height	Offset Y	Horizontal	Vertical				
1X4 -1Y	82.3 MHz	2560	0	2048	0	a	643 to 646	127.972 to 127.378	7.814 to 7.851
						b	644.57	127.632	7.835
		1280	0	2048	0	a	643 to 646	127.972 to 127.378	7.814 to 7.851
						b	644.57	127.632	7.835
	75.4 MHz	2560	0	1024	0	a	643 to 646	127.972 to 127.378	7.814 to 7.851
						b	644.57	127.632	7.835
		1280	0	1024	0	a	643 to 646	127.972 to 127.378	7.814 to 7.851
						b	644.57	127.632	7.835
	61.7 MHz	2560	0	2048	0	a	643 to 646	117.308 to 116.861	8.525 to 8.557
						b	644.29	117.073	8.542
		1280	0	2048	0	a	643 to 646	117.308 to 116.861	8.525 to 8.557
						b	644.29	117.073	8.542
		2560	0	1024	0	a	643 to 646	117.308 to 116.861	8.525 to 8.557
						b	644.29	117.073	8.542
		1280	0	1024	0	a	643 to 646	117.308 to 116.861	8.525 to 8.557
						b	644.29	117.073	8.542

Note: a: Actual operating value b: Calculation value

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

Table 21. Continuous Trigger / Horizontal timing 1X2-1Y (1/2)

Tap Geometry	Pixel Clock	Camera Link	Camera Settings				(a) LVAL Active	(b) LVAL Non-Active	(c) H-Offset
			Width	Offset X	Height	Offset Y			
1X2-1Y	82.3 MHz	2560	2560	0	2048	0	1 (Off)	1 (Off)	1280
			1280	0	2048	0	2 (On)	1 (Off)	640
			2560	0	1024	0	1 (Off)	2 (On)	1280
			1280	0	1024	0	2 (On)	2 (On)	640
	75.4 MHz	2560	2560	0	2048	0	1 (Off)	1 (Off)	1280
			1280	0	2048	0	2 (On)	1 (Off)	640
			2560	0	1024	0	1 (Off)	2 (On)	1280
			1280	0	1024	0	2 (On)	2 (On)	640
	61.7 MHz	2560	2560	0	2048	0	1 (Off)	1 (Off)	1280
			1280	0	2048	0	2 (On)	1 (Off)	640
			2560	0	1024	0	1 (Off)	2 (On)	1280
			1280	0	1024	0	2 (On)	2 (On)	640

SP-5000M-PMCL / SP-5000C-PMCL

Table 22. Continuous Trigger / Horizontal timing 1X2-1Y (2/2)

Camera Settings								1Line Total Clock [Unit: Clock]	Horizontal Frequency [Unit: kHz]	Horizontal Period [Unit: us]			
Tap Geometry	Link Pixel Clock	AOI			Binning								
		Width	Offset X	Height	Offset Y	Horiz ontal	Verti cal						
1X2 -1Y	82.3 MHz	2560	0	2048	0	1 (Off)	1 (Off)	a 1284 to 1287	64.086 to 63.936	15.604 to 15.641			
						b	1285.72		64.000	15.625			
		1280	0	2048	0	2 (On)	1 (Off)	a 1284 to 1287	64.086 to 63.936	15.604 to 15.641			
						b	1285.72		64.000	15.625			
	75.4 MHz	2560	0	1024	0	1 (Off)	2 (On)	a 1284 to 1287	64.086 to 63.936	15.604 to 15.641			
						b	1285.72		64.000	15.625			
		1280	0	1024	0	2 (On)	2 (On)	a 1284 to 1287	64.086 to 63.936	15.604 to 15.641			
						b	1285.72		64.000	15.625			
61.7 MHz	75.4 MHz	2560	0	2048	0	1 (Off)	1 (Off)	a 1284 to 1287	58.745 to 58.608	17.023 to 17.062			
						b	1285.44		58.680	17.042			
		1280	0	2048	0	2 (On)	1 (Off)	a 1284 to 1287	58.745 to 58.608	17.023 to 17.062			
						b	1285.44		58.680	17.042			
	61.7 MHz	2560	0	1024	0	1 (Off)	2 (On)	a 1284 to 1287	58.745 to 58.608	17.023 to 17.062			
						b	1285.44		58.680	17.042			
		1280	0	1024	0	2 (On)	2 (On)	a 1284 to 1287	58.745 to 58.608	17.023 to 17.062			
						b	1285.44		58.680	17.042			

Note: a: Actual operating value b: Calculation value

6.3.2 Vertical timing

Figure 17 shows the vertical timing of Camera Link output during continuous trigger operation. However, with 1X8-1Y 10-bit and 1X10-1Y 8-bit geometries, which are 80-bit configurations, DVAL and Exposure Active, which are normally output to Camera Link spare bits, are not output through the Camera Link interface as data bits are applied to those bits.

In the SP-5000M-PMCL, H-Binning and V-Binning functions are available but H-Binning function does not make the frame rate faster.




Fig. 17 Vertical timing

In the SP-5000-PMCL, if the trigger overlap is set to “Readout”, the image readout is stopped at the start point of the exposure and delayed in order to avoid interference from the exposure. Therefore, the FVAL Active period is extended by the period for which the readout has been stopped.

Table 23. FVAL Active extended time if FVAL Active is overlapped

Tap Geometry	Camera Link Clock	Exposure Active – At FVAL Active Overlap, FVAL Active extended time	
		[Unit: us]	[Unit: Line]
1X10-1Y	82.3 MHz	55.60	16
	75.4 MHz	55.40	16
	61.7 MHz	67.70	16
1X8-1Y	82.3 MHz	63.40	16
	75.4 MHz	69.10	16
	61.7 MHz	84.10	16
1X4-1Y	82.3 MHz	125.40	16
	75.4 MHz	136.60	16
	61.7 MHz	167.40	16
1X2-1Y	82.3 MHz	250.00	16
	75.4 MHz	273.00	16
	61.7 MHz	333.50	16

SP-5000M-PMCL / SP-5000C-PMCL

Table 24. Continuous Trigger / Vertical timing 1X10-1Y, 1X8-1Y (1/3)

Camera Settings								(A)	(B)	(C)	(D)	
Tap Geometry	Frame Period (Typ.)	ROI		Binning		FVAL & DVAL Active [Unit: Line]	FVAL Non-Active [Unit: Line]	V -Offset [Unit: Line]	Exposure Time (Min) [Unit: us]			
		Width	X Offset	Height	Y Offset							
1X10-1Y	82.3 MHz	7463	2560	0	2048	0	1 (Off)	1 (Off)	2048	110.1 or 111.1	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	110.5 or 111.5		
		3732	2560	0	1024	0	1 (Off)	2 (On)	2048	56.1 or 57.1		
			1280	0	1024	0	2 (On)	2 (On)	1028	56.5 or 57.5		
		8141	2560	0	2048	0	1 (Off)	1 (Off)	2048	306.0 or 307.0		
			1280	0	2048	0	2 (On)	1 (Off)	1028	306.5 or 307.5		
	75.4 MHz	4071	2560	0	1024	0	1 (Off)	2 (On)	2048	154.0 or 155.0	0	10
			1280	0	1024	0	2 (On)	2 (On)	1028	154.5 or 155.5		
		9951	2560	0	2048	0	1 (Off)	1 (Off)	2048	305.0 or 306.0		
			1280	0	2048	0	2 (On)	1 (Off)	1028	305.5 or 306.5		
		4976	2560	0	1024	0	1 (Off)	2 (On)	2048	153.0 or 154.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	153.5 or 154.5		
1X8-1Y	82.3 MHz	8333	2560	0	2048	0	1 (Off)	1 (Off)	2048	57.0 or 58.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	57.5 or 58.5		
		4167	2560	0	1024	0	1 (Off)	2 (On)	2048	29.0 or 30.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	29.5 or 30.5		
		9091	2560	0	2048	0	1 (Off)	1 (Off)	2048	60.0 or 61.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	60.5 or 61.5		
	75.4 MHz	4546	2560	0	1024	0	1 (Off)	2 (On)	2048	30.0 or 31.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	30.5 or 31.5		
		11111	2560	0	2048	0	1 (Off)	1 (Off)	2048	68.0 or 69.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	68.5 or 69.5		
		5556	2560	0	1024	0	1 (Off)	2 (On)	2048	34.0 or 35.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	34.5 or 35.5		

[Note] The above FVAL Active period is the value, when the exposure time is set at "10".

As mentioned before, if the next frame readout is overlapped on the previous frame readout, FVAL Active period is reduced by 16 lines.

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

Table 25. Continuous Trigger / Vertical timing 1X10-1Y (2/3)

Camera Settings								Frame Rate [Unit: Hz]	(E) Exposure Time (Max.) [Unit: us]	(F) Exposure End to FVAL Active Start			
Tap Geometry	Frame Period (Typ.)	ROI				Binning				[Unit: Line]	[Unit: us]		
		Width	X Offset	Height	Y Offset	Horizontal	Vertical						
1X10-1Y	82.3 MHz	7463	2560	0	2048	0	1 (Off)	1 (Off)	133.93	[Frame Period] - 100 = 7463 - 100 = 7363	9.1 to 10.1	31.5 to 34.9	
			1280	0	2048	0	2 (On)	1 (Off)			8.1 to 9.1	28.1 to 31.6	
		3732	2560	0	1024	0	1 (Off)	2 (On)	267.71	3732 - 100 = 3632	9.1 to 10.1	31.5 to 34.9	
			1280	0	1024	0	2 (On)	2 (On)			8.1 to 9.1	28.2 to 31.6	
		8141	2560	0	2048	0	1 (Off)	1 (Off)	122.78	8141 - 100 = 8041	9.1 to 10.1	31.5 to 34.9	
			1280	0	2048	0	2 (On)	1 (Off)			8.1 to 9.1	28.2 to 31.6	
	75.4 MHz	4071	2560	0	1024	0	1 (Off)	2 (On)	245.44	4071 - 100 = 3971	9.1 to 10.1	31.5 to 34.9	
			1280	0	1024	0	2 (On)	2 (On)			8.2 to 9.1	28.2 to 31.6	
		9951	2560	0	2048	0	1 (Off)	1 (Off)	100.46	9951 - 100 = 9851	7.8 to 8.8	33.1 to 37.3	
			1280	0	2048	0	2 (On)	1 (Off)			7.0 to 8.0	29.8 to 34.0	
		4976	2560	0	1024	0	1 (Off)	2 (On)	200.82	4976 - 100 = 4876	7.8 to 8.8	33.1 to 37.2	
			1280	0	1024	0	2 (On)	2 (On)			7.0 to 8.0	29.8 to 33.9	

SP-5000M-PMCL / SP-5000C-PMCL

Table 26. Continuous Trigger / Vertical timing 1X8-1Y (3/3)

Camera Settings								Frame Rate [Unit: Hz]	(E) Exposure Time (Max.) [Unit: us]	(F) Exposure End to FVAL Active Start [Unit: Line] [Unit: us]		
Tap Geometry	Frame Period (Typ.)	ROI			Binning		Frame Rate [Unit: Hz]			[Unit: Line]	[Unit: us]	
Pixel Clock	Link Camera	Width	Offset X	Height	Y Offset	Horizontal	Vertical					
1X8 -1Y	82.3 MHz	8333	2560	0	2048	0	1 (Off)	1 (Off)	119.96	8333 - 100 = 8233	8.3 to 9.2	32.9 to 36.4
			1280	0	2048	0	2 (On)	1 (Off)			7.4 to 8.4	29.3 to 33.1
		9091	2560	0	1024	0	1 (Off)	2 (On)	239.79	4167 - 100 = 4067	8.2 to 9.3	32.5 to 36.7
			1280	0	1024	0	2 (On)	2 (On)			7.4 to 8.4	29.2 to 33.1
		75.4 MHz	2560	0	2048	0	1 (Off)	1 (Off)	109.95	9091 - 100 = 8991	7.7 to 8.7	33.2 to 37.5
			1280	0	2048	0	2 (On)	1 (Off)			6.9 to 7.9	29.9 to 34.2
	61.7 MHz	11111	2560	0	1024	0	1 (Off)	2 (On)	219.81	4546 - 100=4446	7.7 to 8.7	33.2 to 37.5
			1280	0	1024	0	2 (On)	2 (On)			6.9 to 7.9	29.9 to 34.2
		11111	2560	0	2048	0	1 (Off)	1 (Off)	89.97	11111 - 100=11011	7.6 to 8.6	40.0 to 45.2
			1280	0	2048	0	2 (On)	1 (Off)			7.0 to 8.0	36.7 to 41.9
			2560	0	1024	0	1 (Off)	2 (On)	179.86	5556 - 100=5456	7.6 to 8.6	40.0 to 45.17
			1280	0	1024	0	2 (On)	2 (On)			7.6 to 8.7	40.0 to 45.2

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

Table 27. Continuous Trigger / Vertical timing 1X4-1Y, 1X2-1Y (1/3)

Camera Settings								(A)	(B)	(C)	(D)	
Tap Geometry	Frame Period (Typ.)	ROI			Binning		FVAL & DVAL Active [Unit: Line]	FVAL Non-Active [Unit: Line]	V-Offset [Unit: Line]	Exposure Time (Min)		
		Width	X Offset	Height	Y Offset	Horizontal						
1X4-1Y	82.3 MHz	16393	2560	0	2048	0	1 (Off)	1 (Off)	2048	45.0 or 46.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	45.5 or 46.5		
		8197	2560	0	1024	0	1 (Off)	2 (On)	2048	22.0 or 23.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	22.5 or 23.5		
	75.4 MHz	17883	2560	0	2048	0	1 (Off)	1 (Off)	2048	45.0 or 46.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	45.5 or 46.5		
		8942	2560	0	1024	0	1 (Off)	2 (On)	2048	23.0 or 24.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	23.5 or 24.5		
	61.7 MHz	21858	2560	0	2048	0	1 (Off)	1 (Off)	2048	42.0 or 43.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	42.5 or 43.5		
		10929	2560	0	1024	0	1 (Off)	2 (On)	2048	21.0 or 22.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	21.5 or 22.5		
1X2-1Y	82.3 MHz	33333	2560	0	2048	0	1 (Off)	1 (Off)	2048	85.0 or 86.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	85.5 or 86.5		
		16667	2560	0	1024	0	1 (Off)	2 (On)	2048	42.0 or 43.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	42.5 or 43.5		
	75.4 MHz	36363	2560	0	2048	0	1 (Off)	1 (Off)	2048	85.0 or 86.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	85.5 or 86.5		
		18182	2560	0	1024	0	1 (Off)	2 (On)	2048	43.0 or 44.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	43.5 or 44.5		
	61.7 MHz	44444	2560	0	2048	0	1 (Off)	1 (Off)	2048	87.0 or 88.0	0	10
			1280	0	2048	0	2 (On)	1 (Off)	1028	87.5 or 88.5		
		22222	2560	0	1024	0	1 (Off)	2 (On)	2048	43.0 or 44.0		
			1280	0	1024	0	2 (On)	2 (On)	1028	43.5 or 44.5		

[Note] The above FVAL Active period is the value, when the exposure time is set at "10".

As mentioned before, if the next frame readout is overlapped on the previous frame readout, FVAL Active period is reduced by 16 lines. In 1X4-1Y and 1X2-1Y tap geometries, FVAL active starting point becomes earlier depending on the exposure time value. Therefore, FVAL Active period is shortened further.

SP-5000M-PMCL / SP-5000C-PMCL

Table 28. Continuous Trigger / Vertical timing 1X4-1Y (2/3)

Camera Settings								(E) Frame Rate [Unit: Hz]	(F) Exposure Time (Max.) [Unit: us]	(F) Active End to FVAL Active Start			
Tap Geometry	Frame Period (Typ.)	ROI		Binning		[Unit: Line] Max	[Unit: us] Min			[Unit: Line] Max	[Unit: us] Min		
		Width	Offset X	Height	Offset Y	Horizontal	Vertical						
1X4-1Y	82.3 MHz	16393	2560	0	2048	0	1 (Off)	1 (Off)	60.97 16393 - 100 =16293	11.0 to 12.0	5.1 to 6.1	86.5 to 94.2	40.3 to 48.1
			1280	0	2048	0	2 (On)	1 (Off)		10.6 to 11.6	4.7 to 5.7	83.1 to 90.9	37.0 to 44.7
		8197	2560	0	1024	0	1 (Off)	2 (On)	121.95 8197 - 100 =8097	11.0 to 12.0	5.1 to 6.1	86.5 to 94.2	40.3 to 48.1
			1280	0	1024	0	2 (On)	2 (On)		10.6 to 11.6	4.7 to 5.7	83.1 to 90.9	36.9 to 44.7
		17883	2560	0	2048	0	1 (Off)	1 (Off)	55.90 17883 - 100 =17783	11.6 to 12.6	4.9 to 5.9	99.3 to 107.6	41.8 to 50.1
			1280	0	2048	0	2 (On)	1 (Off)		11.2 to 12.2	4.5 to 5.5	95.9 to 104.3	38.4 to 46.9
	75.4 MHz	8942	2560	0	1024	0	1 (Off)	2 (On)	111.78 8942 - 100 =8842	11.6 to 12.6	4.9 to 5.9	99.2 to 107.7	41.7 to 50.2
			1280	0	1024	0	2 (On)	2 (On)		11.2 to 12.2	4.5 to 5.5	95.9 to 104.4	38.4 to 46.9
		21858	2560	0	2048	0	1 (Off)	1 (Off)	45.73 21858 - 100 =21758	12.8 to 13.8	4.4 to 5.4	133.7 to 144.1	45.6 to 56.0
			1280	0	2048	0	2 (On)	1 (Off)		12.5 to 13.5	4.0 to 5.0	130.4 to 140.8	42.3 to 52.7
	61.7 MHz	10929	2560	0	1024	0	1 (Off)	2 (On)	91.45 10929 - 100 =10829	12.8 to 13.8	4.4 to 5.4	133.8 to 144.1	45.6 to 56.0
			1280	0	1024	0	2 (On)	2 (On)		12.5 to 13.5	4.0 to 5.0	130.4 to 140.8	42.3 to 52.7

[Note] In 1X4-1Y Tap Geometry, "Exposure Active End to FVAL Active Start" period varies depending on the exposure time setting. When the exposure time is set at "10", it is the maximum period and if the exposure time is incremented by 1 us, it is decreased.

Table 29. Continuous Trigger / Vertical timing 1X2-1Y (3/3)

Camera Settings								(E) Frame Rate [Unit: Hz]	(F) Exposure Time (Max.) [Unit: us]	(F) Exposure Active End to FVAL Active Start				
Tap Geometry	Frame Period (Typ.)	ROI		Binning		Frame Rate [Unit: Hz]	[Unit: Line]		[Unit: us]		Max	Min	Max	Min
		Width	Offset X	Height	Offset Y		Horizontal	Vertical						
1X2-1Y	82.3 MHz	33333	2560	0	2048	0	1 (Off)	1 (Off)	29.99	33333 - 100 =33233	14.5 to 15.5	3.6 to 4.6	226.9 to 242.2	56.0 to 71.4
			1280	0	2048	0	2 (On)	1 (Off)			14.3 to 15.3	3.4 to 4.4	223.5 to 238.9	52.6 to 68.0
		16667	2560	0	1024	0	1 (Off)	2 (On)	59.98	16667 - 100 =16567	14.5 to 15.5	3.6 to 4.6	226.7 to 242.3	55.9 to 71.4
			1280	0	1024	0	2 (On)	2 (On)			14.3 to 15.3	3.4 to 4.4	223.4 to 238.9	52.7 to 68.1
		36363	2560	0	2048	0	1 (Off)	1 (Off)	27.49	36363 - 100 =36263	14.8 to 15.8	3.4 to 4.4	252.3 to 269.2	58.8 to 75.7
			1280	0	2048	0	2 (On)	1 (Off)			14.6 to 15.6	3.3 to 4.3	248.9 to 265.9	55.5 to 72.4
	75.4 MHz	18182	2560	0	1024	0	1 (Off)	2 (On)	54.96	18182 - 100 =18082	14.8 to 15.8	3.4 to 4.4	252.3 to 269.2	58.8 to 75.7
			1280	0	1024	0	2 (On)	2 (On)			14.6 to 15.6	3.3 to 4.2	249.0 to 265.9	55.5 to 72.4
		44444	2560	0	2048	0	1 (Off)	1 (Off)	22.49	44444 - 100 =44344	15.4 to 16.4	3.2 to 4.2	320.2 to 340.9	66.3 to 87.1
			1280	0	2048	0	2 (On)	1 (Off)			15.2 to 16.2	3.0 to 4.0	316.9 to 337.5	63.1 to 83.7
	61.7 MHz	22222	2560	0	1024	0	1 (Off)	2 (On)	44.98	22222 - 100 =22122	15.4 to 16.4	3.2 to 4.2	320.1 to 340.9	66.3 to 87.1
			1280	0	1024	0	2 (On)	2 (On)			15.2 to 16.2	3.0 to 4.0	316.8 to 337.6	63.1 to 83.7

[Note] In 1X2-1Y Tap Geometry, "Exposure Active End to FVAL Active Start" period varies depending on the exposure time setting. When the exposure time is set at "10", it is the maximum period and if the exposure time is incremented by 1 us, it is decreased.

6.3.3 ROI (Region Of Interest) setting

In the SP-5000-PMCL, a subset of the image can be output by setting Width, Height, Offset-X, and Offset-Y. If the height is decreased, the number of lines read out is decreased and as the result, the frame rate is increased. However, in the horizontal direction, the horizontal frequency is not changed if the width is decreased. In the SP-5000M-PMCL, the minimum width is "16" and minimum height is "1". In the SP-5000C-PMCL, the minimum width is "16" and minimum height is "2".

Setting example (1)

Binning Horizontal = 1
Binning Vertical = 1

Setting example (2)

Binning Horizontal = 2
Binning Vertical = 2




Fig. 18 Setting example (No binning)




Fig.19 Setting example (Binning)

6.4 Digital output bit allocation

Table -30 Output level

CCD out		Digital Out		
		8-bit	10-bit	12-bit
Black	0%	8LSB	32LSB	128LSB
Monochrome				
Color	100%	222LSB	890LSB	3560LSB
Monochrome				
Color	115%	255LSB	1023LSB	4095LSB




Fig. 20 Bit allocation (10-bit)

7. Operating modes

7.1. Acquisition control (change the frame rate)

7.1.1 Acquisition control

With Trigger OFF (free-running mode) the frame rate is less than Height Max.rmal ROI setting.. As described before, in Multi ROI operation, h is the same for all 8 default frame rates. However, it is possible to specify a free-running frame rate (i.e., no trigger needed) that is slower than the default rate. This can be useful when a longer exposure time is needed for a specific ROI.

Modification of the frame rate is done by entering a value in the AcquisitionFrameRate control corresponding to the number of microseconds to be allocated to each frame period. Allowed values range from 167 µs to 8,000,000 (8 seconds) depending on the ROI and the tap geometry specified. However if the value entered is less than the time required for the default frame rate, the setting is ignored and the default frame rate is used. For example, in 1X10-1Y camera output format with an 82.3 MHz Camera Link pixel clock, the minimum frame period for the smallest possible ROI (1 line) requires 167 microseconds, so any entry less than 167 will always be ignored in this configuration.

The setting range in Acquisition Frame Rate is:

Shortest	to	Longest
Time required to expose and read out all pixels in the area set by ROI command	to	0.125 Hz = 8 seconds

How to set:

ROI should be set first.

The available number shown in Acquisition Frame Rate will correspond to the standard frame period for the specified ROI.

The value can be increased up to 8,000,000 (8 seconds).

If ROI is changed from a smaller size to a larger size, the default frame rate of the ROI is automatically recalculated inside the camera and changed to the slower frame rate of the larger ROI.

ROI setting:

Height: 1 line to 2048 lines for SP-5000M-PMCL
2 lines to 2048 lines for SP-5000C-PMCL

As for the details of ROI settings, refer to section 6.3.3.

7.1.2 Frame Rate Calculation

The frame rate can be calculated by using the following tables.

SP-5000M-PMCL / SP-5000C-PMCL

Table 31. Frame rate calculation (Continuous Trigger, HDR Mode = “Off”)

Tap Geometry	Camera Link Clock	V -Binning	Continuous Trigger / HDR Mode = “Off” ART Command Minimum value setting calculation [Unit: us]
1X10-Y	82.3 MHz	Off	= ROUND(((Height] x 284.56)+13495) ÷ (82.286MHz x 10^6)
	82.3 MHz	On	= ROUND(((Height] x 284.56)+(13495 ÷ 2)) ÷ (82.286MHz x 10^6)
	75.4 MHz	Off	= ROUND(((Height] x 260.86)+13495) ÷ (75.429MHz x 10^6)
	75.4 MHz	On	= ROUND(((Height] x 260.86)+(13495 ÷ 2)) ÷ (75.429MHz x 10^6)
1X8-Y	61.7 MHz	Off	= ROUND(((Height] x 261.00)+13495) ÷ (61.714MHz x 10^6)
	61.7 MHz	On	= ROUND(((Height] x 261.00)+(13495 ÷ 2)) ÷ (61.714MHz x 10^6)
	82.3 MHz	Off	= ROUND(((Height] x 325.71)+13495) ÷ (82.286MHz x 10^6)
	82.3 MHz	On	= ROUND(((Height] x 325.71)+(13495 ÷ 2)) ÷ (82.286MHz x 10^6)
1X4-Y	75.4 MHz	Off	= ROUND(((Height] x 325.29)+13495) ÷ (75.429MHz x 10^6)
	75.4 MHz	On	= ROUND(((Height] x 325.29)+(13495 ÷ 2)) ÷ (75.429MHz x 10^6)
	61.7 MHz	Off	= ROUND(((Height] x 324.00)+13495) ÷ (61.714MHz x 10^6)
	61.7 MHz	On	= ROUND(((Height] x 324.00)+(13495 ÷ 2)) ÷ (61.714MHz x 10^6)
1X2-Y	82.3 MHz	Off	= ROUND(((Height] x 1285.72)+64677) ÷ (82.286MHz x 10^6)
	82.3 MHz	On	= ROUND(((Height] x 1285.72)+(64677 ÷ 2)) ÷ (82.286MHz x 10^6)
	75.4 MHz	Off	= ROUND(((Height] x 1285.44)+64677) ÷ (75.429MHz x 10^6)
	75.4 MHz	On	= ROUND(((Height] x 1285.44)+(64677 ÷ 2)) ÷ (75.429MHz x 10^6)
	61.7 MHz	Off	= ROUND(((Height] x 1284.42)+64677) ÷ (61.714MHz x 10^6)
	61.7 MHz	On	= ROUND(((Height] x 1284.42)+(64677 ÷ 2)) ÷ (61.714MHz x 10^6)

Table 32. Frame rate calculation (Continuous Trigger, HDR Mode = “ON”)

Tap Geometry	Camera Link Clock	Continuous Trigger / HDR Mode = “On” ART Command Minimum value setting calculation [Unit: us]
1X10-1Y	82.3 MHz	=ROUND((((Height])x284.56) + 4855 - 284.56 + ([Width]÷10)) ÷ 82.286MHz x 10^6) + [Exposure Time]
	75.4 MHz	=ROUND((((Height])x260.86) + 4855 - 260.86 + ([Width]÷10)) ÷ 75.429MHz x 10^6) + [Exposure Time]
	61.7 MHz	=ROUND((((Height])x261.00) + 4855 - 261.00 + ([Width]÷10)) ÷ 61.714MHz x 10^6) + [Exposure Time]
1X8-1Y	82.3 MHz	=ROUND((((Height])x325.71) + 5513 - 325.71 + ([Width]÷8)) ÷ 82.286MHz x 10^6) + [Exposure Time]
	75.4 MHz	=ROUND((((Height])x325.29) + 5513 - 325.29 + ([Width]÷8)) ÷ 75.429MHz x 10^6) + [Exposure Time]
	61.7 MHz	=ROUND((((Height])x324.00) + 5513 - 324.00 + ([Width]÷8)) ÷ 61.714MHz x 10^6) + [Exposure Time]
1X4-1Y	82.3 MHz	=ROUND((((Height])x644.57) + 10944 - 644.57 + ([Width]÷4)) ÷ 82.286MHz x 10^6) + [Exposure Time]
	75.4 MHz	=ROUND((((Height])x644.29) + 10944 - 644.29 + ([Width]÷4)) ÷ 75.429MHz x 10^6) + [Exposure Time]
	61.7 MHz	=ROUND((((Height])x645.43) + 10944 - 645.43 + ([Width]÷4)) ÷ 61.714MHz x 10^6) + [Exposure Time]
1X2-Y	82.3 MHz	=ROUND((((Height])x1285.72) + 21888 - 1285.72 + ([Width]÷2)) ÷ 82.286MHz x 10^6) + [Exposure Time]
	75.4 MHz	=ROUND((((Height])x1285.44) + 21888 - 1285.44 + ([Width]÷2)) ÷ 75.429MHz x 10^6) + [Exposure Time]
	61.7 MHz	=ROUND((((Height])x1284.42) + 21888 - 1284.42 + ([Width]÷2)) ÷ 61.714MHz x 10^6) + [Exposure Time]

[Note] The same formula is applied if Binning function is enabled.

Table 33. Frame rate setting range(Typical) (Continuous Trigger) (1/2)

Camera Settings						ART Command value : limited reference			
Tap Geometry	Camera Link Pixel Clock	Binning	Vertical	Height	HDR Mode	Min.		Max.	
						Setting value	Actual period	Setting value	Actual time /period
1X10 -1Y	82.3 MHz	1 (Off)	2048	Off	7246 (138.007fps)	137.9 fps	8 000 000	8 sec / 0.125 Hz	
		2 (On)	1024	Off	3623 (276.014fps)	275.7 fps			
	75.4 MHz	1 (Off)	2048	Off	7262 (137.703fps)	137.6 fps			
		2 (On)	1024	Off	3631 (275.406fps)	275.1 fps			
	61.7 MHz	1 (Off)	2048	Off	8880 (112.613fps)	112.5 fps			
		2 (On)	1024	Off	4440 (225.225fps)	225.2 fps			
	82.3 MHz	1 (Off)	2048	On	7151 (139.841fps)	139.7 fps			
		2 (On)	1024	On	3610 (277.008fps)	276.7 fps			
	75.4 MHz	1 (Off)	2048	On	7157 (139.723fps)	139.6 fps			
		2 (On)	1024	On	3616 (276.549fps)	276.3 fps			
	61.7 MHz	1 (Off)	2048	On	8750 (114.286fps)	114.2 fps			
		2 (On)	1024	On	4419 (226.296fps)	226.1 fps			
1X8 -1Y	82.3 MHz	1 (Off)	2048	Off	8271 (120.904fps)	120.8 fps			
		2 (On)	1024	Off	4135 (241.838fps)	241.8 fps			
	75.4 MHz	1 (Off)	2048	Off	9011 (110.975fps)	110.9 fps			
		2 (On)	1024	Off	4505 (221.976fps)	221.9 fps			
	61.7 MHz	1 (Off)	2048	Off	10971 (91.149fps)	91.1 fps			
		2 (On)	1024	Off	5485 (182.315fps)	182.3 fps			
	82.3 MHz	1 (Off)	2048	On	8183 (122.205fps)	122.1 fps			
		2 (On)	1024	On	4130 (242.131fps)	241.9 fps			
	75.4 MHz	1 (Off)	2048	On	8915 (101.885fps)	112.1 fps			
		2 (On)	1024	On	4499 (222.272fps)	222.1 fps			
	61.7 MHz	1 (Off)	2048	On	10851 (92.157fps)	92.1 fps			
		2 (On)	1024	On	5475 (182.648fps)	182.5 fps			

[Note]

- (1) The SP-5000-PMCL has maximum 1 line jitter even in continuous trigger operation. Therefore, the actual frame rate might be slower than the setting value.
- (2) If HDR Mode is set to "On", the exposure of the next frame cannot be done while the previous frame is read out. Due to this, the frame rate is slower than with HDR Mode "Off".
- (3) If HDR Mode is set to "On", the fastest frame rate can be achieved when the exposure time is set to "10". As mentioned before, the image readout and exposure cannot be overlapped when HDR mode is ON, thus the fastest frame rate is influenced by the exposure time.

SP-5000M-PMCL / SP-5000C-PMCL

Table 34. Frame rate setting range(Typical) (Continuous Trigger) (2/2)

Camera Settings					ART Command: Limited Reference			
Tap Geometry	Pixel Clock	Link	Binning Vertical	Height	HDR Mode	Min.	Max.	
						Setting Value	Actual Period	Setting Value
1X4 -1Y	82.3 MHz		1 (Off)	2048	Off	16327 (61.248fps)	61.2 fps	8 sec / 0.125 Hz
			2 (On)	1024	Off	8163 (122.504fps)	122.5 fps	
	75.4 MHz		1 (Off)	2048	Off	17803 (56.170fps)	56.1 fps	
			2 (On)	1024	Off	8905 (112.296fps)	112.2 fps	
	61.7 MHz		1 (Off)	2048	Off	21797 (45.878fps)	45.8 fps	
			2 (On)	1024	Off	10889 (91.836fps)	91.7 fps	
	82.3 MHz		1 (Off)	2048	On	16186 (61.782fps)	61.7 fps	
			2 (On)	1024	On	8164 (122.489fps)	122.4 fps	
	75.4 MHz		1 (Off)	2048	On	17648 (56.664fps)	56.6	
			2 (On)	1024	On	8902 (112.334fps)	112.2 fps	
1X2 -1Y	61.7 MHz		1 (Off)	2048	On	21606 (112.334fps)	46.2 fps	8 000 000
			2 (On)	1024	On	10897 (91.768fps)	91.7 fps	
	82.3 MHz		1 (Off)	2048	Off	32786 (30.501fps)	30.5 fps	
			2 (On)	1024	Off	16393 (61.002fps)	61.0 fps	
	75.4 MHz		1 (Off)	2048	Off	35759 (27.965fps)	27.9 fps	
			2 (On)	1024	Off	17879 (55.932fps)	55.9 fps	
	61.7 MHz		1 (Off)	2048	Off	43672 (22.898fps)	22.8 fps	
			2 (On)	1024	Off	21836 (45.796fps))	45.7 fps	
	82.3 MHz		1 (Off)	2048	On	32276 (30.983fps)	30.9 fps	
			2 (On)	1024	On	16276 (61.440fps)	61.4 fps	
	75.4 MHz		1 (Off)	2048	On	35202 (28.407fps)	28.4 fps	
			2 (On)	1024	On	17751 (56.335fps)	56.3 fps	
	61.7 MHz		1 (Off)	2048	On	43022 (23.244fps)	23.2 fps	
			2 (On)	1024	On	21693 (46.098fps)	46.0 fps	

7.2. Exposure setting

7.2.1 Mode

Exposure Mode sets which exposure mode is to be used.

If the trigger is used, Frame Start must also be used.

When Exposure Mode is set to Timed or Trigger Width, the combination of Exposure Mode and Frame Start can set various operations.

The following table shows the operation depending on the combination.

Table -35 Exposure mode and trigger control matrix table

Exposure Mode	Trigger Control	Trigger mode OFF	Trigger mode ON
		Behavior	
OFF	OFF or ON	Free-running No exposure control	-
Timed (EPS) Timed(RCT) Timed (PIV)	OFF	Free-running Exposure control available	-
	ON	-	Operate in EPS, RCT or PIV
Trigger width	OFF	Free-running No exposure control	-
	ON	-	Exposure control by trigger width

Trigger Control select

Frame Start trigger: Sets whether the start of the frame is controlled externally or not.

Trigger mode ON: If Acquisition Active is active and Exposure Mode chooses Timed or Trigger Width, the exposure will be started by using the signal set in Frame Trigger as the trigger.

Trigger mode OFF: If Acquisition Active is active, the camera operates in free-running mode.

Exposure mode can be selected from the followings.

OFF: No shutter control

Timed: The exposure will be done in the preset period. The setting can be done in μ sec units.

Frame Start OFF: Free-running mode and exposure control is available.

Frame Start ON: EPS operation mode

In this status, if RCT or PIV is selected as the Trigger option, the camera will operate in each mode respectively.

Trigger Width: The exposure will be controlled by the width of the trigger pulse.

Frame Start OFF: Free-running mode and control the exposure

Frame Start ON: PWC operation mode

7.2.2 ExposureTime

This command is effective only when Exposure Mode is set to Timed. It is for setting exposure time. The setting step for exposure time is 1 μ sec per step.

Minimum: 10 μ sec

Maximum: 8 seconds

Note: In the continuous trigger mode (Frame Start Trigger Mode: OFF), the maximum setting value of the exposure time is limited by the frame rate setting. In the SP-5000-PMCL, the maximum value of exposure time is “Frame Rate - 100”. If the exposure mode is OFF, the maximum value of exposure time is set in the camera. If the frame period is changed, then the maximum value of exposure time is renewed.

7.2.3 ExposureAuto

This is a function to control the exposure automatically. It is effective only for Timed. ALC Reference controls the target brightness level.

There are three modes: OFF, Once and Continuous.

OFF: No exposure control

Once: Exposure adjusts when the function is set, then remains at that setting

Continuous: Exposure continues to be adjusted automatically

In this mode, the following settings are available.

ALC Speed: Rate of adjustment speed can be set (common with Gain Auto)

Exposure Auto Max: The maximum value for the exposure time to be controlled can be set

Exposure Auto Min: The minimum value for the exposure time to be controlled can be set

ALC Reference: The reference level of the exposure control can be set (common with Gain Auto)

ALC Channel Area: The measurement area of the exposure control can be set (common with Gain Auto)

7.3 Trigger control

7.3.1 Trigger Selector

Selects the trigger operation. In the SP-5000-PMCL, only Frame Start is available.

Table - 36 Trigger selector

Trigger Selector Item	Description	
Frame Start	Frame Start	Trigger

7.3.2 Trigger Mode

Select either free-running operation or external trigger operation.

OFF: Free-running operation

ON: External trigger operation

7.3.3 TriggerSource

Select the trigger source to be used for trigger operation (Frame Start for the SP-5000-PMCL) from the following:

OFF

Line 4 (TTL IN1)

Line 7 (Camera Link CC1 IN)

Soft trigger

Pulse generator 0

Pulse generator 1

Pulse generator 2

Pulse generator 3

7.3.4 TriggerActivation

This command can select how to activate the trigger.

- | | |
|---------------|---|
| Rising edge: | At the rising edge of the pulse, the trigger is activated. |
| Falling edge: | At the falling edge of the pulse, the trigger is activated. |
| Level High: | During the high level of trigger, the accumulation is activated |
| Level Low: | During the low level of trigger, the accumulation is activated |

If Exposure Mode is set to Trigger Width, Level High or Level Low must be used.

Table - 37 Trigger Activation

	Trigger Activation Setting			
Exposure Mode	Rising Edge	Falling Edge	Level High	Level Low
Timed	○	○	×	×
Trigger width	×	×	○	○
Timed PIV	○	○	×	×
Timed RCT	○	○	×	×

7.3.5 Triggeroverlap

This function defines whether or not a trigger pulse can be accepted while data is being read out.

OFF : The trigger pulse is not accepted during CMOS readout.

Read Out : The trigger pulse can be accepted during CMOS readout.

7.4. Normal continuous operation (Timed Exposure Mode/Trigger Mode OFF)

This is used for applications which do not require triggering. In this mode, the video signal for the auto-iris lens is available.

For the video timing, refer to chapter 6.3.

Table - 38 Minimum interval (1X8-1Y)

Trigger Mode	Readout Mode	Time (Min. trigger period)
Timed Exposure Mode Trigger Mode OFF (Note 1)	Full	30.9 ms
	AOI Center 2/3	21.5 ms
	AOI Center 1/2	15.5 ms
	AOI Center 1/4	7.7 ms
	AOI Center 1/8	3.9 ms
	V Binning ON (Full) (Note2)	15.5 ms

Note 1 : Readout setting in Trigger Overlap is not available

Note 2: SP-5000M-PMCL only

7.5. Timed mode (EPS operation)

This mode captures image(s) with a preset exposure time by using the external trigger. An additional setting determines if the trigger pulse can be accepted during the exposure period.

Primary settings to use this mode

Acquisition Mode = Single frame, Multi-frame or Continuous

Trigger Mode = ON

Exposure Mode = Timed

Table - 39 Trigger minimum interval (Trigger Overlap = Readout) (1X8-1Y)

Trigger Mode	Readout Mode	Time (Min. Trigger Period)
Timed Exposure Mode Trigger Mode ON	Full	30.9 ms + 8.01 µs
	AOI Center 2/3	21.5 ms + 8.01 µs
	AOI Center 1/2	15.5 ms + 8.01 µs
	AOI Center 1/4	7.7 ms + 8.01 µs
	AOI Center 1/8	3.9 ms + 8.01 µs
	V Binning ON (Full) (Note 1)	15.5 ms + 8.01 µs

Note1 : SP-5000M-PMCL only

Note2 : If Trigger Overlap is OFF, the accumulation time is added to the above table.

7.5.1 If Overlap setting is OFF




Fig. 21 Overlap OFF

7.5.2 If Overlap setting is Readout




Fig. 22 Overlap Readout

7.6 Trigger width mode (PWC)

In this mode, the exposure time is equal to the trigger pulse width. Accordingly, longer exposure times are supported. Additional settings determine if the trigger pulse can be accepted during the exposure period.

Primary settings to use this mode

Trigger Mode = ON

Exposure Mode = Trigger Width


Table - 40 Minimum trigger interval (Trigger Overlap = Readout) (1X8-1Y)

Trigger Mode	Readout Mode	Time (Min. Trigger Period)
Trigger Width Exposure Mode	Full	30.9 ms + 8.01 µs
	AOI Center 2/3	21.5 ms + 8.01 µs
	AOI Center 1/2	15.5 ms + 8.01 µs
	AOI Center 1/4	7.7 ms + 8.01 µs
	AOI Center 1/8	3.9 ms + 8.01 µs
	V Binning ON (Full) (Note1)	15.5 ms + 8.01 µs

Note1 : SP-5000M-PMCL only

Note2 : If Trigger Overlap is OFF, the accumulation time is added to the above table.

7.6.1 If Overlap setting is OFF



t1	t2	t3
2L (Min.)	208 clocks	7L to 8L

Fig. 23 Overlap = OFF

7.6.2 If Overlap setting is Readout




Fig. 24 Overlap: Readout

7.7. RCT mode

Until the trigger is input, the camera operates continuously and the video signal for the auto-iris lens is output. At this moment, the video signal, FVAL and LVAL are output but DVAL is not output. When the trigger is input, the fast dump is activated to read out the electronic charge very quickly, after which the accumulation and the readout are performed. When the accumulated signal against the trigger is read out, FVAL, LVAL and DVAL are output too.

Primary settings to use this mode

Trigger Mode = ON

Exposure Mode = Timed

Trigger Option = RCT

Table - 41 Minimum trigger interval (1X8-1Y)

Trigger Mode	Readout Mode	Time (Min. Trigger Period)
Reset Continuous Trigger Mode (Note2)	Full	30.9 ms + Exposure time + 1.562 ms
	AOI Center 2/3	21.5 ms + Exposure time + 1.562 ms
	AOI Center 1/2	15.5 ms + Exposure time + 1.562 ms
	AOI Center 1/4	7.7 ms + Exposure time + 1.562 ms
	AOI Center 1/8	3.9 ms + Exposure time + 1.562 ms
	V Binning ON (Full) (Note1)	15.5 ms + Exposure time + 1.562 ms

Note1 : SP-5000M-PMCL only

Note2 : Trigger Overlap “Readout” is not available for this trigger mode.




Fig.25 RCT mode timing

7.8 PIV (Particle Image Velocimetry)

The Particle Image Velocimetry mode can be used in applications where 2 images need to be taken with a very short time interval. It can only be used with strobe flash as illumination. The first accumulation time is 10 µsec to 2 sec. Then, the second exposure will be taken. The first strobe is activated during the first exposure duration and the second strobe is pulsed while the first frame is being read out. In this way, two strobe flashes generate two video outputs.

Basic settings to use this mode

Trigger Mode = ON

Exposure Mode = Timed


Trigger Option = PIV

Table - 42 Minimum trigger interval (1x8-1Y)

Trigger Mode	Readout Mode	Time (Min. Trigger Period)
PIV mode (Note1)	Full	30.9 ms x 2 + Exposure time + 8.01 µs
	AOI Center 2/3	21.5 ms x 2 + Exposure time + 8.01 µs
	AOI Center 1/2	15.5 ms x 2 + Exposure time + 8.01 µs
	AOI Center 1/4	7.7 ms x 2 + Exposure time + 8.01 µs
	AOI Center 1/8	3.9 ms x 2 + Exposure time + 8.01 µs
	V Binning ON (Full) (Note2)	15.5 ms x 2 + Exposure time + 8.01 µs

Note 1. Overlap mode=Readout is not available

Note 2. SP-5000M-PMCL only



Time name	Description	Time
td	Exposure beginning delay	5270 clocks
te1	First exposure time period	10µs to 8s
te2	Second exposure time	8.1 ms
itf	Interframing time	10435 clocks
T	FVAL no active	42 LVAL
tframe1	First frame readout	1 frame
tframe2	Second frame readout	1 frame

Fig. 26 PIV mode

7.9 Sequence Mode

This is a function to capture images in sequence based on preset ROI, Exposure Time, Gain and other parameters in the sequence index table. In order activate this function:

7.9.1 Video send mode

Sequence Mode has two operating modes and it is set in the video send mode.

Video Send Mode	How to select Index
Trigger Sequence	The index can be selected by the frame start trigger signal. (Setting index is determined by the next index setting)
Command Sequence	Select the index directly by setting the index number by Command Sequence Index command.

7.9.2 Sequence mode

Basic setting to use this function

Trigger Mode: ON

Exposure mode : Timed

Trigger option : Sequence

Table - 43 Minimum trigger interval (1x8-1Y)

Trigger Mode	Readout Mode	Time (Min. Trigger Period)
PIV mode	Full	30.9ms + Exposure time + 8.01μs
	ROI Center 2/3	21.5ms + Exposure time + 8.01μs
	ROI Center 1/2	15.5ms + Exposure time + 8.01μs
	ROI Center 1/4	7.7ms + Exposure time + 8.01μs
	ROI Center 1/8	3.9ms + Exposure time + 8.01μs
	V Binning ON (Full) (Note 1)	15.5ms + Exposure time + 8.01μs

Note 1: SP-5000M-PMCL only

Note 2: The minimum trigger interval assumes that the exposure time is the same for each index in the sequence. If the exposure time is different, the difference in period should be added to the interval calculation.

Note 3: If it is necessary to use different exposure times, it is recommended to arrange the exposure times from the shortest to the longest.

Note 4: In sequence mode, the exposure should be adjusted so that the operation is not in LVAL sync accumulation.

7.9.3 Sequence mode timing

The following drawing shows the sequence mode timing concept.




Fig. 27 Behavior of Sequence trigger

In this mode, it is not possible to overlap the next exposure while the previous trigger operation (Index table) is in progress.

Sequence Index Table should proceed through Index 0 and after Index 0 is activated, the next index can be processed.

Table 44. Sequence mode: Sequence Index default value

Sequence ROI Index	Sequence ROI													
	Width	Height	Offset		Gain Selector			Exposure Time	Black Level	Binning		LUT Enable	Frame Count	Next Index
			X	Y	Gain (ALL)	Red	Blue			Horizontal	Vertical			
- Index 0	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 1	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 2	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 3	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 4	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 5	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 6	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 7	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 8	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0
- Index 9	2560	2048	0	0	100	0	0	180000	0	1 (Off)	1 (Off)	Off	1	Index 0

7.9.4 Sequence ROI setting parameters

Setting parameters for Sequence ROI are as follows.

(1) Sequence ROI Index Selector

In Sequence ROI Index Selector, Index 0 to 9 can be selected.

Sequence ROI - Width, Height, Offset X, Offset Y, Gain Selector - Gain/Red/Blue, Exposure Time, Black Level, Binning Horizontal, Binning Vertical, LUT Enable, Frame Count, Next Index for the selected index are displayed.

(2) Sequence ROI Width

Set the width of sequence ROI. The setting range is 8 to 2560 pixels.

Rules for setting area and step number are the same as the normal ROI mode set by [Video Send Mode] = “Normal”.

(3) Sequence ROI Height

Set the height of sequence ROI. The setting range is 1 to 2048 lines.

Rules for setting area and step number are the same as the normal ROI mode set by [Video Send Mode] = “Normal”.

(4) Sequence ROI Offset X

Set Offset X of sequence ROI.

Sequence ROI Binning Horizontal =1 (Off) :

Setting range is 0 to (2560 - [Sequence ROI Width])

Sequence ROI Binning Horizontal =2 (On) :

Setting range is 0 to (1280 - [Sequence ROI Width])

The limitations of step number and other factors are the same as the normal ROI mode set by [Video Send Mode] = “Normal”.

(5) Sequence ROI Offset Y

Set Offset Y of sequence ROI.

Sequence ROI Binning Vertical =1 (Off) :

Setting range is 0 to (2048 - [Sequence ROI Height])

Sequence ROI Binning Vertical =2 (On) :

Setting range is 0 to (1024 - [Sequence ROI Height])

The limitations of step number and other factors are the same as the normal ROI mode set by [Video Send Mode] =“Normal”.

(6) Sequence ROI Gain Selector

In Sequence ROI Gain Selector, the gain settings for each index are available.

SP-5000C-PMCL: Gain(ALL), Red and Blue can be set.

SP-5000M-PMCL: Only Gain is displayed and can be set.

(7) Sequence ROI Black Level

Black Level setting is available for each index.

(8) Sequence ROI Exposure Time

Exposure Time setting is available for each index.

(9) Sequence ROI Binning Horizontal

ON or OFF of Horizontal Binning for each index can be set.

(10) Sequence ROI Binning Vertical

ON or OFF of Vertical Binning for each index can be set.

(11) Sequence ROI LUT Enable

Enable or disable of LUT function for each index 0 to 9 can be set.

(12) Sequence ROI Frame Count

This can set how many times the selected index is repeated. This is applied to each index.

Triggers are input according to numbers set in Frame Count and index is repeated and moves to the next index. Therefore, the same number of triggers as Frame Count must be input.

(13) Sequence ROI Next Index

The number of the index that will follow the current index can be set.

If [Video Send Mode] is set to “Trigger Sequence” and the trigger pulse is input in EPS trigger, the sequence is executed from index 0.

(14) Sequence ROI Reset Command

This command resets the current index pointer and reverts to index 0 in the table. Frame Count is also re-initialized.




Fig. 28 Sequence trigger timing

7.10 Multi ROI function

This function divides one frame image into a maximum of 8 images vertically and reads out all areas in one frame. In this function, width is the same for all 8 images.

Multi ROI setting

Video Sending Mode: Set to Multi ROI

Table 45 Multi ROI Index table default values

Multi ROI Index Max	1		
Multi ROI Width	2560		
Multi ROI Index Selector	Multi ROI		
	Height	Offset	
- Index 1	1	X	Y
- Index 2	1	0	0
- Index 3	1	0	0
- Index 4	1	0	0
- Index 5	1	0	0
- Index 6	1	0	0
- Index 7	1	0	0
- Index 8	1	0	0

7.10.1 Multi ROI setting parameters

(1) Multi ROI Index Max : Setting value = 1 ~ 8

Maximum 8 ROI settings are possible in a frame. Set Index 1 through 8 in Multi ROI Index table as an application requires.

(2) Multi ROI Width

The setting range and Step number are the same as the normal ROI setting in which [Width] plus [Offset X] should be equal to [Width Max]. In Multi ROI operation, the maximum offset value in index 1 to index 8 is the object in this calculation.

(3) Multi ROI Index Selector :

Index 1 to 8 can be selected. [Height], [Offset X], and [Offset Y] of the selected Multi ROI Index are displayed and can be set.

(4) Multi ROI Offset X :

Offset X can be set for each ROI area of Multi ROI Index 1 to 8.

The restriction for setting Step and other factors are the same as the normal ROI setting. As described before, in Multi ROI operation, Multi ROI Width is a common width setting for Multi ROI Index 1 to 8.

(5) Multi ROI Height :

Height can be set for each ROI area of Multi ROI Index 1 to 8.

The restriction for setting Step and other factors are the same as the normal ROI setting.


(6) Multi ROI Offset Y :

Offset Y can be set for each ROI area of Multi ROI Index 1 to 8.

The restriction for setting Step and other factors is the same as the normal ROI setting. The sum of Multi ROI Height values of index 1 to 8 should be less than Height Max.

SP-5000M-PMCL / SP-5000C-PMCL

ROI setting explanation if Multi ROI Index Max is set to 4



Video output of Multi ROI




Fig. 29 Multi ROI settings and output image

7.11. Operation and function matrix

Table - 46 Operation and function matrix

Exposure operation	Trigger Mode	Trigger Option	Binning Vertical (Note1)	Binning Horizontal (Note1)	Exposure Time	AOI	Auto White Balance (Note2)	Auto Iris Output	Auto Gain	Auto Exposure	Overlap
OFF	OFF	OFF	1	1	×	○	○	○	○	×	×
			2	2	×	○	○	○	○	×	×
Timed	OFF	OFF	1	1	○	○	×	○	○	○	×
			2	2	○	○	×	○	○	○	×
Timed	ON	OFF	1	1	○	○	×	×	×	×	○
			2	2	○	○	×	×	×	×	○
Trigger Width	ON	OFF	1	1	×	○	×	×	×	×	○
			2	2	×	○	×	×	×	×	○
RCT	ON	RCT	1	1	○	○	○	○	○	○	×
			2	2	×	×	○	×	×	×	×
PIV	ON	PIV	1	1	×	○	×	×	×	×	×
			2	2	×	×	×	×	×	×	×
Sequence Trigger	ON	Sequence Trigger	1	1	○	○	×	×	×	×	×
			2	2	○	○	×	×	×	×	×

(Note1) SP-5000M-PMCL only

(Note2) SP-5000C-PMCL only

8. Other functions

8.1 Black level control

This function adjusts the setup level.

Variable range: -256 to 255 LSB (at 10-bit output)

8.1.1 Black Level Selector

The following items can be adjusted.

Monochrome: Black Level All

Color: Black Level All/ Black Level Red/ Black Level Blue

8.1.2 Black Level

The black level can be adjusted in the following range.

Monochrome: Black Level All : -256 ~+255

Color: Black Level All : -256 ~+255

Black Level Red/Blue: -512 ~+511

8.2 Gain control

In the SP-5000-PMCL, the gain control uses Analog Base Gain and Digital Gain.

Analog Base Gain can be set at 0dB, +6dB or +12dB. The digital gain is used for the master gain setting.

For setting the gain,

1. Set analog gain (Select from 0dB, +6dB and +12dB)
2. Set digital gain

The master gain (DigitalAll) for both monochrome and color can be set x1(0dB) to x16(+24dB) against the analog base gain. The resolution for gain setting is 0.01%/step which is 0.05dB to 0.08dB, depending on the setting value.

In the SP-5000C-PMCL, blue and red gain can be set from x0.45 to x5.62 against the master gain setting and its resolution is x0.01/step.

Note: If the gain up function is used, it is recommended to use the analog base gain as the master gain setting. For instance, if +12dB gain up is required, the analog base gain is set at +12dB and no digital gain is added. This is because the signal-to-noise is better on analog gain performance. However, the AGC function works only in digital gain.

Additionally, the analog base gain is effective in order to minimize the drop of the histogram at higher gain settings. Please note that the analog base gain has less accuracy due to its variability.




Fig.30 Gain control

8.2.1 Gain Selector

The following parameters can be set.

Monochrome: Digital All

Color: Digital All/Digital Red/ Digital Blue

8.2.2 Gain

The range for adjustment is as follows.

Monochrome: Digital All: 1 ~ 16 (x1 (0dB) ~x16 (+24dB))

Color: Digital All: 1 ~ 16 (x1 (0dB) ~ x16 (+24dB))

Digital Red: -0.4476 ~ 5.6235 (-7dB ~+15dB)

Digital Blue: 0.4476 ~ 5.6235 (-7dB ~+15dB)

8.2.3 Gain Raw

The range for adjustment is as follows.

Mono: Gain Raw Digital All : 100 ~ 1600 (0dB~24dB)

Color: Gain Raw Digital All : 100 ~ 1600(0dB~24dB)

Gain Raw Digital Red / Gain Raw Digital Blue : -4533~37876

8.2.4 Gain Auto

This provides automatic control of the gain level.

This is controlled by the command JAI ALC Reference.

There are three modes.

OFF: Adjust manually.

Once: Operate only one time when this command is set

Continuous: Operate the auto gain continuously

The following detailed settings are also available.

ALC Speed: The rate of adjustment of GainAuto can be set (common with Exposure Auto)

Gain Auto Max: The maximum value of GainAuto control range can be set

Gain Auto Min:	The minimum value of GainAuto control range can be set
ALC Reference:	The reference level of Gain Auto control can be set (common with Exposure Auto)
ALC channel area:	The measurement area of GainAuto control can be set, either entire area or individual section (Common with Exposure Auto)

High Left	High Mid-left	High Mid-right	High Right
Mid-High Left	Mid-High Mid-left	Mid-High Mid-right	Mid-High Right
Mid-Low Left	Mid-Low Mid-left	Mid-Low Mid-right	Mid-Low Right
Low Left	Low Mid-left	Low Mid-right	Low Right

Fig.31 ALC channel area

8.3. LUT

This function can be used to convert the input to the desired output characteristics. The Look-Up Table (LUT) has 256 points for setup. The output level can be created by multiplying the gain data by the input level.

8.3.1 LUT Enable

ON or OFF LUT function.

8.3.2 LUT Index

The number of LUT data elements is 256. The lowest level is Index 0 and the highest level is Index 255.

8.3.3 LUT Value

There are 256 LUT data elements to which a value can be assigned. The minimum LUT value is 0 and the maximum LUT value is 255.

The data between LUT data elements is calculated from adjacent data elements.

In the color camera, LUT characteristics for R, G and B are the same.

Output Data = Video IN x LUT data




Fig.32 LUT data processing method

8.4 Gamma

This command is used set gamma between gamma 0.45 and gamma 1.0 (OFF). 8 steps are provided. The gamma value is an approximate value.




Fig.33 Gamma correction

8.5 Shading Correction

This function compensates for shading (non-uniformity) caused by the lens or the light source used. This compensation can be performed even if shading issues are not symmetrical in horizontal and/or vertical directions.

There are two methods of correction.

Flat shading correction:

The method to compensate the shading is to measure the highest luminance level in the image and use that data as the reference. Luminance levels of other areas are then adjusted so that the level of the entire area is equal. The block grid for compensation is 20 (H) x 16(V) and each block contains 128 x 128 pixels. The complementary process is applied to produce the compensation data with less error.




Fig.34 Concept drawing of flat shading correction

Color shading correction (For SP-5000C-PMCL only):

In this case, R channel and B channel are adjusted to match with G channel characteristics. The block grid for compensation is 20 (H) x 16(V) and each block contains 128 x 128 pixels. The complementary process is applied to produce the compensation data with less error.




Fig. 35 Concept drawing of color shading correction

Note: Under the following conditions, the shading correction circuit may not work properly.

- If there is some area in the image with a video level less than 70%
- If part of the image or the entire image is saturated
- If the highest video level in the image is less than 300LSB (at 10-bit output)

8.6 Blemish compensation

The SP-5000-PMCL has a blemish compensation circuit. This function compensates blemishes on the CMOS sensor (typically pixels with extremely high response or extremely low response). This applies to both monochrome and color versions. Pixels that fulfill the blemish criteria can be compensated by averaging the data from pixels in both adjacent columns and, in the case of the SP-5000C-PMCL, the defective pixels can be compensated by averaging the data from the same Bayer color pixels in adjacent columns. The number of pixels that can be compensated is up to 512 pixels.




Fig. 36 Blemish compensation

If several consecutive pixels are defective in the horizontal direction, 3 pixels for monochrome and 2 same color pixels for color can be compensated.




Fig 37. Compensation of consecutive defective pixels

8.7 ALC

In the SP-5000-PMCL, auto gain, auto shutter and auto iris functions can be combined to provide a wide ranging automatic exposure control from dark to bright or vice versa. The functions are applied in the sequence shown below and if one function is disabled, the linkage between the other two is maintained.

In order to make the ALC function effective, set the Auto Iris Lens Control Signal Output to “ON”. The auto iris function works together with AGC and Exposure Auto.

If the lighting condition is changed from bright to dark AIC – ASC – AGC
 If the lighting condition is changed from dark to bright AGC – ASC – AIC




Fig.44 ALC function concept

ALC Reference will determine the target video level for AGC, Auto Shutter and/or Auto iris. For instance, if ALC Reference is set to 100% video level, AGC, Auto Shutter and/or Auto iris will function to maintain 100% video level.

8.8 HDR (High Dynamic Range) (SP-5000M-PMCL only)

HDR sensing mode can be set when HDR Mode is set to ON while Exposure Mode is Timed. The parameters to configure dynamic range are HDR_SLOPE Level 1, Level 2, Level 3 and Level 4. The user can select any one of those parameters as required for their application. In this mode, the timed exposure is used as the reference and the value selected in HDR_SLOPE will compensate to get an appropriate dynamic range by changing the exposure time.

Notes:

1. If the exposure mode is OFF and the HDR mode is set to ON, the exposure mode is automatically changed to Timed.
2. If horizontal binning and/or vertical binning are set to ON, the HDR mode cannot be set. In this case, the HDR mode must be set first before H-Binning and/or V-Binning are set.
3. In this mode, exposure overlapped behavior is not available and the frame rate is slower than

the normal operation.

4. The exposure time value is fixed at the value when HDR Mode is activated. When the exposure time is changed, HDR Mode should be off. Once the exposure time is changed, the HDR Mode can be set to ON again.
5. In this mode, Exposure Auto function is disabled.




Fig. 39 HDR characteristics

Knee Slope	Dynamic Range [%]
1	(200)
2	(400)
3	(800)
4	(1600)

8.9. Lens

The SP-5000M-PMCL and SP-5000C-PMCL can be used with 4 different types of lenses. The lens used must be selected in Lens Select.

Table -47 Lens selector

Lens Select	Description (Control with camera)	Note
P-Iris Lens	1) Iris position can be remotely controlled manually 2) Auto iris control is also available	If P-iris lens is used, the specific model name should be selected in lens select.
Motor controlled lens	1) Iris position can be remotely controlled manually 2) Auto iris control is also available	
Video iris lens	Only auto iris control is available	Option
DC iris lens	Only auto iris control is available	Option

8.9.1 About P-Iris

New Spark Series SP-5000M-PMCL and SP-5000C-PMCL come equipped with P-Iris control as part of the standard lens control function. The P-Iris system is a newly developed lens control method designed to control the iris more precisely. Especially for video cameras in surveillance applications utilizing megapixel CCD or CMOS imagers, it becomes a very important factor to control an iris in order to achieve the maximum camera performance. In surveillance applications, depending on shooting conditions, resolution and depth of field are important factors. The iris is deeply related with these factors. If the iris diaphragm is smaller, but not too small, resolution gets better and the depth of field is also deeper. The P-Iris system controls the iris diaphragm precisely and maintains the best image with the highest resolution and depth of field. P-Iris can also combine with gain and electronic shutter to keep the appropriate iris position under changing lighting conditions (ALC function).

8.9.2 Setting for P-iris lens being used

P-iris lens uses an absolute setting value control system and therefore, if the following parameters are input, precise iris position control is possible.

8.9.2.1 P-Iris lens select

Select the lens used from the P-iris select list. At this moment, there are no 1-inch P-Iris lenses available in the list.

P-Iris lens select	Description	Control step number	Open F value
TBD			

8.9.2.2 Step max.

The iris control step depends on the lens. This setting uses the value stored in the camera.

8.9.2.3 Position

The iris position can be set between 0 to Step max. 0 means to open the iris and step max is to close the iris.

In the following conditions, the camera initializes P-iris control and acquires iris position.

- 1) When the camera is powered
- 2) When a lens is selected in the P-Iris select list
- 3) If the lens selection is changed in the P-iris lens select list

8.9.2.4 Current F value

The current F value is indicated by using iris position information based on commands sent from the camera to the P-iris lens during auto-iris operation.

The relationship between iris position and F value depends on the lens used.

8.9.2.5 P-Iris Auto min. / P-Iris Auto max.

This function can set the control range when the iris is operated automatically. Auto max. sets the limit when the iris opens and Auto min. sets the limit when the iris closes. Auto max. can be set to fully open but Auto min. is stopped at F5.6 as lens performance typically begins to degrade if the iris closes past this point.

8.9.3 Motorized lens

The SP-5000M-PMCL and SP-5000C-PMCL can use a motorized lens for zoom, focus and iris. The following functions are available to control the lens via the 10-pin AUX connector.

8.9.3.1 Iris

Open: While this command is being sent, the iris continues to open.

Close: While this command is being sent, the iris continues to close.

Stop: When this command is supplied, the iris operation stops.

8.9.3.2 Zoom

Wide: While this command is being sent, the zoom continues to move towards wide angle.
Tele: While this command is being sent, the zoom continues to move towards telephoto.
Stop: When this command is supplied, the zoom operation stops.

8.9.3.3 Focus+

Near: While this command is being sent, the focus continues to move towards close range.
Far: While this command is being sent, the focus continues to move towards infinity.
Stop: When this command is supplied, the focus operation stops.

9. Camera control

In the SP-5000-PMCL, control of all camera functions is done by the JAI SDK and Control Tool software. All controllable camera functions are stored in an XML file inside of the camera. The JAI SDK and Control Tool software can be downloaded from www.jai.com.


If you need to use the Short ASCII communication protocol and associated control tool, please contact your local JAI representative.

Specific notes regarding Control Tool use:

1. For SP-5000-PMCL, the JAI SDK and Control Tool 2.0 can be used to control the camera, provided the PC on which the JAI software is installed is connected to the camera via a GenCP-compliant Camera Link frame grabber. Many frame grabber vendors also provide their own GenICam control tool software, as do a number of third-party software companies. Software conflicts can occur between these GenICam tools and the JAI SDK and Control Tool causing one or both tools to function improperly. Therefore, if you intend to use the JAI SDK and Control Tool you should A) not install any other GenICam software on your host PC, or B) install the JAI SDK and Control Tool last, after installing any other software. This will, in most cases, ensure that the JAI SDK and Control Tool functions properly. If not, please contact the frame grabber manufacturer or JAI to determine other ways to eliminate any software conflict.

2. The frame grabber used must be compliant with Camera Link Specification v1.1 or greater in order to communicate with the JAI SDK and Control Tool. If it is not, the JAI SDK and Control Tool cannot be used, and the Short ASCII communication protocol and associated control tool should be used instead.

10. External appearance and dimensions



Dimensions tolerance: $\pm 0.3\text{mm}$ Unit: mm

Fig. 40 Appearance and Dimensions

11. Specifications

11.1. Camera spectral response




Fig.41 SP-5000M-PMCL Spectral response




Fig.42 SP-5000C-PMCL Spectral response

SP-5000M-PMCL / SP-5000C-PMCL

11.2. Specification table

Table - 48 Specification table

Specifications		SP-5000M-PMCL	SP-5000C-PMCL	
Scanning system		Progressive scan		
Synchronization		Internal		
Interface	CameraLink Specifications (V.2.0 RC2), Conforming with PoCL specifications			
	Camera Link Pixel Clock: 61.7 MHz, 75.4 MHz, 82.3 MHZ selectable (Default setting: 82.3 MHz)			
Image sensor		1 inch Monochrome CMOS	1 inch Bayer color CMOS	
Aspect ratio		5:4		
Effective image size		12.8 (h) x 10.24 (v) mm	16.39 mm diagonal	
Cell size		5.0 (h) x 5.0 (v) μ m		
Active pixels		2560 (h) x 2048 (v)		
Pixel clock		48 MHz		
Acquisition Frame rate	1X2 - 1Y	30 fps (Max.) to 0.125s (Min.) 8-bit 30 fps (Max.) to 0.125s (Min.) 10-bit 30 fps (Max.) to 0.125s (Min.) 12-bit	30 fps (Max.) to 0.125s (Min.) 8-bit 30 fps (Max.) to 0.125s (Min.) 10-bit 30 fps (Max.) to 0.125s (Min.) 12-bit	
	1X4 - 1Y	61 fps (Max.) to 0.125s (Min.) 8-bit 61 fps (Max.) to 0.125s (Min.) 10-bit 61 fps (Max.) to 0.125s (Min.) 12-bit	61 fps (Max.) to 0.125s (Min.) 8-bit 61 fps (Max.) to 0.125s (Min.) 10-bit 61 fps (Max.) to 0.125s (Min.) 12-bit	
	1x8 - 1Y	120 fps (Max.) to 0.125s (Min.) 8-bit 120 fps (Max.) to 0.125s (Min.) 10-bit	120 fps (Max.) to 0.125s (Min.) 8-bit 120 fps (Max.) to 0.125s (Min.) 10-bit	
	1x10 - 1Y	134 fps (Max.) to 0.125s (Min.) 8-bit	134 fps (Max.) to 0.125s (Min.) 8-bit	
	Binning	H1/V2 268 fps (Max.) ~0.125s (Min.) 1X10-1Y	—	
		H2/V1 134 fps (Max.) ~0.125s (Min.) 1X10-1Y	—	
	H2/V2	268 fps (Max.) ~0.125s (Min.) 1X10-1Y	—	
EMVA 1288 Parameters		At 10-bit output	At 10-bit output	
Absolute sensitivity Maximum SNR		23.50 p (λ = 525 nm) 41.48 dB	36.08 p (λ = 525 nm) 38.00 dB	
SN ratio (Traditional)		55dB (Typical) (0dB gain, Black))	53dB (Typical) (0dB gain, Green Pixel Black)	
Image Output Format Digital	Full image	2560 (h) x 2048 (v)		
	Height	1 ~2048 lines, 1 line / step		
		2 ~2048 lines, 2 lines / step		
	OFFSET Y	0 ~2047 lines, 1 line / step		
	Width	1X2-1Y, 1X4-1Y, 1X8-1Y 16 ~2560 pixels, 16 pixels/step 1X10-1Y 80 ~2560 pixels, 80 pixels/step		
		1X2-1Y, 1X4-1Y, 1X8-1Y 16 ~2560 pixels, 16 pixels/step 1X10-1Y 80 ~2560 pixels, 80 pixels/step		
	OFFSET X	1X2-1Y, 1X4-1Y, 1X8-1Y 0 ~2544 pixels, 16 pixels/step 1X10-1Y 0 ~2480 pixels, 80 pixels/step		
		1X2-1Y, 1X4-1Y, 1X8-1Y 0 ~2544 pixels, 16 pixels/step 1X10-1Y 0 ~2480 pixels, 80 pixels/step		
	H Binning	2560 pixels		
	H1	2560 pixels		

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

	H2	1280 pixels The frame rate is not changed.	—
V Binning	V1	2048 lines	2048 lines
	V2	1024 lines	—
Bit assignment		8-bit, 10-bit, 12-bit	8-bit, 10-bit, 12-bit
Acquisition Mode		Continuous	
Trigger selector		Frame Start	
Trigger mode		Continuous, Timed(EPS), Trigger Width,	
Trigger option		Overlap ON/OFF, Long time exposure, PIV, Timed (RCT) with ALC Timed (RCT) with ALC continuous	
Trigger input signal		Line4 (TTL IN), Line7 (Camera link CC1), Pulse Generator 0/1/2/3, Soft Trigger, NAND0 (out), NAND1 (out) Optional: Line10 (TTL IN2), Line11 (LVDS IN)	
Exposure Mode	Timed	10 µs (Min) ~ 8 sec. (Max), Step: 1µs (Note 4)	
	Trigger Width	10 µs (Min) ~ ∞ (Max) (Note 4)	
Auto exposure		OFF / Once / Continuous	
Exposure Auto response speed		1 ~8	
Digital I/O		Line Selector (Hirose 12P): GPIO IN / GPIO OUT	
Black level adjust	Reference	33.5LSB 10-bit (Average of 100*100)	
	Adj. range	-256 ~+255LSB 10-bit	
	Resolution	1 STEP = 1LSB	
Analog Base Gain		x1(0dB), x2(+6dB), x4(+12dB)	
Gain Adjust	Manual adj. range	0dB ~+24dB, 0.01%/step	0dB ~+24dB, 0.01%/step
	WB gain	—	R / B : -7dB to +15dB, 0.01dB/ step
	WB area	—	4 x 4
	WB range	—	3000K ~ 9000K
	White balance	—	OFF, Once, continuous
Blemish comp.	Detection	Detect white blemish above the threshold value (Black blemish is detected only by factory)	
	Compensation	Complement by adjacent pixels (Continuous blemishes are not compensated)	
	Correct Numbers	Up to 512 pixels	
ALC (Note 1)		AGC, Auto Shutter, and Auto Iris can be combined and automatically controlled	
Gamma (Note1)		0.45 ~ 1.0 (8 steps are available)	
LUT(Note1)		OFF: γ=1.0, ON=256 points can be set	
Shading compensation(Note1)		Flat field Block based (20 x 16 blocks)	Flat field, Color shading Block based (20 x 16 blocks)
HDR Mode		Level 1, 2, 3 and 4 based of the exposure time setting	—
Power supply	Power input	DC+12V to +24V ± 10% (at the input terminal)	
	Current	380mA (12V input, full image)	
	Power Consumption	4.5W (12V input, full image)	
Lens mount		C mount, Rear protrusion of the lens is less than 10 mm.	
Flange back		C mount : 17.526 mm, Tolerance 0 to -0.05 mm	
Optical filter		Protection glass : Not provided	IR cut filter (Half value is 670 nm)
Operating temperature / Humidity (Performance guaranteed)		-5°C to +45°C / 20% - 80% (non-condensing)	

SP-5000M-PMCL / SP-5000C-PMCL

Operating temperature / Humidity	-45°C to +70°C / 20% - 80% (non-condensing)
Storage Temp. / Humidity	-45°C to +70°C / 20% - 80 % (non-condensing)
Regulation	CE (EN61000-6-2 and EN61000-6-3), FCC part 15 class B, RoHS, WEEE
Housing Dimensions	62 x 62 x 55.5 mm (W x H x D) (excluding protrusion)
Weight	215 g

- Note 1) These functions are effective on 12-bit output. If the output is 8-bit or 10-bit, there are some restrictions about setting range and functionalities.
- Note 2) The above specifications are based on 82.3 MHz Camera Link Pixel Clock.
- Note 2) Approximately 5 minutes pre-heating is required to achieve these specifications.
- Note 3) The above specifications are subject to change without notice.
- Note 4) Initial units may be limited to 50 us minimum exposure time. Consult JAI.

Appendix 1 Short ASCII Command Communication Protocol

This chapter described the communication control protocol based on the short ASCII command as the reference

1 Communication setting

Baud Rate	9600
Data Length	8bit
Start Bit	1bit
Stop Bit	1bit
Parity	Non
Xon/Xoff Control	Non

2 Protocol (Short ASCII Command)

2.1 Transmit the setting command to camera

NN is any kind of command.

NN=[Param.]<CR><LF>

e.g.

Send to camera: GA=0 <CR><LF>

Camera response: COMPLETE<CR><LF>

When camera receives a valid command, camera will return 'COMPLETE'.

If camera receives an improper command, camera will return one of the following:

e.g.

Send to camera: GAX=0 <CR><LF>

Camera response: 01 Unknown Command!!<CR><LF>

e.g.

Send to camera: GA=1000 <CR><LF>

Camera response: 02 Bad Parameters!!<CR><LF>

2.2 Transmit the request command to camera

The status of camera's settings can be queried by transmitting NN?<CR><LF>, where NN is any valid command.

The camera will return the current setting data.

e.g.

Send to camera: GA? <CR><LF>

Camera response: GA=0<CR><LF>

2.3 Switching baud rate between PC and camera

Camera always starts up with 9600 bps. This can be switched to higher baud rates after communication has been established. When switching to other baud rates the procedure is as follows.

e.g. Change baud rate to 115200 bps

1. Confirm baud rates camera supported

Send to camera: SBDRT? <CR><LF>

Camera response: SBDRT=31(0x1F)<CR><LF>

2. Request new baud rate

Send to camera: CBDRT=16(0x10) <CR><LF>

Camera response: COMPLETE<CR><LF>

(Change baud rate to 115200 bps)

3. Rewrite new baud rate again with new baud rate (Confirmation command)

Send to camera: CBDRT=16(0x10) <CR><LF>

Camera response: COMPLETE<CR><LF>

In case the camera does not receive the confirming command with new baud rate within 250 ms after sending the acknowledgement it falls back to the original baud rate (9600 bps).

2.4 Command list (Short ASCII command)

2.4.1 GenCP Bootstrap Register

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALUT	Description
DeviceVendorName	I String	R/O	DVN	"JAI Ltd., Japan"	—	—	—	DVN?<CR><LF>
DeviceModelName	I String	R/O	MD		—	—	—	MD?<CR><LF>
DeviceVersion	I String	R/O	DV	Indicate device version (e.g. "0.1.0.0")	—	—	—	DV?<CR><LF>
DeviceID	I String	R/O	ID	Revision+Order-Number	—	—	—	ID?<CR><LF>
DeviceUserID	I String	R/W	UD	User can save and load free text. (12 or less characters)				UD=[Param.]<CR><LF> UD?<CR><LF>

2.4.2 Technology Specific Bootstra Register

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALUT	Description
SupportedBaudrates	I Integer	R/O	SBDR T	Indicate Support/Non-support status for each baud rate bit0: 9600bps bit1: 19200bps bit2: 38400bps bit3: 57600bps bit4: 115200bps bit5: 230400bps bit6: 460800bps bit7: 921600bps	0x01	0xFF	0x1F	SBDRT?<CR><LF> This camera supports 9600bps, 19200bps, 38400bps, 57600bps, and 115200bps.
CurrentBaudrate	I Integer	R/W	CBDR T	READ: Indicate current baud rate WRITE: Set any bit of baud rate bit0: 9600bps bit1: 19200bps bit2: 38400bps bit3: 57600bps bit4: 115200bps bit5: 230400bps bit6: 460800bps bit7: 921600bps	0x01	0x80	1 (9600bps)	CBDRT=[Param.]<CR><LF> CBDRT?<CR><LF> In case of WRITE execution (change baud rate), it needs to control in the proper sequence between Host and Camera. (Refer to the section 3.3)

2.4.3 Device Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFAULT	Description
DeviceFirmwareVersion	I String	R/O	VN	Firm Ver. No.	—	—	—	VN?<CR><LF>
DeviceReset	I Command	W/O	CRS00	1	—	—	—	CRS00=1<CR><LF>

2.4.4 Image Format Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFAULT	Description
Height	I Integer	R/W	HTL	Min~(Max - OffsetY)	1(Mono) 2(Bayer)	2048	2048	HTL=[Param.]<CR><LF> HTL?<CR><LF>
Width	I Integer	R/W	WTC	Min~(Max - OffsetX)	16	2560	2560	WTC=[Param.]<CR><LF> WTC?<CR><LF>
Offset Y	I Integer	R/W	OFL	Min~(Max - Height)	0 2047 (Mono) 2046 (Bayer)	0	0	OFL=[Param.]<CR><LF> OFL?<CR><LF>
Offset X	I Integer	R/W	OFC	Min~(Max - Width)	0	2544	0	OFC=[Param.]<CR><LF> OFC?<CR><LF>
BinningHorizontal	I Integer	R/W	HB	1: Normal / 2: Binning mode	1	2	1	HB=[Param.]<CR><LF> HB?<CR><LF> only Mono
BinningVertical	I Integer	R/W	VB	1: Normal / 2: Binning mode	1	2	1	VB=[Param.]<CR><LF> VB?<CR><LF> only Mono
PixelFormat	I Enumeration	R/(W)	BA	Mono model: 0: Mono8 1: Mono10 2: Mono12 Bayer model: 0: BayerRG8 1: BayerRG10 2: BayerRG12	0	2	0	BA=[Param.]<CR><LF> BA?<CR><LF>
TestImageSelector	I Enumeration	R/W	TPN	0: Off 1: GreyHorizontalRamp 2: GreyVerticalRamp 3:GreyHorizontalRampMoving 4: Horizontal Colorbar* 5: Vertical Colorbar* 6: Moving Colorbar* (* Bayer model only)	0	6	0	TPN=[Param.]<CR><LF> TPN?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

2.4.5 Acquisition Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALULT	Description
FrameStartTrig Mode	I Enumeration	R/W	TM	Off/On	0	1	0	TM=[Param.]<CR><LF> TM?<CR><LF>
TrigSoftware	I Command	(R)/W	STRG	0	—	—	—	STRG=0<CR><LF>
FrameStartTrig Source	I Enumeration	R/W	TI	0: Low 1: High 2: SoftTrigger 8: PulseGenerator0 9: PulseGenerator1 10: PulseGenerator2 11: PulseGenerator3 12: TTL_In1 13: CL_CC1_In 14: Nand0 15: Nand1 16: TTL_In2(Option) 17: LVDS_In(Option)	0	17	0	TI=[Param.]<CR><LF> TI?<CR><LF>
FrameStartTrig Activation	I Enumeration	R/W	TA	0: RisingEdge 1: FallingEdge 2: LevelHigh 3: LevelLow	0	3	0	TA=[Param.]<CR><LF> TA?<CR><LF>
FrameStartTrig Over Lap	I Enumeration	R/W	TO	0: Off / 1: ReadOut	0	1	0	TO=[Param.]<CR><LF> TO?<CR><LF>
ExposureMode	I Enumeration	R/W	EM	0: Off 1: Timed 2: TriggerWidth	0	2	0	EM=[Param.]<CR><LF> EM?<CR><LF>
ExposureTimeRaw	I Integer	R/W	PE	Min~Max[us]	10	80000 00	18000	PE=[Param.]<CR><LF> PE?<CR><LF>
ExposureAuto	I Enumeration	R/W	ASC	0: Off 2: Once 1: Continuous	0	2	2	ASC=[Param.]<CR><LF> ASC?<CR><LF>

2.4.6 Digital I/O Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALUT	Description
LineInverter_Line1	I Boolean	R/W	L10	False/True	0	1	0	L10=[Param.]<CR><LF> L10?<CR><LF>
LineInverter_Line8	I Boolean	R/W	L11	False/True	0	1	0	L11=[Param.]<CR><LF> L11?<CR><LF>
LineInverter_Line9	I Boolean	R/W	L12	False/True	0	1	0	L12=[Param.]<CR><LF> L12?<CR><LF>
LineInverter_Nand0In1	I Boolean	R/W	ND0IN V1	False/True	0	1	0	ND0INV1=[Param.]<CR><LF> ND0INV1?<CR><LF>
LineInverter_Nand0In2	I Boolean	R/W	ND0IN V2	False/True	0	1	0	ND0INV2=[Param.]<CR><LF> ND0INV2?<CR><LF>
LineInverter_Nand1In1	I Boolean	R/W	ND1IN V1	False/True	0	1	0	ND1INV1=[Param.]<CR><LF> ND1INV1?<CR><LF>
LineInverter_Nand1In2	I Boolean	R/W	ND1IN V2	False/True	0	1	0	ND1INV2=[Param.]<CR><LF> ND1INV2?<CR><LF>
LineSource_Line1	I Enumeration	R/W	LS0	0: Low 1: High 3: Frame TriggerWait 4: Frame Active 5: Exposure Active 6: Fval 7: Lval 8: Pulse Generator0 9: Pulse Generator1 10: Pulse Generator2 11: Pulse Generator3 12: TTL_In 13: CL_CC1_In 14: Nand0 15: Nand1 16: TTL_In2 (Option) 17: LVDS_In (Option)	0	17	0	LS0=[Param.]<CR><LF> LS0?<CR><LF> For 12pin TTL out
LineSource_Line8	I Enumeration	R/W	LS1	Same as for Line1	0	17	0	LS1=[Param.]<CR><LF> LS1?<CR><LF> For Option TTL out
LineSource_Line9	I Enumeration	R/W	LS2	Same as for Line1	0	17	0	LS2=[Param.]<CR><LF> LS2?<CR><LF> For Option TTL out
LineSource_Nand0In1	I Enumeration	R/W	ND0IN1	Same as for Line1	0	17	0	ND0IN1=[Param.]<CR><LF> ND0IN1?<CR><LF>
LineSource_Nand0In2	I Enumeration	R/W	ND0IN2	Same as for Line1	0	17	0	ND0IN2=[Param.]<CR><LF> ND0IN2?<CR><LF>
LineSource_Nand1In1	I Enumeration	R/W	ND1IN1	Same as for Line1	0	17	0	ND1IN1=[Param.]<CR><LF> ND1IN1?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

LineSource_Nand1In2	I Enumeration	R/W	ND1IN2	Same as for Line1	0	17	0	ND1IN2=[Param.]<CR><LF> ND1IN2?<CR><LF>
---------------------	------------------	-----	--------	-------------------	---	----	---	--

2.4.7 Analogue Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALUT	Description
GainRawDigital All	I Integer	R/W	FGA	min~0~max	100	1600	100	FGA=[Param.]<CR><LF> FGA?<CR><LF>
GainRawDigital RedAll	I Integer	R/W	PGR	min~0~max	-4533	28400	0	PGR=[Param.]<CR><LF> PGR?<CR><LF> (Bayer model only)
GainRawDigital BlueAll	I Integer	R/W	PGB	min~0~max	-4533	28400	0	PGB=[Param.]<CR><LF> PGB?<CR><LF> (Bayer model only)
GainAuto	I Enumeration	R/W	AGC	0: Off 1: Continuous 2: Once	0	2	0	AGC=[Param.]<CR><LF> AGC?<CR><LF>
BlackLevelRaw All	I Integer	R/W	BL	min~0~max	-256	255	0	BL=[Param.]<CR><LF> BL?<CR><LF>
BlackLevelRaw Red	I Integer	R/W	BLR	min~0~max	-512	511	0	BLR1=[Param.]<CR><LF> BLR1?<CR><LF> (Bayer model only)
BlackLevelRaw Blue	I Integer	R/W	BLB	min~0~max	-512	511	0	BLB1=[Param.]<CR><LF> BLB1?<CR><LF> (Bayer model only)
BalanceWhiteAuto	I Enumeration	R/W	AWB	0: Off 1: Once 2: Continuous	0	2	0	AWB=[Param.]<CR><LF> AWB?<CR><LF> (Bayer model only)

2.4.8 LUT Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALUT	Description
LUTValueRed	I Integer	R/W	LUTR	Param 1: LUT index Param 2:LUTdata (Min~Max) (Bayer model only)	0	4095	γ 09 相当值	LUT*=[Param1],[Param2]<CR><LF> LUT*?[Param1]<CR><LF>
LUTValueGreen (Mono)	I Integer	R/W	LUTG	Param 1: LUT index Param 2:LUTdata (Min~Max)	0	4095		
LUTValueBlue	I Integer	R/W	LUTB	Param 1: LUT index Param 2:LUTdata (Min~Max) (Bayer model only)	0	4095		

2.4.9 Transport Layer Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DEFALU LT	Description
DeviceTapGeometry	I Enumeration	R/(W)	TAGM	1: Geometry_1X2_1Y 3: Geometry_1X4_1Y 5: Geometry_1X8_1Y 6: Geometry_1X10_1Y	1	6	5	TAGM=[Param.]<CR><LF> TAGM?<CR><LF>

2.4.10 User Set Control

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DE FAULT	Description
UserSetLoad	I Command	(R)/W	LD	0: Default 1: UserSet1 2: UserSet2 3: UserSet3	0	3	0	LD=[Param.]<CR><LF> LD?<CR><LF>
UserSetSave	I Command	(R)/W	SA	1: UserSet1 2: UserSet2 3: UserSet3	1	3	1	SA=[Param.]<CR><LF> SA?<CR><LF>

2.4.11 JAI-Custom

Name	Interface	Access	Short ASCII	Values	MIN	MAX	DE FAUL T	Description
BlemishWhiteEnable	I Boolean	R/W	BMW	0: False 1: True	0	1	0	BMW=[Param.]<CR><LF> BMW?<CR><LF>
BlemishWhiteDetect	I Command	W/O	BMRCW	0	0	0	0	BMRCW=0<CR><LF>
BlemishWhiteDetect Threshold	I Integer	R/W	BMTHW	0	0	100	10	BMTHW=[Param.]<CR><LF> BMTHW?<CR><LF>
BlemishWhiteDetect PositionX	I Integer	R/W	BMPXW	Param 1: Blemish index Param 2: X position(Min~Max)	0	2559	0	BMPXW=[Param1],[Param2]<CR><LF> BMPXW? [Param1]<CR><LF>
BlemishWhiteDetect PositionY	I Integer	R/W	BMPYW	Param 1: Blemish index Param 2: Y position(Min~Max)	0	2047	0	BMPYW=[Param1],[Param2]<CR><LF> BMPYW? [Param1]<CR><LF>
ShadingCorrection Mode	I Enumeration	R/W	SDCM	0: Flat Shading 1: Color Shading* (*Bayer model only)	0	1	0	SDCM=[Param.]<CR><LF> SDCM?<CR><LF>
ShadingCorrect	I Command	W/O	RS		0	0	0	BMRCW=0<CR><LF>
RequestShading DetectResult	I Enumeration	R/O	SDRS	0=Complete. 1=Too Bright. 2=Too dark. 3=Timeout Error.	0	6	0	SDRS?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

				4=Busy. 5=Limit. 6= Trig is not set as Normal.				
ShadingMode	I Enumeration	R/W	SDM	0: OFF 1: User 1 2: User 2 3: User 3	0	3	0	SDM=[Param.]<CR><LF> SDM?<CR><LF>
VideoSendMode	I Enumeration	R/W	VSM	0: Normal 1: Trigger Sequence 2: Command Sequence 3: Multi Roi Mode	0	3	0	VSM=[Param.]<CR><LF> VSM?<CR><LF>
SequenceModelIndex	I Enumeration	R/W	SQI	0: Index0 1: Index1 2: Index2 3: Index3 4: Index4 5: Index5 6: Index6 7: Index7 8: Index8 9: Index9	0	9	0	SQI=[Param.]<CR><LF> SQI?<CR><LF>
SequenceModeFrameCount0	I Integer	R/W	SQF1	Min~Max	1	255	1	SQF1=[Param.]<CR><LF> SQF1?<CR><LF>
SequenceModeFrameCount1	I Integer	R/W	SQF2	Min~Max	1	255	1	SQF2=[Param.]<CR><LF> SQF2?<CR><LF>
SequenceModeFrameCount2	I Integer	R/W	SQF3	Min~Max	1	255	1	SQF3=[Param.]<CR><LF> SQF3?<CR><LF>
SequenceModeFrameCount3	I Integer	R/W	SQF4	Min~Max	1	255	1	SQF4=[Param.]<CR><LF> SQF4?<CR><LF>
SequenceModeFrameCount4	I Integer	R/W	SQF5	Min~Max	1	255	1	SQF5=[Param.]<CR><LF> SQF5?<CR><LF>
SequenceModeFrameCount5	I Integer	R/W	SQF6	Min~Max	1	255	1	SQF6=[Param.]<CR><LF> SQF6?<CR><LF>
SequenceModeFrameCount6	I Integer	R/W	SQF7	Min~Max	1	255	1	SQF7=[Param.]<CR><LF> SQF7?<CR><LF>
SequenceModeFrameCount7	I Integer	R/W	SQF8	Min~Max	1	255	1	SQF8=[Param.]<CR><LF> SQF8?<CR><LF>
SequenceModeFrameCount8	I Integer	R/W	SQF9	Min~Max	1	255	1	SQF9=[Param.]<CR><LF> SQF9?<CR><LF>
SequenceModeFrameCount9	I Integer	R/W	SQF10	Min~Max	1	255	1	SQF10=[Param.]<CR><LF> SQF10?<CR><LF>
SequenceModeNextIndex0	I Enumeration	R/W	SQNI1	Same SequenceRoiIndex as	0	9	0	SQNI1=[Param.]<CR><LF> SQNI1?<CR><LF>
SequenceModeNextIndex1	I Enumeration	R/W	SQNI2	Same SequenceRoiIndex as	0	9	0	SQNI2=[Param.]<CR><LF> SQNI2?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

SequenceModeN ext Index2	I Enumera tion	R/W	SQNI3	Same SequenceRoIndex as	0	9	0	SQNI3=[Param.]<CR>< LF> SQNI3?<CR><LF>
SequenceModeN ext Index3	I Enumera tion	R/W	SQNI4	Same SequenceRoIndex as	0	9	0	SQNI4=[Param.]<CR>< LF> SQNI4?<CR><LF>
SequenceModeN ext Index4	I Enumera tion	R/W	SQNI5	Same SequenceRoIndex as	0	9	0	SQNI5=[Param.]<CR>< LF> SQNI5?<CR><LF>
SequenceModeN ext Index5	I Enumera tion	R/W	SQNI6	Same SequenceRoIndex as	0	9	0	SQNI6=[Param.]<CR>< LF> SQNI6?<CR><LF>
SequenceModeN ext Index6	I Enumera tion	R/W	SQNI7	Same SequenceRoIndex as	0	9	0	SQNI7=[Param.]<CR>< LF> SQNI7?<CR><LF>
SequenceModeN ext Index7	I Enumera tion	R/W	SQNI8	Same SequenceRoIndex as	0	9	0	SQNI8=[Param.]<CR>< LF> SQNI8?<CR><LF>
SequenceModeN ext Index8	I Enumera tion	R/W	SQNI9	Same SequenceRoIndex as	0	9	0	SQNI9=[Param.]<CR>< LF> SQNI9?<CR><LF>
SequenceModeN ext Index9	I Enumera tion	R/W	SQNI10	Same SequenceRoIndex as	0	9	0	SQNI10=[Param.]<CR>< LF> SQNI10?<CR><LF>
SequenceMode Height0	I Integer	R/W	SQH1	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH1=[Param.]<CR><L F> SQH1?<CR><LF>
SequenceMode Height1	I Integer	R/W	SQH2	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH2=[Param.]<CR><L F> SQH2?<CR><LF>
SequenceMode Height2	I Integer	R/W	SQH3	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH3=[Param.]<CR><L F> SQH3?<CR><LF>
SequenceMode Height3	I Integer	R/W	SQH4	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH4=[Param.]<CR><L F> SQH4?<CR><LF>
SequenceMode Height4	I Integer	R/W	SQH5	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH5=[Param.]<CR><L F> SQH5?<CR><LF>
SequenceMode Height5	I Integer	R/W	SQH6	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH6=[Param.]<CR><L F> SQH6?<CR><LF>
SequenceMode Height6	I Integer	R/W	SQH7	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH7=[Param.]<CR><L F> SQH7?<CR><LF>
SequenceMode Height7	I Integer	R/W	SQH8	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH8=[Param.]<CR><L F> SQH8?<CR><LF>
SequenceMode Height8	I Integer	R/W	SQH9	Min~Max	1(Mon o) 2(Bay er)	2048	2048	SQH9=[Param.]<CR><L F> SQH9?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

SequenceMode Height9	I Integer	R/W	SQH10	Min~Max	1(Mono) 2(Bayer)	2048	2048	SQH10=[Param.]<CR><LF> SQH10?<CR><LF>
SequenceMode OffsetY0	I Integer	R/W	SQOY1	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY1=[Param.]<CR><LF> SQOY1?<CR><LF>
SequenceMode OffsetY1	I Integer	R/W	SQOY2	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY2=[Param.]<CR><LF> SQOY2?<CR><LF>
SequenceMode OffsetY2	I Integer	R/W	SQOY3	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY3=[Param.]<CR><LF> SQOY3?<CR><LF>
SequenceMode OffsetY3	I Integer	R/W	SQOY4	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY4=[Param.]<CR><LF> SQOY4?<CR><LF>
SequenceMode OffsetY4	I Integer	R/W	SQOY5	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY5=[Param.]<CR><LF> SQOY5?<CR><LF>
SequenceMode OffsetY5	I Integer	R/W	SQOY6	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY6=[Param.]<CR><LF> SQOY6?<CR><LF>
SequenceMode OffsetY6	I Integer	R/W	SQOY7	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY7=[Param.]<CR><LF> SQOY7?<CR><LF>
SequenceMode OffsetY7	I Integer	R/W	SQOY8	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY8=[Param.]<CR><LF> SQOY8?<CR><LF>
SequenceMode OffsetY8	I Integer	R/W	SQOY9	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY9=[Param.]<CR><LF> SQOY9?<CR><LF>
SequenceMode OffsetY9	I Integer	R/W	SQOY10	Min~Max	0	2047 (Mno) 2046 (Bayer)	0	SQOY10=[Param.]<CR><LF> SQOY10?<CR><LF>
SequenceMode Gain0	I Integer	R/W	SQGA1	Min~Max	100	1600	0	SQGA1=[Param.]<CR><LF> SQGA1?<CR><LF>
SequenceMode Gain1	I Integer	R/W	SQGA2	Min~Max	100	1600	0	SQGA2=[Param.]<CR><LF> SQGA2?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

SequenceMode Gain2	I Integer	R/W	SQGA3	Min~Max	100	1600	0	SQGA3=[Param.]<CR><LF> SQGA3?<CR><LF>
SequenceMode Gain3	I Integer	R/W	SQGA4	Min~Max	100	1600	0	SQGA4=[Param.]<CR><LF> SQGA4?<CR><LF>
SequenceMode Gain4	I Integer	R/W	SQGA5	Min~Max	100	1600	0	SQGA5=[Param.]<CR><LF> SQGA5?<CR><LF>
SequenceMode Gain5	I Integer	R/W	SQGA6	Min~Max	100	1600	0	SQGA6=[Param.]<CR><LF> SQGA6?<CR><LF>
SequenceMode Gain6	I Integer	R/W	SQGA7	Min~Max	100	1600	0	SQGA7=[Param.]<CR><LF> SQGA7?<CR><LF>
SequenceMode Gain7	I Integer	R/W	SQGA8	Min~Max	100	1600	0	SQGA8=[Param.]<CR><LF> SQGA8?<CR><LF>
SequenceMode Gain8	I Integer	R/W	SQGA9	Min~Max	100	1600	0	SQGA9=[Param.]<CR><LF> SQGA9?<CR><LF>
SequenceMode Gain9	I Integer	R/W	SQGA10	Min~Max	100	1600	0	SQGA10=[Param.]<CR><LF> SQGA10?<CR><LF>
SequenceMode ExposureTime0	I Integer	R/W	SQPE1	Min~Max	10	8000000	18000	SQPE1=[Param.]<CR><LF> SQPE1?<CR><LF>
SequenceMode ExposureTime1	I Integer	R/W	SQPE2	Min~Max	10	8000000	18000	SQPE2=[Param.]<CR><LF> SQPE2?<CR><LF>
SequenceMode ExposureTime2	I Integer	R/W	SQPE3	Min~Max	10	8000000	18000	SQPE3=[Param.]<CR><LF> SQPE3?<CR><LF>
SequenceMode ExposureTime3	I Integer	R/W	SQPE4	Min~Max	10	8000000	18000	SQPE4=[Param.]<CR><LF> SQPE4?<CR><LF>
SequenceMode ExposureTime4	I Integer	R/W	SQPE5	Min~Max	10	8000000	18000	SQPE5=[Param.]<CR><LF> SQPE5?<CR><LF>
SequenceMode ExposureTime5	I Integer	R/W	SQPE6	Min~Max	10	8000000	18000	SQPE6=[Param.]<CR><LF> SQPE6?<CR><LF>
SequenceMode ExposureTime6	I Integer	R/W	SQPE7	Min~Max	10	8000000	18000	SQPE7=[Param.]<CR><LF> SQPE7?<CR><LF>
SequenceMode ExposureTime7	I Integer	R/W	SQPE8	Min~Max	10	8000000	18000	SQPE8=[Param.]<CR><LF> SQPE8?<CR><LF>
SequenceMode ExposureTime8	I Integer	R/W	SQPE9	Min~Max	10	8000000	18000	SQPE9=[Param.]<CR><LF> SQPE9?<CR><LF>
SequenceMode ExposureTime9	I Integer	R/W	SQPE10	Min~Max	10	8000000	18000	SQPE10=[Param.]<CR><LF> SQPE10?<CR><LF>
SequenceMode Hbinning0	I Enumeration	R/W	SQHB1	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB1=[Param.]<CR><LF> SQHB1?<CR><LF> (Mono model only)

SP-5000M-PMCL / SP-5000C-PMCL

SequenceMode Hbinning1	I Enumeration	R/W	SQHB2	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB2=[Param.]<CR><LF> SQHB2?<CR><LF> (Mono model only)
SequenceMode Hbinning2	I Enumeration	R/W	SQHB3	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB3=[Param.]<CR><LF> SQHB3?<CR><LF> (Mono model only)
SequenceMode Hbinning3	I Enumeration	R/W	SQHB4	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB4=[Param.]<CR><LF> SQHB4?<CR><LF> (Mono model only)
SequenceMode Hbinning4	I Enumeration	R/W	SQHB5	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB5=[Param.]<CR><LF> SQHB5?<CR><LF> (Mono model only)
SequenceMode Hbinning5	I Enumeration	R/W	SQHB6	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB6=[Param.]<CR><LF> SQHB6?<CR><LF> (Mono model only)
SequenceMode Hbinning6	I Enumeration	R/W	SQHB7	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB7=[Param.]<CR><LF> SQHB7?<CR><LF> (Mono model only)
SequenceMode Hbinning7	I Enumeration	R/W	SQHB8	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB8=[Param.]<CR><LF> SQHB8?<CR><LF> (Mono model only)
SequenceMode Hbinning8	I Enumeration	R/W	SQHB9	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB9=[Param.]<CR><LF> SQHB9?<CR><LF> (Mono model only)
SequenceMode Hbinning9	I Enumeration	R/W	SQHB10	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQHB10=[Param.]<CR><LF> SQHB10?<CR><LF> (Mono model only)
SequenceMode Vbinning0	I Enumeration	R/W	SQVB1	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB1=[Param.]<CR><LF> SQVB1?<CR><LF> (Mono model only)
SequenceMode Vbinning1	I Enumeration	R/W	SQVB2	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB2=[Param.]<CR><LF> SQVB2?<CR><LF> (Mono model only)
SequenceMode Vbinning2	I Enumeration	R/W	SQVB3	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB3=[Param.]<CR><LF> SQVB3?<CR><LF> (Mono model only)
SequenceMode Vbinning3	I Enumeration	R/W	SQVB4	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB4=[Param.]<CR><LF> SQVB4?<CR><LF> (Mono model only)
SequenceMode Vbinning4	I Enumeration	R/W	SQVB5	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB5=[Param.]<CR><LF> SQVB5?<CR><LF> (Mono model only)
SequenceMode Vbinning5	I Enumeration	R/W	SQVB6	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB6=[Param.]<CR><LF> SQVB6?<CR><LF> (Mono model only)

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

SequenceMode Vbinning6	I Enumeration	R/W	SQVB7	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB7=[Param.]<CR><LF> SQVB7?<CR><LF> (Mono model only)
SequenceMode Vbinning7	I Enumeration	R/W	SQVB8	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB8=[Param.]<CR><LF> SQVB8?<CR><LF> (Mono model only)
SequenceMode Vbinning8	I Enumeration	R/W	SQVB9	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB9=[Param.]<CR><LF> SQVB9?<CR><LF> (Mono model only)
SequenceMode Vbinning9	I Enumeration	R/W	SQVB10	1: Hbinning = OFF 2: Hbinning = ON	1	2	1	SQVB10=[Param.]<CR><LF> SQVB10?<CR><LF> (Mono model only)
SequenceMode LutEnable0	I Enumeration	R/W	SQLUT1	Off/On	0	1	0	SQLUT1=[Param.]<CR><LF> SQLUT1?<CR><LF>
SequenceMode LutEnable1	I Enumeration	R/W	SQLUT2	Off/On	0	1	0	SQLUT2=[Param.]<CR><LF> SQLUT2?<CR><LF>
SequenceMode LutEnable2	I Enumeration	R/W	SQLUT3	Off/On	0	1	0	SQLUT3=[Param.]<CR><LF> SQLUT3?<CR><LF>
SequenceMode LutEnable3	I Enumeration	R/W	SQLUT4	Off/On	0	1	0	SQLUT4=[Param.]<CR><LF> SQLUT4?<CR><LF>
SequenceMode LutEnable4	I Enumeration	R/W	SQLUT5	Off/On	0	1	0	SQLUT5=[Param.]<CR><LF> SQLUT5?<CR><LF>
SequenceMode LutEnable5	I Enumeration	R/W	SQLUT6	Off/On	0	1	0	SQLUT6=[Param.]<CR><LF> SQLUT6?<CR><LF>
SequenceMode LutEnable6	I Enumeration	R/W	SQLUT7	Off/On	0	1	0	SQLUT7=[Param.]<CR><LF> SQLUT7?<CR><LF>
SequenceMode LutEnable7	I Enumeration	R/W	SQLUT8	Off/On	0	1	0	SQLUT8=[Param.]<CR><LF> SQLUT8?<CR><LF>
SequenceMode LutEnable8	I Enumeration	R/W	SQLUT9	Off/On	0	1	0	SQLUT9=[Param.]<CR><LF> SQLUT9?<CR><LF>
SequenceMode LutEnable9	I Enumeration	R/W	SQLUT10	Off/On	0	1	0	SQLUT10=[Param.]<CR><LF> SQLUT10?<CR><LF>
SequenceMode BlackLevel0	I Integer	R/W	SQBL1	Min~Max	-256	255	0	SQBL1=[Param.]<CR><LF> SQBL1?<CR><LF>
SequenceMode BlackLevel1	I Integer	R/W	SQBL2	Min~Max	-256	255	0	SQBL2=[Param.]<CR><LF> SQBL2?<CR><LF>
SequenceMode BlackLevel2	I Integer	R/W	SQBL3	Min~Max	-256	255	0	SQBL3=[Param.]<CR><LF> SQBL3?<CR><LF>
SequenceMode BlackLevel3	I Integer	R/W	SQBL4	Min~Max	-256	255	0	SQBL4=[Param.]<CR><LF> SQBL4?<CR><LF>
SequenceMode BlackLevel4	I Integer	R/W	SQBL5	Min~Max	-256	255	0	SQBL5=[Param.]<CR><LF> SQBL5?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

SequenceMode BlackLevel5	I Integer	R/W	SQBL6	Min~Max	-256	255	0	SQBL6=[Param.]<CR><LF> SQBL6?<CR><LF>
SequenceMode BlackLevel6	I Integer	R/W	SQBL7	Min~Max	-256	255	0	SQBL7=[Param.]<CR><LF> SQBL7?<CR><LF>
SequenceMode BlackLevel7	I Integer	R/W	SQBL8	Min~Max	-256	255	0	SQBL8=[Param.]<CR><LF> SQBL8?<CR><LF>
SequenceMode BlackLevel8	I Integer	R/W	SQBL9	Min~Max	-256	255	0	SQBL9=[Param.]<CR><LF> SQBL9?<CR><LF>
SequenceMode BlackLevel9	I Integer	R/W	SQBL10	Min~Max	-256	255	0	SQBL10=[Param.]<CR><LF> SQBL10?<CR><LF>
SequenceMode GainRed0	I Integer	R/W	SQPGR1	Min~Max	-4533	17713	0	SQPGR1=[Param.]<CR><LF> SQPGR1?<CR><LF> (Bayer model only)
SequenceMode GainRed1	I Integer	R/W	SQPGR2	Min~Max	-4533	17713	0	SQPGR2=[Param.]<CR><LF> SQPGR2?<CR><LF> (Bayer model only)
SequenceMode GainRed2	I Integer	R/W	SQPGR3	Min~Max	-4533	17713	0	SQPGR3=[Param.]<CR><LF> SQPGR3?<CR><LF> (Bayer model only)
SequenceMode GainRed3	I Integer	R/W	SQPGR4	Min~Max	-4533	17713	0	SQPGR4=[Param.]<CR><LF> SQPGR4?<CR><LF> (Bayer model only)
SequenceMode GainRed4	I Integer	R/W	SQPGR5	Min~Max	-4533	17713	0	SQPGR5=[Param.]<CR><LF> SQPGR5?<CR><LF> (Bayer model only)
SequenceMode GainRed5	I Integer	R/W	SQPGR6	Min~Max	-4533	17713	0	SQPGR6=[Param.]<CR><LF> SQPGR6?<CR><LF> (Bayer model only)
SequenceMode GainRed6	I Integer	R/W	SQPGR7	Min~Max	-4533	17713	0	SQPGR7=[Param.]<CR><LF> SQPGR7?<CR><LF> (Bayer model only)
SequenceMode GainRed7	I Integer	R/W	SQPGR8	Min~Max	-4533	17713	0	SQPGR8=[Param.]<CR><LF> SQPGR8?<CR><LF> (Bayer model only)
SequenceMode GainRed8	I Integer	R/W	SQPGR9	Min~Max	-4533	17713	0	SQPGR9=[Param.]<CR><LF> SQPGR9?<CR><LF> (Bayer model only)
SequenceMode GainRed9	I Integer	R/W	SQPGR10	Min~Max	-4533	17713	0	SQPGR10=[Param.]<CR><LF> SQPGR10?<CR><LF> (Bayer model only)
SequenceMode GainBlue0	I Integer	R/W	SQPGB1	Min~Max	-4533	17713	0	SQPGB1=[Param.]<CR><LF> SQPGB1?<CR><LF> (Bayer model only)

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

SequenceMode GainBlue1	I Integer	R/W	SQPGB 2	Min~Max	-4533	17713	0	SQPGB2=[Param.]<CR><LF> SQPGB2?<CR><LF> (Bayer model only)
SequenceMode GainBlue2	I Integer	R/W	SQPGB 3	Min~Max	-4533	17713	0	SQPGB3=[Param.]<CR><LF> SQPGB3?<CR><LF> (Bayer model only)
SequenceMode GainBlue3	I Integer	R/W	SQPGB 4	Min~Max	-4533	17713	0	SQPGB4=[Param.]<CR><LF> SQPGB4?<CR><LF> (Bayer model only)
SequenceMode GainBlue4	I Integer	R/W	SQPGB 5	Min~Max	-4533	17713	0	SQPGB5=[Param.]<CR><LF> SQPGB5?<CR><LF> (Bayer model only)
SequenceMode GainBlue5	I Integer	R/W	SQPGB 6	Min~Max	-4533	17713	0	SQPGB6=[Param.]<CR><LF> SQPGB6?<CR><LF> (Bayer model only)
SequenceMode GainBlue6	I Integer	R/W	SQPGB 7	Min~Max	-4533	17713	0	SQPGB7=[Param.]<CR><LF> SQPGB7?<CR><LF> (Bayer model only)
SequenceMode GainBlue7	I Integer	R/W	SQPGB 8	Min~Max	-4533	17713	0	SQPGB8=[Param.]<CR><LF> SQPGB8?<CR><LF> (Bayer model only)
SequenceMode GainBlue8	I Integer	R/W	SQPGB 9	Min~Max	-4533	17713	0	SQPGB9=[Param.]<CR><LF> SQPGB9?<CR><LF> (Bayer model only)
SequenceMode GainBlue9	I Integer	R/W	SQPGB 10	Min~Max	-4533	17713	0	SQPGB10=[Param.]<CR><LF> SQPGB10?<CR><LF> (Bayer model only)
CommnadSeque nce Index	I Enumera tion	R/W	SQI	Same as SequenceModelIndex	0	9	0	CSQI=[Param.]<CR><L F> CSQI?<CR><LF>
CurrentSequenc e Index	I Enumera tion	R/O	SQIDX	Same as SequenceModelIndex	0	9	0	SQIDX?<CR><LF>
SequenceReset	I Enumera tion	W/O	SQRST	0	0	0	0	SQRST=[Param.]<CR>< LF>
SequenceLutMo de	I Enumera tion	R/W	SQLUT	0: Gamma 1: LUT	0	1	0	SQLUT=[Param.]<CR>< LF> SQLUT?<CR><LF>
MultiRoiIndexM ax	I Integer	R/W	MRIM	Min~Max	1	8	1	MRIM=[Param.]<CR><L F> MRIM?<CR><LF>
MultiRoiWidth	I Integer	R/W	MRW	Min~Max	8	5120	8	MRW=[Param.]<CR><L F> MRW?<CR><LF>
MultiRoiHeight1	I Integer	R/W	MRH1	Min~Max	0	3840	1	MRH1=[Param.]<CR>< LF> MRH1?<CR><LF>
MultiRoiHeight2	I Integer	R/W	MRH2	Min~Max	0	3840	1	MRH2=[Param.]<CR>< LF> MRH2?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

MultiRoiHeight3	I Integer	R/W	MRH3	Min~Max	0	3840	1	MRH3=[Param.]<CR><LF> MRH3?<CR><LF>
MultiRoiHeight4	I Integer	R/W	MRH4	Min~Max	0	3840	1	MRH4=[Param.]<CR><LF> MRH4?<CR><LF>
MultiRoiHeight5	I Integer	R/W	MRH5	Min~Max	0	3840	1	MRH5=[Param.]<CR><LF> MRH5?<CR><LF>
MultiRoiHeight6	I Integer	R/W	MRH6	Min~Max	0	3840	1	MRH6=[Param.]<CR><LF> MRH6?<CR><LF>
MultiRoiHeight7	I Integer	R/W	MRH7	Min~Max	0	3840	1	MRH7=[Param.]<CR><LF> MRH7?<CR><LF>
MultiRoiHeight8	I Integer	R/W	MRH8	Min~Max	0	3840	1	MRH8=[Param.]<CR><LF> MRH8?<CR><LF>
MultiRoiOffsetX1	I Integer	R/W	MROX1	Min~Max	0	5118	0	MROX1=[Param.]<CR><LF> MROX1?<CR><LF>
MultiRoiOffsetX2	I Integer	R/W	MROX2	Min~Max	0	5118	0	MROX2=[Param.]<CR><LF> MROX2?<CR><LF>
MultiRoiOffsetX3	I Integer	R/W	MROX3	Min~Max	0	5118	0	MROX3=[Param.]<CR><LF> MROX3?<CR><LF>
MultiRoiOffsetX4	I Integer	R/W	MROX4	Min~Max	0	5118	0	MROX4=[Param.]<CR><LF> MROX4?<CR><LF>
MultiRoiOffsetX5	I Integer	R/W	MROX5	Min~Max	0	5118	0	MROX5=[Param.]<CR><LF> MROX5?<CR><LF>
MultiRoiOffsetX6	I Integer	R/W	MROX6	Min~Max	0	5118	0	MROX6=[Param.]<CR><LF> MROX6?<CR><LF>
MultiRoiOffsetX7	I Integer	R/W	MROX7	Min~Max	0	5118	0	MROX7=[Param.]<CR><LF> MROX7?<CR><LF>
MultiRoiOffsetX8	I Integer	R/W	MROX8	Min~Max	0	5118	0	MROX8=[Param.]<CR><LF> MROX8?<CR><LF>
MultiRoiOffsetY1	I Integer	R/W	MROY1	Min~Max	0	3839	0	MROY1=[Param.]<CR><LF> MROY1?<CR><LF>
MultiRoiOffsetY2	I Integer	R/W	MROY2	Min~Max	0	3839	0	MROY2=[Param.]<CR><LF> MROY2?<CR><LF>
MultiRoiOffsetY3	I Integer	R/W	MROY3	Min~Max	0	3839	0	MROY3=[Param.]<CR><LF> MROY3?<CR><LF>
MultiRoiOffsetY4	I Integer	R/W	MROY4	Min~Max	0	3839	0	MROY4=[Param.]<CR><LF> MROY4?<CR><LF>
MultiRoiOffsetY5	I Integer	R/W	MROY5	Min~Max	0	3839	0	MROY5=[Param.]<CR><LF> MROY5?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

MultiRoiOffsetY6	I Integer	R/W	MROY6	Min~Max	0	3839	0	MROY6=[Param.]<CR><LF> MROY6?<CR><LF>
MultiRoiOffsetY7	I Integer	R/W	MROY7	Min~Max	0	3839	0	MROY7=[Param.]<CR><LF> MROY7?<CR><LF>
MultiRoiOffsetY8	I Integer	R/W	MROY8	Min~Max	0	3839	0	MROY8=[Param.]<CR><LF> MROY8?<CR><LF>
LUTMode	I Enumeration	R/W	LUTC	0: Off 1: Gamma 2: LUT	0	2	0	LUTC=[Param.]<CR><LF> LUTC?<CR><LF>
AlcSpeed	I Integer	R/W	ALCS	Min~Max	1	8	4	ALCS=[Param.]<CR><LF> ALCS?<CR><LF> for AGC and ASC
ExposureAutoMax	I Integer	R/W	ASCEA	Min~Max[us]	101	8000000	18000	ASCEA=[Param.]<CR><LF> ASCEA?<CR><LF> Maximum value is varied depending on frame rate.
ExposureAutoMin	I Integer	R/W	ASCEI	Min~Max	100	7999999	100	ASCEI=[Param.]<CR><LF> ASCEI?<CR><LF> Maximum value is varied depending on frame rate.
RequestExposureAutoResult	I Enumeration	R/O	ASRS	0=Complete. 1=Too Bright. 2=Too dark. 3=Timeout Error. 4=Busy. 5=Limit. 6= Trig is not set as Normal.	0	6	0	ASRS?<CR><LF>
TriggerOption	I Enumeration	R/W	TRGOP	0: Off 1: RCT 2: PIV 3: Smear-less 4: RCT Continuous	0	4	0	TRGOP=[Param.]<CR><LF> TRGOP?<CR><LF>
AlcReference	I Integer	R/W	AGCF	Min~Max[%]	1	100	50	AGCF=[Param.]<CR><LF> AGCF?<CR><LF>
GainAutoMax	I Integer	R/W	AGCGA	Min~Max	101	1600	1600	AGCGA=[Param.]<CR><LF> AGCGA?<CR><LF>
GainAutoMin	I Integer	R/W	AGCGI	Min~Max	100	1599	100	AGCGI=[Param.]<CR><LF> AGCGI?<CR><LF>
RequestGainAutoResult	I Enumeration	R/O	AGRS	0=Complete. 1=Too Bright. 2=Too dark. 3=Timeout Error. 4=Busy. 5=Limit. 6= Trig is not set as Normal.	0	6	0	AGRS?<CR><LF>
AutoIrisLensControlSignalOutput	I Enumeration	R/W	AIC	0: Off 1: On	0	1	0	AIC=[Param.]<CR><LF> AIC?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

LensSelect	I Enumeration	R/W	AIS	0: None 1: P-IRIS Lens 2: MOTOR Iris Lens 3: Video Iris Lens 4: DC Iris Lens	0	4	0	AIS=[Param.]<CR><LF> AIS?<CR><LF>
VideoIrisStateControl	I Enumeration	R/W	ISC	0: Video 1: Close 2: Open	0	1	2	ISC=[Param.]<CR><LF> ISC?<CR><LF>
ALCChannelAreaAll	I Enumeration	R/W	ALCA	0: Off / 1: On	0	1	0	ALCA=[Param.]<CR><LF> ALCA?<CR><LF>
ALCChannelAreaLowRight	I Enumeration	R/W	ALCLR	0: Off / 1: On	0	1	1	ALC**=[Param.]<CR><LF> ALC**?<CR><LF>
ALCChannelAreaLowMidRight	I Enumeration	R/W	ALCLMR	0: Off / 1: On	0	1	1	
ALCChannelAreaLowMidLeft	I Enumeration	R/W	ALCLML	0: Off / 1: On	0	1	1	
ALCChannelAreaLowLeft	I Enumeration	R/W	ALCLL	0: Off / 1: On	0	1	1	
ALCChannelAreaMidLowRight	I Enumeration	R/W	ALCMLR	0: Off / 1: On	0	1	1	
ALCChannelAreaMidLowMidRight	I Enumeration	R/W	ALCMLMR	0: Off / 1: On	0	1	1	
ALCChannelAreaMidLowMidLeft	I Enumeration	R/W	ALCMLML	0: Off / 1: On	0	1	1	
ALCChannelAreaMidLowLeft	I Enumeration	R/W	ALCMLL	0: Off / 1: On	0	1	1	
ALCChannelAreaMidHighRight	I Enumeration	R/W	ALCMHR	0: Off / 1: On	0	1	1	
ALCChannelAreaMidHighMidRight	I Enumeration	R/W	ALCMHMR	0: Off / 1: On	0	1	1	
ALCChannelAreaMidHighMidLeft	I Enumeration	R/W	ALCMHML	0: Off / 1: On	0	1	1	
ALCChannelAreaMidHighLeft	I Enumeration	R/W	ALCMHL	0: Off / 1: On	0	1	1	
ALCChannelAreaHighRight	I Enumeration	R/W	ALCHR	0: Off / 1: On	0	1	1	
ALCChannelAreaHighMidRight	I Enumeration	R/W	ALCHMR	0: Off / 1: On	0	1	1	
ALCChannelAreaHighMidLeft	I Enumeration	R/W	ALCHML	0: Off / 1: On	0	1	1	
ALCChannelAreaHighLeft	I Enumeration	R/W	ALCHL	0: Off / 1: On	0	1	1	

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

AWBChannelAreaAll	I Enumeration	R/W	AWBA	0: Off / 1: On	0	1	0	AWBA=[Param.]<CR><LF> AWBA?<CR><LF>
AWBChannelAreaLowRight	I Enumeration	R/W	AWBLR	0: Off / 1: On	0	1	1	
AWBChannelAreaLowMidRight	I Enumeration	R/W	AWBMR	0: Off / 1: On	0	1	1	
AWBChannelAreaLowMidLeft	I Enumeration	R/W	AWBML	0: Off / 1: On	0	1	1	
AWBChannelAreaLowLeft	I Enumeration	R/W	AWBLL	0: Off / 1: On	0	1	1	
AWBChannelAreaMidLowRight	I Enumeration	R/W	AWBMLR	0: Off / 1: On	0	1	1	
AWBChannelAreaMidLowMidRight	I Enumeration	R/W	AWBMLMR	0: Off / 1: On	0	1	1	
AWBChannelAreaMidLowMidLeft	I Enumeration	R/W	AWBMLML	0: Off / 1: On	0	1	1	
AWBChannelAreaMidLowLeft	I Enumeration	R/W	AWBMLL	0: Off / 1: On	0	1	1	
AWBChannelAreaMidHighRight	I Enumeration	R/W	AWBMR	0: Off / 1: On	0	1	1	AWB**=[Param.]<CR><LF> AWB**?<CR><LF> (Bayer model only)
AWBChannelAreaMidHighMidRight	I Enumeration	R/W	AWBMHMR	0: Off / 1: On	0	1	1	
AWBChannelAreaMidHighMidLeft	I Enumeration	R/W	AWBMHML	0: Off / 1: On	0	1	1	
AWBChannelAreaMidHighLeft	I Enumeration	R/W	AWBMLH	0: Off / 1: On	0	1	1	
AWBChannelAreaHighRight	I Enumeration	R/W	AWBHR	0: Off / 1: On	0	1	1	
AWBChannelAreaHighMidRight	I Enumeration	R/W	AWBMR	0: Off / 1: On	0	1	1	
AWBChannelAreaHighMidLeft	I Enumeration	R/W	AWBML	0: Off / 1: On	0	1	1	
AWBChannelAreaHighLeft	I Enumeration	R/W	AWBHL	0: Off / 1: On	0	1	1	
RequestBalanceWhiteAutoResult	I Enumeration	R/O	AWRS	0=Complete. 1=Too Bright. 2=Too dark. 3=Timeout Error. 4=Busy. 5=Limit. 6= Trig is not set as Normal.	0	6	0	AWRS?<CR><LF> (Bayer model only)

SP-5000M-PMCL / SP-5000C-PMCL

CurrentAreaNoRequest	I Integer	R/O	EA	0: Factory area 1: User 1 area 2: User 2 area 3: User 3 area	0	3	0	EA?<CR><LF> The camera return the latest used DATA AREA.	
PirisLensSelect	I Enumeration	R/W	PLS	No lens available				PLS=[Param.]<CR><LF> PLS?<CR><LF>	
PIrisStepMax	I Integer	R/O	PIS	Indicate control maximum value	P-IRIS step	0	255	128	PIS?<CR><LF> Different depending on PirisLensSelect value
PIrisPosition	I Integer	R/W	PIP	Min~Max		0	255	128	PIP=[Param.]<CR><LF> PIP?<CR><LF> Maximum value is PirisStepMax
PirisAutoMin	I Enumeration	R/W	PLI	0: FULL OPEN 1: F1.4 2: F2 3: F2.8 4: F4 5: F5.6 6: F8 7: F11 8: F16 9: F22 10: F32 11: CLOSE		0	11	1	PLI=[Param.]<CR><LF> PLI?<CR><LF> Minimum value and Maximum value are different depending on PirisLensSelect value
PirisAutoMax	I Enumeration	R/W	PLA	Same as above.		0	11	5	PLI=[Param.]<CR><LF> PLI?<CR><LF> Minimum value and Maximum value are different depending on PirisLensSelect value
PirisCurrentFvalue	I Enumeration	R/O	PCV	Same as above.		0	11	0	PCV?<CR><LF>
AcquisitionFrameLine	I Integer	R/W	AR	Min~Max		1	325786	774	AR=[Param.]<CR><LF> AR?<CR><LF> Maximum value is calculated depending on Height and Offset Y settings
GammaSelector	I Integer	R/W	GMA	0($\gamma=1$) ~ 8($\gamma=0.45$) ~ 15($\gamma=TBD$)		0	15	8	GMA=[Param.]<CR><LF> GMA?<CR><LF>
Temperature	I Integer	R/O	TMP0	value		—	—	—	TMP0?<CR><LF> (Value ÷ 128) = Temperature[°C]
GpioPulseGenDivede Value	I Integer	R/W	PGDEV	Min~Max		1	4096	1	PGDEV=[Param.]<CR><LF> PGDEV?<CR><LF>
GpioPulseGenLength0	I Integer	R/W	PGL0	Min~Max		1	1048575	1	PGL0=[Param.]<CR><LF> PGL0?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

GpioPulseGenLength1	I Integer	R/W	PGL1	Min~Max	1	10485 75	1	PGL1=[Param.]<CR><LF> PGL1?<CR><LF>
GpioPulseGenLength2	I Integer	R/W	PGL2	Min~Max	1	10485 75	1	PGL2=[Param.]<CR><LF> PGL2?<CR><LF>
GpioPulseGenLength3	I Integer	R/W	PGL3	Min~Max	1	10485 75	1	PGL3=[Param.]<CR><LF> PGL3?<CR><LF>
GpioPulseGenStart Point0	I Integer	R/W	PGST0	Min~Max	0	10485 74	0	PGST0=[Param.]<CR><LF> PGST0?<CR><LF>
GpioPulseGenStart Point1	I Integer	R/W	PGST1	Min~Max	0	10485 74	0	PGST1=[Param.]<CR><LF> PGST1?<CR><LF>
GpioPulseGenStart Point2	I Integer	R/W	PGST2	Min~Max	0	10485 74	0	PGST2=[Param.]<CR><LF> PGST2?<CR><LF>
GpioPulseGenStart Point3	I Integer	R/W	PGST3	Min~Max	0	10485 74	0	PGST3=[Param.]<CR><LF> PGST3?<CR><LF>
GpioPulseGenEnd Point0	I Integer	R/W	PGENO	Min~Max	1	10485 75	1	PGENO=[Param.]<CR><LF> PGENO?<CR><LF>
GpioPulseGenEnd Point1	I Integer	R/W	PGEN1	Min~Max	1	10485 75	1	PGEN1=[Param.]<CR><LF> PGEN1?<CR><LF>
GpioPulseGenEnd Point2	I Integer	R/W	PGEN2	Min~Max	1	10485 75	1	PGEN2=[Param.]<CR><LF> PGEN2?<CR><LF>
GpioPulseGenEnd Point3	I Integer	R/W	PGEN3	Min~Max	1	10485 75	1	PGEN3=[Param.]<CR><LF> PGEN3?<CR><LF>
GpioPulseGenRepeat Count0	I Integer	R/W	PGRPT0	Min~Max	0	255	0	PGRPT0=[Param.]<CR><LF> PGRPT0?<CR><LF>
GpioPulseGenRepeat Count1	I Integer	R/W	PGRPT1	Min~Max	0	255	0	PGRPT1=[Param.]<CR><LF> PGRPT1?<CR><LF>
GpioPulseGenRepeat Count2	I Integer	R/W	PGRPT2	Min~Max	0	255	0	PGRPT2=[Param.]<CR><LF> PGRPT2?<CR><LF>
GpioPulseGenRepeat Count3	I Integer	R/W	PGRPT3	Min~Max	0	255	0	PGRPT3=[Param.]<CR><LF> PGRPT3?<CR><LF>
GpioPulseGenCl ear Mode0	I Enumeration	R/W	PGCM0	0: Free Run 1: Level High 2: Level Low 3: Rising Edge 4: Falling Edge	0	4	0	PGCM0=[Param.]<CR><LF> PGCM0?<CR><LF>
GpioPulseGenCl ear Mode1	I Enumeration	R/W	PGCM1	Same as above.	0	4	0	PGCM1=[Param.]<CR><LF> PGCM1?<CR><LF>
GpioPulseGenCl ear Mode2	I Enumeration	R/W	PGCM2	Same as above.	0	4	0	PGCM2=[Param.]<CR><LF> PGCM2?<CR><LF>
GpioPulseGenCl ear Mode3	I Enumeration	R/W	PGCM3	Same as above.	0	4	0	PGCM3=[Param.]<CR><LF> PGCM3?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

GpioPulseGenSync Mode0	I Enumeration	R/W	PGSM0	0: Async Mode 1: Sync Mode	0	1	0	PGSM0=[Param.]<CR><LF> PGSM0?<CR><LF>
GpioPulseGenSync Mode1	I Enumeration	R/W	PGSM1	Same as above.	0	1	0	PGSM1=[Param.]<CR><LF> PGSM1?<CR><LF>
GpioPulseGenSync Mode2	I Enumeration	R/W	PGSM2	Same as above.	0	1	0	PGSM2=[Param.]<CR><LF> PGSM2?<CR><LF>
GpioPulseGenSync Mode3	I Enumeration	R/W	PGSM3	Same as above.	0	1	0	PGSM3=[Param.]<CR><LF> PGSM3?<CR><LF>
GpioPulseGenIn put0	I Enumeration	R/W	PGIN0	0:Low 1:High 2:Soft 3:AcquisitionTrigger Wait 4:FrameTriggerWait 5:FrameActive 6:ExposureActive 7:FVAL 8:LVAL 9:PG0 10:PG1 11:PG2 12:PG3 13: TTL in 14:CL CC1 in 15:nand0 16:nand1 17: OPTTL in2 18: OPLVDS in	0	18	0	PGIN0=[Param.]<CR><LF> PGIN0?<CR><LF>
GpioPulseGenIn put1	I Enumeration	R/W	PGIN1	Same as above.	0	18	0	PGIN1=[Param.]<CR><LF> PGIN1?<CR><LF>
GpioPulseGenIn put2	I Enumeration	R/W	PGIN2	Same as above.	0	18	0	PGIN2=[Param.]<CR><LF> PGIN2?<CR><LF>
GpioPulseGenIn put3	I Enumeration	R/W	PGIN3	Same as above.	0	18	0	PGIN3=[Param.]<CR><LF> PGIN3?<CR><LF>
GpioPulseGenIn vert0	I Enumeration	R/W	PGINV0	0:Non-Inv 1:Inv	0	1	0	PGIN0=[Param.]<CR><LF> PGIN0?<CR><LF>
GpioPulseGenIn vert1	I Enumeration	R/W	PGINV1	Same as above.	0	1	0	PGIN1=[Param.]<CR><LF> PGIN1?<CR><LF>
GpioPulseGenIn vert2	I Enumeration	R/W	PGINV2	Same as above.	0	1	0	PGIN2=[Param.]<CR><LF> PGIN2?<CR><LF>
GpioPulseGenIn vert3	I Enumeration	R/W	PGINV3	Same as above.	0	1	0	PGIN3=[Param.]<CR><LF> PGIN3?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL



See the possibilities

GpioNand0Input Source1	I Enumeration	R/W	ND0IN1	0: Low 1: High 2: FrameTriggerWait 3: FramActive 4: ExposureActive 5: Fval 6: PulseGenerator0 7: PulseGenerator1 8: PulseGenerator2 9: PulseGenerator3 10: TTL_In1 11: CL_CC1_In	0	11	0	ND0IN1=[Param.]<CR><LF> ND0IN1?<CR><LF>
GpioNand1Input Source1	I Enumeration	R/W	ND1IN1	Same as above.	0	11	0	ND1IN1=[Param.]<CR><LF> ND1IN1?<CR><LF>
GpioNand0Input Source2	I Enumeration	R/W	ND0IN2	0: Low 1: High 2: FrameTriggerWait 3: FramActive 4: ExposureActive 5: Fval 6: PulseGenerator0 7: PulseGenerator1 8: PulseGenerator2 9: PulseGenerator3 10: TTL_In1 11: CL_CC1_In	0	11	0	ND0IN2=[Param.]<CR><LF> ND0IN2?<CR><LF>
GpioNand1Input Source2	I Enumeration	R/W	ND1IN2	Same as above.	0	11	0	ND1IN2=[Param.]<CR><LF> ND1IN2?<CR><LF>
GpioNand0Input Invert1	I Enumeration	R/W	ND0INV 1	0: Non-Inv 1: Inv	0	1	0	ND0INV1=[Param.]<CR><LF> ND0INV1?<CR><LF>
GpioNand1Input Invert1	I Enumeration	R/W	ND1INV 1	Same as above.	0	1	0	ND1INV1=[Param.]<CR><LF> ND1INV1?<CR><LF>
GpioNand0Input Invert2	I Enumeration	R/W	ND0INV 2	0: Non-Inv 1: Inv	0	1	0	ND0INV2=[Param.]<CR><LF> ND0INV2?<CR><LF>
GpioNand1Input Invert2	I Enumeration	R/W	ND1INV 2	Same as above.	0	1	0	ND1INV2=[Param.]<CR><LF> ND1INV2?<CR><LF>
MotorLensIris	I Enumeration	R/W	MLI	0: Stop 1: Open 2: Close	0	2	0	MLI=[Param.]<CR><LF> MLI?<CR><LF>
MotorLensZoom	I Enumeration	R/W	MLZ	0: Stop 1: Wide 2: Tele	0	2	0	MLZ=[Param.]<CR><LF> MLZ?<CR><LF>
MotorLensFocus	I Enumeration	R/W	MLF	0: Stop 1: Wide 2: Tele	0	2	0	MLF=[Param.]<CR><LF> MLF?<CR><LF>
LUTSequenceR	I Enumeration	R/W	LUTSR	Min~Max	0	4095	0	LUTSR=[Param.]<CR><LF> LUTSR?<CR><LF>
LUTSequenceG	I Enumeration	R/W	LUTSG	Min~Max	0	4095	0	LUTSG=[Param.]<CR><LF> LUTSG?<CR><LF>
LUTSequenceB	I Enumeration	R/W	LUTSB	Min~Max	0	4095	0	LUTSB=[Param.]<CR><LF> LUTSB?<CR><LF>

SP-5000M-PMCL / SP-5000C-PMCL

BlemishNum	I Integer	R/O	BNUM	Min~Max	0	512	0	BNUM?<CR><LF>
CameraLinkClockFrequency	I Enumeration	R/W	CLCF	0= 82.3MHz 1= 75.4MHz 2= 61.7MHz	0	2	0	CLCF=[Param.]<CR><LF> CLCF?<CR><LF>
VideoProcessByPass	I Enumeration	R/W	VPB	0: Off / 1: On	0	1	0	VPB=[Param.]<CR><LF> VPB?<CR><LF>
HighDynamicRangeMode	I Enumeration	R/W	HES	0: Off / 1: On	0	1	0	HES=[Param.]<CR><LF> HES?<CR><LF>
HighDynamicRangeSlope	I Enumeration	R/W	HKS	0: 70dB 1: 80dB 2: 90dB 3: 100dB	0	3	0	HKS=[Param.]<CR><LF> HKS?<CR><LF>

Appendix 2

1. Precautions

Personnel not trained in dealing with similar electronic devices should not service this camera. The camera contains components sensitive to electrostatic discharge. The handling of these devices should follow the requirements of electrostatic sensitive components.

Do not attempt to disassemble this camera.

Do not expose this camera to rain or moisture.

Do not face this camera towards the sun, extreme bright light or light reflecting objects.

When this camera is not in use, put the supplied lens cap on the lens mount.

Handle this camera with the maximum care.

Operate this camera only from the type of power source indicated on the camera.

Power off the camera during any modification such as changes of jumper and switch setting.

2. Typical Sensor Characteristics

The following effects may be observed on the video monitor screen. They do not indicate any fault of the camera, but are associated with typical sensor characteristics.

V. Aliasing

When the CMOS camera captures stripes, straight lines or similar sharp patterns, jagged edges may appear on the monitor.

Blemishes

All cameras are shipped without visible image sensor blemishes.

Over time some pixel defects can occur. This does not have a practical effect on the operation of the camera. These will show up as white spots (blemishes).

Exposure to cosmic rays can cause blemishes to appear on the image sensor. Please take care to avoid exposure to cosmic rays during transportation and storage. It is recommended using sea shipment instead of air flight in order to limit the influence of cosmic rays on the camera. Pixel defects/blemishes also may emerge due to prolonged operation at elevated ambient temperature, due to high gain setting, or during long time exposure. It is therefore recommended to operate the camera within its specifications.

Patterned Noise

When the sensor captures a dark object at high temperature or is used for long time integration, fixed pattern noise may appear on the video monitor screen.

3. Caution when mounting a lens on the camera


When mounting a lens on the camera dust particles in the air may settle on the surface of the lens or the image sensor of the camera. It is therefore important to keep the protective caps on the lens and on the camera until the lens is mounted. Point the lens mount of the camera downward to prevent dust particles from landing on the optical surfaces of the camera. This work should be done in a dust free environment. Do not touch any of the optical surfaces of the camera or the lens.

4. Caution when mounting the camera

When you mount the camera on your system, please make sure to use screws of the recommended length described in the following drawing. Longer screws may cause serious damage to the PCB inside the camera.

If you mount the tripod mounting plate, please use the provided screws.


Camera chassis



Tripod mount

Attaching the tripod mount

Camera chassis



Fixing plate

Mounting the camera to fixing plate

5. Exportation

When exporting this product, please follow the export regulation of your own country.

6. References

1. This manual and a datasheet for SP-5000M-PMCL / SP-5000C-PMCL can be downloaded from www.jai.com
2. Camera control software can be downloaded from www.jai.com

Manual change history

User's Record

Camera type: SP-5000M-PMCL / SP-5000C-PMCL

Revision:

Serial No.

Firmware version.

For camera revision history, please contact your local JAI distributor.

User's Mode Settings.

User's Modifications.

Company and product names mentioned in this manual are trademarks or registered trademarks of their respective owners. JAI A-S cannot be held responsible for any technical or typographical errors and reserves the right to make changes to products and documentation without prior notification.

Europe, Middle East & Africa

Phone +45 4457 8888
Fax +45 4491 3252

Asia Pacific

Phone +81 45 440 0154
Fax +81 45 440 0166

Americas

Phone (toll-free) +1 800 445 5444
Phone +1 408 383 0300

Visit our web site at www.jai.com



See the possibilities

Documentation Utilisateur

Camera Tool version 3.4



<u>Contact :</u>	R&D VISION Tél. : (33) 1 76 62 11 50 Fax : (33) 1 76 61 61 60 Web : www.rd-vision.com e-mail : support@rd-vision.com
------------------	--



TABLE DES MATIERES

I. PRESENTATION DE L'APPLICATION	2
I.1. INTRODUCTION	2
I.2. DEMARRAGE DE L'APPLICATION	2
II. PARAMETRES REGLABLES	5
II.1. ONGLETS « SETTINGS ».....	5
II.2. ONGLET « ADVANCED »	7
II.2.1. Shading	8
II.2.2. White Balance	8
II.3. ONGLET « I/O »	9
II.3.1. Hardware	10
II.3.2. Polarity	11
II.4. ONGLET CUSTOM	12
III. « DIRECT ACCESS »	13
IV. « SAVE CURRENT SETTINGS »	14
IV.1. ONGLET « FILE »	14
IV.2. ONGLET « BUS DRIVER ».....	15
IV.3. ONGLET « SERIAL PORT »	15
V. ERREURS ET RESOLUTIONS	17
VI. DEFINITIONS.....	18
VII. LISTE DES CAMERAS IMPLEMENTEES.....	20
VII.1. FIREWIRE.....	20
VII.2. CAMERA LINK.....	20
VII.3. ETHERNET	20
VII.4. USB	20
VIII. NOTES.....	20




I. PRÉSENTATION DE L'APPLICATION

I.1. Introduction

Aujourd’hui HIRIS permet l’acquisition d’images de différentes caméras simultanément. Il fonctionne sur le principe du conteneur d’image. *Camera Tool* permet de compléter la solution HIRIS en proposant le réglage des caméras. C’est une interface généraliste pouvant paramétriser des caméras de modèles et marques différentes.

I.2. Démarrage de l’application

Au lancement de l’application, cette boîte de dialogue apparaît.




- Tous les contrôles sont désactivés au lancement de l’application, seul le bouton *Camera* reste actif.
- Les différents paramètres sont répartis dans 3 onglets :
 - Settings : Contient les paramètres les plus utilisés et les plus répandus sur les caméras.



- Advanced : Contient des paramètres avancés, utilisés plus rarement et beaucoup moins répandus sur les caméras.
- I/O : Contient une fonctionnalité avancée qui surveille des I/O.


La liste des caméras apparaît sous forme d'arborescence, où chaque « nœud » représente un modèle de caméra et chaque « feuille » un fichier de sauvegarde qui lui est rattaché.

Lorsque l'on choisit une caméra ou un fichier de sauvegarde dans la liste :





Si aucune erreur ne se produit tous les paramètres disponibles sur la caméra deviennent actifs :






II. PARAMETRES REGLABLES

L'application propose un grand nombre de paramètres réglables. Ceux-ci sont répartis sur plusieurs onglets.

II.1. Onglets « Settings »

L'onglet « Settings » propose le réglage des principaux paramètres.



- *Output :*
 - *Taps* : Nombre de taps en sortie
 - *Bits* : Dynamique du capteur
 - *Rate* : Débit théorique de la caméra
- *Trigger :*
 - *Trigger (liste déroulante)* : Choix du mode de déclenchement
 - *Polarity* : Polarité de déclenchement en mode trigger
 - *Input* : Entrée de déclenchement pour le trigger
 - *Synchrone/Asynchrone* : Mode de synchronisation du trigger
 - *Number of frames* : Nombre d'images pour le mode BULK
- *Exposure* : Choix du temps d'exposition entre des valeurs prédéfinies et le réglage manuel
- *Gain* : Réglage du gain
- *Offset* : Réglage de l'offset
- *FPS* : Fréquence d'images théorique de la caméra



Attention, concernant les FPS max, ceux-ci sont limités par le temps d'exposition et parfois par la taille de l'AOI. Les calculs des FPS max sont les suivants :

- FPS max = $1 / (\text{temps d'exposition en sec} + \Delta t \text{ en sec})$,
- FPS max = $(\text{débit maximum}) / (\text{taille d'une image en Octets})$.


Dans ce cas c'est la plus petite valeur qui est retenue.

Pour plus d'information sur les différents modes du Trigger, se référer à la section [VI. Définitions](#) ou à la Documentation Constructeur de la caméra.



II.2. Onglet « Advanced »

L'onglet « Advanced » paramètre des fonctionnalités avancées de la caméra.



- *Aera Of Interest* : Région d'intérêt
 - *Mode* : (Des)Activation de la ROI
 - *Left, Top, Width, Height* : Réglage manuel de la ROI
 - *Schéma (rectangle)* : La zone en blanc représente la ROI. Un double-clique sur la croix permet de centrer la ROI en mode « User ».
- *Binning* : Réglage du binning
- *Image size* : Nombre de pixels de la caméra
- *High SNR* : Réglage du High SNR (2^n images).
- *White Balance* : Réglage de la balance des blancs
- *LUT* : En développement
- *Shading* :
 - *Auto* : Réglage Auto/Manuel du hading
 - *Activate* : (Des)Activation du shading



II.2.1. Shading

Le shading (cf. [VI. Definitions](#)) n'est disponible, actuellement, que sur les cameras AVT. Pour utiliser ce paramètre, 2 solutions sont possibles :

- Auto : Il suffit de cliquer sur le bouton *Auto*, ensuite cocher la case *Activate* puis cliquer sur le bouton *SET*. En mode Auto la caméra calcul et génère une image automatiquement. Pour plus d'information se référer à la Documentation Constructeur de la caméra.
- Manuel : Le mode manuel est beaucoup moins simple que le mode Auto. En effet, avant toute chose il faut créer l'image que la caméra superposera avec celles qu'elle reçoit du capteur. L'image doit être au format .RAW. Il faut aussi qu'elle ait le même nombre de pixels que la caméra. C'est-à-dire qu'il faut changer l'image si le Binning ou l'AOI a été modifié. (Ex : si la caméra fait 640x480 pixels et qu'elle est en mode Binning 2x2, il faudra donc une image de 320x240 pixels pour le shading.)

Une fois l'image créée, il suffit de la charger en cliquant sur *Select File* puis cocher la case *Activate* et enfin de cliquer sur *SET*.


II.2.2. White Balance

Le *White Balance* (cf. [VI. Definitions](#)) n'est actuellement disponible que sur les caméras AVT en mode *Auto*. La caméra va alors régler automatiquement les composantes U et V. Ce réglage peut prendre quelques secondes (le temps dépend du temps d'exposition de la caméra). Une fois le réglage fini les valeurs des composantes U et V s'affiche dans les champs prévus.



II.3. Onglet « I/O »

Cet onglet propose de surveiller des I/O à 1kHz.



- *Hardware* : Choix du type d'I/O
- *Polarity* : Choix de la polarité de déclenchement d'une I/O.
- *Liste Inputs* :
 - *Set* : Choix des entrées à prendre en compte en cochant les cases
 - *Hiris Images Containers* : Association de l'entrée sélectionnée à une ou plusieurs Image Container d'HIRIS
- *Liste Outputs* : En développement
- *Delay* : En développement
- *Check* : Démarrage du contrôle des I/O.

Pour associer un Image Container à une entrée, il faut sélectionner cette entrée en cochant sa case associée *Seq1* par exemple, puis choisir en cliquant dans la colonne « *Hiris Images Containers* » à la ligne désirée, ici *Seq1*, pour faire apparaître la liste des Images Containers. Idem pour plusieurs Images Containers.

Dans l'exemple qui suit, nous avons donc activé les entrées *Seq1*, *Seq2* et *Burst1*. *Seq1* est relié aux Images Containers 0, 1 et 2. *Seq2* est relié à l'Image Container 4. *Burst1* est relié à l'Image Container 1.



	Set	Inputs	Hiris Images Containers	
<input checked="" type="checkbox"/>	Seq 1	0 1 2		✓ #0
<input checked="" type="checkbox"/>	Seq 2	4		✓ #1
<input checked="" type="checkbox"/>	Burst 1	1		✓ #2


II.3.1. Hardware

Le réglage *Hardware* permet de définir quel type d'entrée sera surveillé. Actuellement l'application supporte 3 types d'entrées. Un message d'erreur apparaît si les IOs sur le matériel sélectionné ne sont pas disponibles.

- **Camera** : Disponible seulement sur les caméras AVT, l'entrée n°2 de la caméra est surveillée à 1 kHz (**IO_INP_CTRL2** cf. documentation des caméras AVT). Cette entrée est liée à l'entrée **Seq 1**. S'il y a changement d'état de cette entrée défini dans *Polarity HIRIS* déclanche la ou les séquences des ImageBoxes associées. Pour les 3 autres entrées, **Seq 2**, **Burst 1** et **Burst 2** elles sont associées au Port Parallèle si celui-ci est disponible. Pour plus d'information sur le brochage du port parallèle, cf. la section associée ci-dessous.
- **Grabber** : Disponible seulement sur les cartes d'acquisition SAPERA, les 4 premières entrées disponibles sur la carte sont surveillé à 1kHz (**GPI_0**, **GPI_1**, **GPI_2** et **GPI_3**).
 - **GPI_0** correspond à **Seq 1**,
 - **GPI_1** correspond à **Burst 1**,
 - **GPI_2** correspond à **Seq 2**,
 - **GPI_3** correspond à **Burst 2**.
- **Parallel Port** : Disponible seulement sur les PC équipé d'un port parallèle. Si le PC est équipé de plusieurs ports parallèles, il faut utiliser le premier port (LPT1). Seuls les entrées ACK, PE, SELECT et ERROR sont utilisé (cf. [brochage du port parallèle](#)).
 - **ACK** correspond à l'entrée **Seq 1**,
 - **PE** correspond à l'entrée **Burst 1**,
 - **SELECT** correspond à l'entrée **Seq 2**,
 - **ERROR** correspond à l'entrée **Burst 2**.



Brochage du port parallèle :




Représentation du Port Parallèle

Broche	Nom	I/O
1	/STROBE	I/O
2	D0	O
3	D1	O
4	D2	O
5	D3	O
6	D4	O
7	D5	O
8	D6	O
9	D7	O
10	ACK	I
11	BUSY	I
12	PE (Paper End)	I
13	SELECT	I
14	/AUTOFEED	I/O
15	ERROR	I
16	/INIT	I/O
17	/SELECT IN	I/O
18-25	Masse	--


II.3.2. Polarity

Le réglage *Polarity* permet de définir le type d'événement qui sera surveillé par le module :

- All : Mode de déclenchement sur n'importe quel front du signal :



- High : Mode de déclenchement sur un front montant du signal :




- Low : Mode de déclenchement sur un front descendant du signal :





II.4. Onglet Custom

Cet onglet, disponible uniquement sur certaine caméra, regroupe des paramètres non commun ou spécifiques à la caméra. Il se présente sous la forme d'un tableau : d'un coté le paramètre avec sa description. De l'autre coté un champ pour la valeur du paramètre. Ce champ peut être en lecture seule, une liste de choix ou un champ de saisie de valeur.



The screenshot shows the Camera Tool interface with the 'Custom' tab selected. A table displays various camera parameters and their current values. The parameters listed are:

Parameters	Value
ADC (Mhz)	2
Coupling	AC
Termination	High
Threshold (mV)	0
Gate Mode	Safe
Gate Delay (ns)	0
Gate Width (ns)	1
Number of strips per clean	1
AuxOutDelay (ns)	3
LogicOut	Not scan
Temperature	0
TemperatureSet	0
On Chip Accumulation	1
Continous clean	0

Liste des paramètres et de leur description. (Left callout pointing to the parameter column)

Liste des valeurs des paramètres (Right callout pointing to the value column)

Pour plus d'information concernant les différents paramètres intégrés dans cet onglet, veuillez vous référer à la documentation de la caméra directement.




III. « DIRECT ACCESS »

Cette boîte de dialogue communique avec la caméra en envoyant des mots, pour les caméras utilisant le protocole série, ou en accédant directement aux registres, pour les caméras utilisant le FireWire. Pour ouvrir cette boîte de dialogue, cliquer sur *Macro* dans la barre de menu puis sur *Direct Access*.

N'utilisez ce mode que si vous connaissez les adresses ou mots à envoyer à la caméra. Si la syntaxe n'est pas respectée cela peut bloquer la caméra ou l'interface. Auquel cas il faudra débrancher et rebrancher la caméra ainsi que redémarrer l'application.

Voici un aperçu de cette boîte de dialogue :




- *Read* : pour les caméras FireWire, lit la valeur à l'adresse registre de la caméra et l'affiche dans le champ *Value*.
- *Send* : pour les caméras en liaison série pour envoyer des mots à la caméra.
- *Write* : pour les caméras FireWire, écrit la valeur du champ *Value* à l'adresse registre de la caméra.




IV. « SAVE CURRENT SETTINGS »

La fonction *Save Current Settings* sauvegarde les paramètres en cours sur la caméra afin de les charger ultérieurement. Cette fonction est disponible dans la barre de menu dans *File*, lorsqu'une caméra a déjà été sélectionnée ou par le bouton « Save » sous l'arborescence des caméras.



IV.1. Onglet « File »


L'onglet *File* permet la saisie d'information sur la sauvegarde des paramètres courants, tels que le nom de la caméra, le nom du fichier et des notes supplémentaires.






IV.2. Onglet « Bus Driver »

L'onglet *Bus Driver* contient des informations sur le bus, la carte du bus et sur son driver. Ces informations sont optionnelles mais sont utiles pour choisir le port du bus sur lequel est branchée la caméra, ou le driver CVB utilisé par Hiris.



IV.3. Onglet « Serial Port »

L'onglet *Serial Port* paramètre le port série. Les valeurs pré-saisies fonctionnent pour la caméra sélectionnée. Changer le port ID pour correspondre à celui de la caméra. Pour les numéros COM ils sont à utiliser dans le cas des cartes Sapera, lorsqu'un port est émulé. Pour les numéros DLL, ils sont à utiliser dans le cas où les cartes Sapera n'ont aucun port émulé ou pour tout autre carte.



La sauvegarde se fait dans un fichier *.cfg.
On retrouve ce fichier dans l'arborescence des caméras.
Recharger le fichier créé pour l'utiliser dans le Caméra Tool.



V. ERREURS ET RESOLUTIONS

En développement



VI. DEFINITIONS

- **AOI / ROI :**
Aera of Interest, Région d'intérêt de l'image. Ce paramètre permet de définir une région particulière sur les images reçues, permettant ainsi d'augmenter la vitesse de transfert.
- **Binning :**
Permet de diviser la résolution de l'image en regroupant plusieurs pixels voisins, ceci pour augmenter la vitesse de transfert des images.
- **Bits :** Nombre de bits alloués en sortie de la caméra pour le transfert de l'image (8/10/12...bits).
- **BULK (Trigger):**
Mode de trigger qui, lorsque la caméra reçoit un top, déclenche une séquence. Cette séquence peut être réglée pour un nombre d'images précis ou infini.
- **Color RAW :** Permet de désactiver ou non l'ajout des couleurs sur l'image directement à partir de la caméra.
- **Edge (Trigger) :** Mode de déclenchement qui permet de contrôler le départ de chaque image. Un changement d'état (défini dans *Polarity*) permet de démarrer une image, avec le temps d'exposition réglé dans la caméra.
- **Exposure :**
Temps d'exposition du capteur. Aussi appelé Shutter.
- **FPS :**
Frames Per Second ou fréquence d'images de la caméra.
- **Gain :**
Il définit l'amplification du signal en sortie du capteur. Aussi appelé Brightness.
- **Gamma :**
Ce paramètre corrige la « non linéarité » de la reproduction lumineuse. Il joue sur les niveaux de gris moyen.
- **High SNR :**
Permet de moyenner plusieurs images à la suite afin de diminuer le bruit. (Diminution de la cadence de la camera).
- **Input (Trigger):**
Définit l'entrée de déclenchement de la caméra (CameraLink/Hirose).
- **Level (Trigger) :**



Mode de déclenchement qui permet de contrôler le temps d'exposition du capteur (Shutter) avec un signal externe. L'état *High* (ou *Low* suivant la polarité choisi) du signal correspond au temps d'exposition alors que l'autre état est un état de repos du capteur.

- **LUT**: Look-Up Table, c'est la relation entre le niveau de gris de l'image vue par le capteur et celui représenté à l'écran.
- **Offset**:
Il définit l'offset du signal en sortie du capteur, s'additionne avec le Gain. Aussi appelé Contrast.
- **PIV (Trigger)**: Mode de trigger qui, lorsque la caméra reçoit un top, déclenche la caméra pour deux images avec un temps minimale entre les deux images.
- **Polarity (Trigger)**:
Définit le front (montant ou descendant) de déclenchement.
- **Shading**:
Correction de l'ombrage. Corrige le défaut des capteurs sur les extrémités en augmentant l'ombrage dans les zones les plus claires. Pour cela on superpose une image fixe sur les images de la caméra.
- **Taps**: Définit le nombre de « Taps » (Single : l'image est transférée d'un seul bloc et Dual : l'image est divisée en 2 pour être transférée).
- **Trigger Mode**:
Mode de déclenchement de la caméra. Il peut être interne (*Freerun*) la caméra se déclenche à l'infini ou externe la caméra attend une impulsion pour démarrer (plusieurs mode sont disponible en externe : *Edge*, *Level*, *PIV*, *BULK*).
- **White Balance** (ou Balance des blancs):
Permet de faire varier la quantité d'une couleur primaire (rouge/bleu/vert). Selon les caméras le réglage agit sur les 3 couleurs primaires ou sur 2 composantes U et V. (U : vert → bleu, V : vert → rouge).



VII. LISTE DES CAMERAS IMPLEMENTEES

VII.1. FireWire

- AVT :
 - Guppy :
 - F033B/C
 - F036B/C
 - F038B/C
 - F044B/C
 - F046B/C
 - F080B/C
 - F146B/C
 - F503B/C
 - Marlin :
 - F033B/C
 - F046B/C
 - F080B/C
 - F145B/C
 - F146B/C
 - F201B/C
 - F131B/C
 - Pike :
 - F032B/C
 - F100B/C
 - F145B/C
 - F210B/C
 - F421B/C
 - F505B/C
 - Stingray :
 - F033B/C
 - F046B/C
 - F080B/C
 - F145B/C
 - F146B/C
 - F201B/C
- CV-M8
- CV-M8CL
- BM-500
- BM-500CL
- AB-1600CL
- Hamamatsu
 - C9100-013
 - C9300-024
 - C8484
- Mikrotron
 - EoSens 1360,
 - EoSens 1361,
 - EoSens 1362,
 - EoSens 1363,
- IDT Vision
 - MotionScope M3
 - MotionScope M5.
- TELI Toshiba
 - Clever Dragon 12Mpixels
- VDS Vosskühler
 - NIR-300

VII.2. Camera Link

- Dalsa
 - Falcon 01M1H
 - Falcon 04M60
 - Piranha 2 04K40
 - Spyder 3 SC 02K80
- JAI
 - TM-4200
 - CV-M2
 - CV-M2CL

VII.3. Ethernet

- FLIR
 - SC2500
 - SC7000
- Roper
 - PI-MAX3
 - ProEM
- Hamamatsu
 - C8000

VII.4. USB


- uEye
 - UI1220



VIII. NOTES

Manuel utilisateur

HIRIS version 4.5



Contact : **R&D VISION**
www.rd-vision.com
Tél. : (33) 1 76 62 11 50
Fax : (33) 1 76 61 61 60
www.rd-vision.com
e-mail : support@rd-vision.com



TABLE DES MATIERES.

I. INTRODUCTION	3
I.1. PRINCIPALES FONCTIONS D'HIRIS :.....	4
II. INSTALLATION	5
II.1. PREALABLES.....	5
II.2. INSTALLATION DU LOGICIEL HIRIS.	5
II.3. DESINSTALLATION.....	6
II.4. PROTECTION DU LOGICIEL ET MODE DEMO.	6
II.4.1. ACTIVATION DU LOGICIEL	6
II.5. RECOMMANDATIONS	6
III. ARCHITECTURE HIRIS.....	7
IV. FONCTIONNEMENT.....	8
IV.1. GENERALITES	8
IV.2. INTERFACE UTILISATEUR	8
V. BOITE DE DIALOGUE PRINCIPALE.....	9
V.1. MENU <i>PROJECT</i>	9
V.2. MENU <i>LOAD</i>	11
V.2.1. CHARGEMENT D'UNE CAMERA (<i>LOAD/CAMERA</i>)	11
V.2.2. CHARGEMENT D'UNE SEQUENCE (<i>LOAD/SEQUENCE</i>)	11
VI. LE CONTENEUR D'IMAGES	12
VI.1. MODE CAMERA : BARRE D'OUTILS	12
VI.1.1. DESCRIPTION DE LA BARRE D'OUTILS.....	12
VI.1.2. INFORMATIONS SUR L'ETAT DU CONTENEUR D'IMAGES.....	13
VI.1.3. REGLAGE DES PARAMETRES D'ACQUISITION DES IMAGES.	14
VI.1.4. UTILISATION DES <i>TRIGGER</i>.....	14
VI.1.5. ENREGISTREMENT D'UNE SEQUENCE D'IMAGE.	16
VI.1.6. BOUTON <i>SETUP</i>	17
VI.1.7. PLAYER	21
VI.1.8. SAUVEGARDE DES IMAGES.....	22
VI.1.9. ONGLET PLUGINS	23
VI.2. MODE SEQUENCE : BARRE D'OUTILS.....	24
VI.2.1. INFORMATIONS GENERALES	24
VI.2.2. PLAYER	24
VI.2.3. EXPORT DE LA SEQUENCE	24
VI.3. FONCTIONNALITES DES BOUTONS DE LA ZONE D'AFFICHAGE DU CONTENEUR D'IMAGES	25
VI.3.1. <i>DISPLAY</i>	25
VI.3.2. LOOK UP TABLE (<i>LUT</i>).....	27
VI.3.3. DÉCODAGE <i>BAYER</i> (LOOK UP TABLE)	32



VI.3.4. CORRECTION D'IMAGES CCD (SHADING)	33
VI.3.5. <i>CALIB.</i> (CALIBRATION SPATIALE).....	35
VI.3.6. <i>TOOLS</i>	39
VI.3.6.1. HISTOGRAM	39
VI.3.6.2. PROFILE	39
VII. SYNCHRONISATION DES CONTAINERS D'IMAGES.....	41
VII.1. MENU DE SYNCHRONISATION DES CONTAINERS.	41
VII.2. SYNCHRONISATION DES CONTAINERS DE CAMERAS.	42
VII.3. SYNCHRONISATION DES CONTAINERS DE SEQUENCES.	44
VIII. RACCOURCIS CLAVIER ET UTILISATION DE LA SOURIS.....	46
VIII.1. UTILISATION DES RACCOURCIS CLAVIER.	46
VIII.2. UTILISATION DE LA SOURIS.	47
IX. FAQ	49
IX.1. PROBLEME DE CHARGEMENT D'UNE CAMERA.	49
IX.2. PROBLEME DE CADENCE D'IMAGE OU DE PERTE D'IMAGES.	50
IX.3. PROBLEMES DE CHARGEMENT D'UNE SEQUENCE.	51
X. NOTES PERSONNELLES	52




I. INTRODUCTION

Le logiciel **HIRIS** est utilisé pour l'acquisition de séquences d'images à cadence élevée avec un contrôle précis des événements extérieurs de déclenchement.

Le logiciel intègre un lecteur de séquence et des outils pour aider l'utilisateur à optimiser l'acquisition d'images.

Basé sur un driver universel, il est compatible avec plus de 250 caméras du marché.



HIRIS peut s'enrichir de fonctionnalités avancées grâce à l'ajout de modules spécifiques, il propose un contrôle par des applications externes simplifiant l'intégration dans un système complexe.



I.1. Principales fonctions d'HIRIS :

Acquisition de séquences en RAM avec allocation dynamique

Acquisition Direct to disk¹

Acquisition Direct to files¹ avec format de sortie (RAW, BMP, JPG, TIFF, PNG, AVI)

Gestion des images 8 à 24 bits

LUTs (Look-Up Table) d'affichage sur ROI (Region Of Interest) et décodage Bayer temps réel

Indexation temporelle précise des images (Time stamp)

Plusieurs modes d'enregistrement des images avec le Pré-Trigger

Décimation de l'acquisition programmable

Acquisition programmée (Time Lapse)

Plusieurs modes de déclenchement de l'enregistrement des séquences :

- **Trigger matériel externe TTL**
- **Touche clavier**
- **Analyse d'image temps réel**

Rotations, miroirs d'affichage (display), Zoom et ROI

Correction d'images numériques (courant d'obscurité, ombrage, sensibilité)

Synchronisation de plusieurs caméras simultanées

Synchronisation d'acquisition et de lectures de plusieurs caméras

Sauvegarde des séquences d'images au format RAW, JPEG, BMP, PNG, AVI, TIF (8-16 bits)

Histogramme temps réel et statistiques

Tracé des profils (pixels, zone)

Ajout d'overlays et d'incrustations dans l'image

Calibration spatiale et correction de déformations de l'image

Partage des images et du contrôle pour des applications tierces

Sauvegarde des paramètres de l'application sous forme de projets

Support de nombreuses cartes d'acquisitions et caméras² (+250)

Développé pour Windows XP SP2 ou ultérieur, compatible Windows 7

¹ Pour des performances optimales sans perte d'image la configuration matérielle doit être adaptée au flux d'images. (*Nous consulter*).

² liste des cartes et caméras supportées <http://en.commonvisionblox.de> – Products – Frame Grabbers



II. INSTALLATION

II.1. Préalables

- Windows XP SP2 ou ultérieur- Windows 7 32bits
- **Droits administrateur sur le compte**
- DirectX 9 minimum installé
- Services packs à jour

ATTENTION :

HIRIS utilise les librairies **ImageManager CommonVisionBlox Version 10.2** (Stemmer Imaging) :

- Si ces librairies ne sont pas installées sur la machine, suivre toute l'installation décrite dans ce document.
- Si elles existent mais dans une autre version, elles doivent être désinstallées avant l'installation d'HIRIS.


II.2. Installation du logiciel HIRIS.

Lancer **Hiris_Setup.exe**, installeur de l'application **HIRIS** et ses documentations.

L'installeur propose les options suivantes :

- **HIRIS** (*application et librairies nécessaires à son fonctionnement*),
- **HIRIS Plugins** (*modules de Hiris*),
- **Camera Tool** (*application de paramétrages de caméras*),
- **EG** (*application du boîtier de synchronisation développé par R&D Vision*),
- **MicroFlu** (*outils de paramétrage pour les applications de microfluidiques*),
- **Batch Export** (*Application d'export de séquence par lot*),
- **DRIVERS** (*Pilotes matériels des cartes d'acquisitions, driver CVB des caméras*)

Le bouton *Détails...* permet de sélectionner les composants à installer dans chacune de ces catégories.



Toutes les librairies de **HIRIS** doivent être installées pour un fonctionnement optimal. L'installeur offre toutefois la possibilité de refuser leur installation.

Installez les drivers correspondant à votre matériel, en acceptant si possible les chemins pas défaut.

À la fin de cette installation, **veuillez redémarrer votre ordinateur**.



II.3. Désinstallation

Pour une désinstallation complète, il est nécessaire de suivre l'ordre indiqué ci-dessous à partir du panneau de configuration, ajout suppression de programmes :

- Désinstaller les drivers d'acquisition (catégorie Common Vision Blox).



- Désinstaller **HIRIS**.

II.4. Protection du logiciel et mode démo.

- **HIRIS** est protégé par une clef matérielle (parallèle ou USB) et une licence fournie par R&D Vision. L'activation du logiciel n'est possible qu'avec cette clef et la clef d'enregistrement correspondante.
- En mode démo, l'export et la sauvegarde d'images sur disque sont désactivés et les modules optionnels ont des limitations spécifiques.

II.4.1. Activation du logiciel

HIRIS ainsi que chacun de ses modules sont protégés par une clef d'activation unique qui relie votre clef matérielle à l'ordinateur sur lequel **HIRIS** doit s'exécuter.



Vous pouvez gérer l'enregistrement des licences au travers de la boîte de dialogue « **HIRIS Licences manager** » accessible depuis le menu *Help* en cliquant sur *Register*.




Sélectionnez dans la liste déroulante le module souhaité. **Le bouton Register est grisé si le produit est déjà enregistré.**

II.5. Recommandations

Au cas où la clef de protection ne serait pas détectée après l'installation, veuillez exécuter le programme d'installation du driver **Sentinel** présent dans le répertoire *Program files/Stemmer Imaging/Common Vision Blox/Dongle* (droits administrateurs requis).



III. ARCHITECTURE HIRIS





IV. FONCTIONNEMENT

IV.1. Généralités

HIRIS est une application s'articulant autour de conteneurs d'images (*Image_container ou sequence*).

Le matériel est relié à **HIRIS** via un driver universel : CVB.

HIRIS reçoit des messages de chaque driver CVB actif lui indiquant que des images sont arrivées depuis une source (caméra).

HIRIS interprète ces messages et les différentes options de chaque conteneur d'image pour organiser les données dans chaque conteneur.

HIRIS traite aussi d'autres événements provenant soit de matériels (I/O) soit de zones mémoires partagées avec d'autres programmes et applications (Ex : Camera Tool) soit des résultats de traitement d'images.

IV.2. Interface utilisateur


L'interface utilisateur d'**HIRIS** comprend une boîte de dialogue principale contenant un menu et 3 boutons.

Ceux-ci sont utilisés pour charger respectivement :

- un Projet (cf § IV.1)
- une Caméra (cf § III.2.2)
- une Séquence (cf § III.2.2)



Chaque caméra et chaque séquence est accessible via une boîte de dialogue appelée conteneur d'images et comprenant une **boîte de dialogue de contrôle** et une **zone d'affichage**. La boîte de dialogue de contrôle peut être affichée/effacée via l'appui sur la molette de la souris.





V. BOITE DE DIALOGUE PRINCIPALE

Au lancement **HIRIS** est initialisé par le fichier RDVision.ini situé dans le répertoire de l'application (par défaut C:\Program files\RDVision\Hiris).

Ce fichier d'initialisation contient un certain nombre de paramètres nécessaires au logiciel **HIRIS**.

[Common]

ConfigFile=C:\Program files\RDVision\Hiris\RDVisionUser.ini	<i>fichier projet par défaut</i>
LASTCAPTUREPATH=F:\Acquisition	<i>chemin d'acquisition des séquences</i>
LASTBINARYPATH=F:\ Acquisition	<i>répertoire des fichiers binaires</i>
LASTCAPTUREPREFIXE=Sequence	<i>préfixe des fichiers séquences</i>
LASTBINARYPREFIXE=Sequence	<i>préfixe des fichiers binaires</i>
PIV_CONFIG_INI_PATH=RDVisionPIV.ini	<i>fichier de configuration du plugin PIV</i>
[HirisPro:0:]	
MODSTREAMAVI_PREFIXE=Video	<i>paramètre du plugin avistreaming</i>
MODSTREAMAVI_PATH=C:\Program files\RDVision\Hiris\Sequence	
MODSTREAMAVI_FPS=25.00	
[SYNCHROBOX]	
MODE=0	
EXTFRAMERATE=25.00	
[AVI]	
CODEC=AVI	<i>codec par défaut pour l'export</i> (AVI = divx 3.1, WMV = Windows Media 9).

V.1. Menu Project

Un fichier projet (extension .hpj) contient les paramètres choisis pour les différents conteneurs d'image, tels que la source des images, la configuration d'acquisition des séquences, les paramètres utilisateur.

Load Last Project

Charge le dernier fichier projet utilisé.

(**Nb :** Au chargement d'un projet, il est proposé de valider l'ouverture de chaque conteneur listé dans le fichier projet.)



Load Project File (ou bouton Load Project)

Charge un fichier projet choisi par l'utilisateur.

Save Project


Sauvegarde le projet dans le fichier courant.

Save Project As

Sauvegarde le projet dans un nouveau fichier, ou un fichier existant. Ce fichier devient le projet courant.

Préférences

Donne accès à des paramètres avancés du logiciel, ces options sont valables pour toute l'application



- *Auto Load Project*

Au chargement d'**HIRIS** le dernier fichier projet sauvegardé est automatiquement chargé.

- *Absolute TimeStamp*.

Si *Absolute Timestamp* est coché, les temps mesurés pour chaque image font référence à l'horloge interne de l'ordinateur ou au référencement temporel des images fourni par la caméra. Sinon, les temps sont relatifs à l'image de déclenchement (Trigger).

Exemple d'une acquisition en pré-trigger :

Relative Timestamp		Absolute Timestamp	
Index	TimeStamp	Index	TimeStamp
0	-0.287375	0	25.166477
1	-0.229876	1	25.223976
2	-0.172375	2	25.281478
3	-0.114875	3	25.338851
4	-0.057501	4	25.396351
5	0	5	25.453851
6	0.057497	6	25.511352
7	0.115	7	25.568726
8	0.172374	8	25.626226
9	0.229875	9	25.683726

- *Sequence autofolder*.

Création d'un répertoire à chaque enregistrement de séquence sur le disque dur (mode Direct to Disk ou Direct to Files). La date et l'heure sont utilisées pour créer le répertoire au format ISO 8601 :2000: AAAA-MM-JJThh.mm.ss.

- *Image container synchronized*.

Activation du mode de synchronisation de commandes des containers d'images.(cf. chap. VII.2).

- *Share Image*.

Partage de l'image courante pour une application externe.




V.2. Menu Load



V.2.1. Chargement d'une caméra (*Load/Camera*)

Le menu *Load/New Camera* ou le bouton *camera* ouvrent une boîte de dialogue qui liste les différents drivers installés sur le PC. Les drivers sont situés dans le répertoire **C:/Program Files/Stemmer Imaging/Common Vision Blox/Drivers**.



Container name:

Le conteneur peut être nommé par rapport à un matériel spécifique (caméra) ou à son utilisation.

Description:

Un descriptif rapide du driver sélectionné est indiqué



V.2.2. Chargement d'une séquence (*Load/Sequence*)

Le menu *Load/Sequence* ouvre un navigateur pour sélectionner un fichier de séquence d'extension .seq contenant les paramètres d'une séquence préalablement enregistrée sur le disque dur.

Il est possible d'ouvrir une série d'images au format (raw, bmp, tif, png, jpg). Pour cela, sélectionnez un fichier de la série désirée puis valider. Tous les fichiers présents dans le répertoire et ayant un nom identique sont ajoutés à la nouvelle séquence. Cette action crée un fichier de séquence (.seq) qui peut être rechargé par la suite. Le format des images géré par HIRIS est le format 8,16, 24 bits.

Les vidéos au format AVI, WMV sont aussi accessibles en séquence. Les codecs utilisés lors de la génération des vidéos doivent impérativement être installés sur la station d'acquisition. Certains formats vidéo compressés ne sont pas gérés par HIRIS et peuvent créer des instabilités du logiciel.

Si l'utilisateur choisit plusieurs fichiers de séquence un message apparaît pour proposer de synchroniser toutes les séquences sélectionnées (cf. chap VII.3).




VI. LE CONTENEUR D'IMAGES

VI.1. Mode Caméra : Barre d'outils

VI.1.1. Description de la barre d'outils

La barre d'outils du conteneur contient plusieurs parties distinctes :






VI.1.2. Informations sur l'état du conteneur d'images.

Suivant le mode du conteneur (live ou acquisition) les informations sont différentes.

En mode **Live** les informations sont les suivantes :

- Résolution et dynamique de la caméra
- Cadence de réception des images par le conteneur
- Mémoire RAM disponible pour le conteneur
- Nombre d'images maximum enregistrables en mémoire RAM




La cadence de réception des images est calculée à partir des 25 dernières images reçues par le conteneur. Deux méthodes de datation des images sont implémentées, l'une utilisant les dates des images fournis par la carte d'acquisition ou la caméra (très précis et non fluctuant en fonction de l'utilisation de la machine mais disponible que sur certaines configurations), l'autre méthode utilise le temps processeur et les événements générés par le driver CVB (Précis, mais fortement dépendant de l'utilisation de la machine).

Si la cadence de réception est inférieure à la cadence de la caméra c'est qu'HIRIS ne peut pas afficher et enregistrer simultanément toutes les images reçues.

Comme l'œil humain ne « voit » qu'environ 25 i/s il n'est pas utile de demander au conteneur d'afficher toutes les images reçues (Ex : fréquence caméra > 50i/s).

Pour limiter le flux de données à afficher, HIRIS adapte automatiquement le taux de rafraîchissement des images (*Display Decimation*). Les images non affichées **ne sont pas effacées de la séquence**.

Les performances de la machine (processeur, carte graphique, carte mère, OS...) peuvent limiter les possibilités d'affichage des images en temps réels pendant leurs acquisitions.



Une ouverture du logiciel vers des applications externes est intégrée, ainsi l'image courante et le contrôle du logiciel sont partagés par un système de zone mémoire commune. Cette ouverture se déclenche par la sélection du mode d'acquisition **External** qui rend inactif un ensemble de contrôle du logiciel pour permettre à un programme externe de prendre la main (cf. chapitre VIII).

En mode **Record** les informations sont les suivantes :

- Enregistrement en cours
- État de l'enregistrement par rapport au Trigger (*Pretrigger* ou *Posttrigger*)



Le descriptif des différentes étapes de l'enregistrement par rapport à l'évènement de déclenchement de la séquence d'images (Trigger) est détaillé dans la partie VI 1.3.




VI.1.3. Réglage des paramètres d'acquisition des images.

Dans la section *Acquisition mode* on sélectionne le mode d'acquisition des images.

La séquence est définie soit par un nombre d'images, soit par une durée (en sec.) ou par des actions sur le bouton *Record* (mode Start/Stop).

La durée est calculée à partir de la fréquence réelle des images (actualiser automatiquement). La valeur par défaut est à 1 FPS. (Valeur réglable dans le fichier de configuration du logiciel Hiris.ini dans le champ DefaultFPS)




Pour un mode d'enregistrement basé sur un nombre d'images ou une durée, sélectionner dans la liste le mode *Frames* ou *Secondes* et saisir le nombre d'images ou la durée d'acquisition. Dans le 3^e mode, l'acquisition est paramétré en fonction des capacités du support d'enregistrement. Vous pouvez ensuite modifier le *Pretrigger offset* pour définir le moment de prise en compte de l'événement de *Trigger* dans la séquence.

Pour que le *Pretrigger offset* soit actif, il faut définir un événement *Trigger* (touche clavier, IO, automatique par analyse d'image comme présenté au chapitre VI 1.4.).


Le *Pretrigger offset* est utilisé pour conserver un certain nombre d'images avant l'arrivée de l'événement *Trigger*. Tant que l'événement n'est pas reçu, l'acquisition boucle sur la durée définie par le *Pretrigger offset*.

La figure ci-dessous présente l'utilisation du mode *Pretrigger* et du *Trigger* automatique dans une ROI pour l'enregistrement d'une séquence d'images en vidéo rapide (200 images/sec).



Nb : Un offset au maximum correspond à garder toutes les images qui ont précédé l'événement Trigger.

VI.1.4. Utilisation des *Trigger*




Cette boîte de dialogue permet de définir les évènements de déclenchement des acquisitions d'images (Trigger). Le *Trigger* peut être matériel (I/Os), logiciel (analyse d'image) ou sur ordre de l'utilisateur (appui d'une touche du clavier).

- Behaviour

Il s'agit de la réception par le système d'un événement extérieur conditionnant le début d'enregistrement :

- **Freerun**: Attente d'événement désactivée. Dès que le bouton *Record* est appuyé, l'acquisition commence.
- **Single**: L'évènement est reçu une fois. Tout événement ultérieur n'est pas pris en compte avant la fin de la séquence en cours.







- Burst Mode

Si le logiciel **Camera Tool** est disponible (voir liste du matériel supportant cette option), ce mode permet d'acquérir des séries d'images dont le début est validé par un signal extérieur.

- Source

- Key : La touche « T » du clavier génère l'événement de trigger.
- Hard : Le basculement d'une IO via un signal TTL déclenche l'acquisition de la séquence. Cette fonctionnalité est disponible directement via certaines caméras (Input2 pour les caméras AVT) ou certaines cartes IO (nous consulter).
- In Image : Tout changement d'intensité de l'image dans une ROI constitue l'événement de déclenchement.
 - *Settings* permet de sélectionner dans l'image la zone active du trigger (ROI) ainsi que la sensibilité du déclenchement. Il peut être changé en live pour vérifier le comportement du témoin de trigger. (Vert si trigger reçu).



Dans ce mode, la ROI est visible en rouge (option *show ROI on image*) dans le conteneur d'images. Dans le mode Start/Stop, il est possible de définir une zone pour le démarrage de l'acquisition et une 2^e zone pour l'arrêt de l'acquisition. Pour cela, sélectionnez le type de zone à définir puis choisissez sur l'image la zone désirée, puis changez de type et recommencez l'opération.

Le seuil sélectionné est le pourcentage de changement de variance dans la ROI entre deux images successives.

(Exemple Chap. VI.1.3. avec mode pre-trigger)

- Synchro


- Indépend. : Chaque conteneur d'image attend son propre événement de déclenchement.
- Master : Le conteneur maître écoute l'événement *Trigger* et dès réception débute son enregistrement ainsi que celui des conteneurs esclaves.
- Slave : Les conteneurs attendent le signal de déclenchement de l'enregistrement de la part du conteneur maître (*Master*).

Le logiciel **Camera Tool** offre beaucoup de fonctionnalités complémentaires pour la gestion d'événements de déclenchement et l'interaction entre des matériels (caméra, carte d'acquisition, carte IO,...) et **HIRIS**.



VI.1.5. Enregistrement d'une séquence d'image.

Les paramètres d'acquisition (nombre d'images, *PretriggerOffset*) sont validés avant l'acquisition par l'appui sur le bouton *Valid*.




Différents destinations d'acquisition sont possibles, soit en mémoire RAM ou soit directement sur les disques durs. Dans la fenêtre *Setup*, différents modes sont disponibles : *RAM*, *Direct to Disk*, *Direct to Files*. Le premier mode enregistre les images dans la mémoire vive de la station d'acquisition, les deux autres modes enregistrent sur le disque. Pour une acquisition directement sur le disque dur assurez-vous des performances suffisantes de votre matériel pour ne pas perdre d'images.


Dans le cas d'acquisition des images directement sur le disque dur une fenêtre de sélection de destination des fichiers d'enregistrement s'affiche.

Dans le cas d'une utilisation en mode *Direct to Disk*, pour des raisons de performances d'écritures sur disque, les images sont stockées sans compression, ni perte d'image ou de qualité dans des fichiers binaires de 128Mo (.bin). Dans ces conditions, il est préférable d'enregistrer des séquences courtes ou comprenant des petites quantités de données en RAM pour éviter de trop vite saturer les disques d'acquisition et de réduire ainsi leurs performances.

Un fichier .seq (fichier texte) *Sequence Data* regroupe les informations nécessaires à la relecture de la séquence.



En cas d'enregistrement sur disque en mode *Direct to Files* le choix du type de fichier s'effectue par l'intermédiaire de la liste déroulante. Les différents types de format de sorties sont : RAW, BMP, JPG, TIFF, PNG. **Ce mode de fonctionnement peut provoquer des pertes d'images en fonction des performances de la station d'acquisition.**



Après validation des paramètres d'acquisition, l'enregistrement peut commencer en appuyant sur le bouton *Record*. L'enregistrement peut être mis en pause (*Pause*) ou stoppé (*Record*).



VI.1.6. Bouton *Setup*



Cette boîte de dialogue permet d'accéder à des paramètres supplémentaires pour la configuration d'**HIRIS**.

Image Destination: Indication du mode d'acquisition en cours (*RAM*, *Direct to Disk*, *Direct to Files*).

Container Name: Modification du nom donné au conteneur d'images en cours.

Camera Framerate: Cadence d'acquisition utilisée comme base de temps. Le bouton *Get* extrait cette valeur de la dernière utilisation du Live³.

Player Framerate: Vitesse de relecture de la séquence dans le player.

Display Decimation: Information du taux de rafraîchissement des images affichées. (Réduction de la charge processeur dédiée à l'affichage).

Frames decimation: la fonction de décimation permet d'enregistrer des images à une cadence inférieure de la cadence caméra et ce sur une période définie par un nombre d'images ou un événement.

Frame Rate: Cadence d'acquisition



Décimation: nombre d'images ignorées lors de l'acquisition.

Resulting Frame Rate: cadence d'enregistrement avec la décimation active

Start Decimation mode / Stop Decimation mode: sens de la décimation. Si vous voulez arrêter la décimation sur un événement (I/O ou nombre d'images *Image count*) utilisez les informations dans *Stop décimation mode*. Si vous indiquez *None* alors la décimation sera conservée sur toute la séquence. (I/O : même entrée que celle gérée pour le déclenchement *Hardware Trigger* (Ex : Input 2 sur les caméras AVT)).

Image count: nombre d'images pour activer la décimation.

Les fonctionnalités de *Time-lapse* sont utilisées pour programmer une acquisition d'image à des intervalles de temps réguliers.




³ Le calcul est réalisé sur les 10 dernières images.



Driver Properties: Cette boîte de dialogue est gérée directement par CVB. Un certain nombre de paramètres ne sont pas utiles pour **HIRIS** et peuvent même rendre instable l'application. Nous vous conseillons de ne modifier que les paramètres situés dans les onglets *Image Rectangle*, *Select Camera* et *Select Board*.

General:

Dans cet onglet est listé les options et les possibilités du driver CVB utilisé. La propriété IGrab2 indique que le temps des images est fourni par la carte d'acquisition ou la caméra.



Trigger:

Certaines cartes d'acquisition peuvent déclencher la prise d'image des caméras. Cette fonction passe par un mode particulier du driver qui est activé en sélectionnant les options *Trigger on field* ou *Frame Reset / Restart*.





Image Rectangle:

Dans cet onglet vous pouvez définir la zone de l'image que vous souhaitez conserver à l'acquisition d'image. Les dimensions indiquées ne sont pas directement paramétrées au niveau de la caméra, mais uniquement pour l'acquisition.







Ces réglages doivent suivre une procédure précise :

Régler la largeur (*Width*), cliquez sur *Set New Size* puis sur appliquer.

Régler la hauteur (*Height*), cliquez sur *Set New Size* puis sur appliquer.



Régler la position de la zone (*Left* et *Top*), cliquez sur *Set new Offset*, validez en cliquant sur appliquer.



A la fermeture de la fenêtre (en cliquant sur *OK*), l'ensemble des données de la caméra sont mises à jour. Cette méthode de fenêtrage de l'image peut accélérer la cadence de la caméra. Cette option n'est pas disponible pour toutes les caméras ou tous les drivers CVB.


Select Camera :

Si plusieurs caméras sont connectées sur la même carte ou le même contrôleur d'acquisition d'images vous pouvez choisir la caméra associée au conteneur via le bouton *Current Port* situé dans la partie *ICameraSelect 2 properties*.




Select Board :

Si vous possédez plusieurs cartes ou contrôleurs d'acquisition d'images vous pouvez aussi choisir lequel est relié au conteneur (*IBoardSelect2 Properties*).





Lors d'un second chargement successif du même driver vous aurez un message vous indiquant que vous devez changer de Port (caméra ou carte) pour éviter des conflits entre deux conteneurs d'images reliés à la même source. Les onglets *Select Board* et *Select Camera* sont utiles dans ce cas.



Reset Grabber : Lors du clic sur ce bouton, une fenêtre d'avertissement s'affiche :



Cette fonctionnalité recharge le conteneur d'image en cours, ce qui provoque un rechargeement du driver CVB. Toutes les données en cours seront perdues. La modification de certains paramètres des cameras réalisée par le logiciel Caméra Tool nécessite l'utilisation de cette fonction. **Attention : son utilisation peut malgré tout provoquer des instabilités.**




: Ce bouton sauve la configuration du conteneur d'images dans le fichier de projet par défaut (C:\Program files\RDVision\Hiris\RDVisionUser.ini).




VI.1.7. Player

Les outils du *Player* permettent de se déplacer dans la séquence enregistrée.



- : Début / Fin de la séquence (flèches haut/ bas)
- : Recul / Avance image par image (flèches gauche / droite)
- : Lecture / Pause
- : Affichage de l'image correspondant à l'événement de Trigger
- Step** : incrément de lecture (peut être négatif)



Les outils dessous la barre de *Player* sont très pratiques pour se déplacer dans une grande séquence. Le trait rouge indique le moment de l'événement de déclenchement (*Trigger*) de l'enregistrement de la séquence.



La sélection de la plage d'images que vous voulez visualiser s'effectue avec les curseurs à gauche et à droite.



Vous pouvez déplacer cette partie de la séquence en cliquant entre les deux flèches et en déplaçant cette zone.



Ensuite vous pouvez vous déplacer précisément dans la plage d'image sélectionnée avec le curseur jaune.



VI.1.8. Sauvegarde des images



Sauvegarde d'une séquence d'images :

Nb : Cette fonction est désactivée en mode démo.


Sauvegarde sur disque la séquence au format TIFF (8-16 bits), RAW, BMP, JPEG ou AVI, en choisissant l'emplacement, le nom du fichier et les paramètres d'indexation. La sauvegarde peut être entière ou partielle (par saut d'images).

Dans le cas d'acquisitions d'images par couple, la fonction *PIV Mode* permet d'ajouter un suffixe A ou B aux noms de fichiers, pour les identifier.

Le format AVI sauvegarde les images sous forme d'une vidéo. Le codec de compression est choisi de manière interactive, au moyen d'une boîte de dialogue qui s'affiche lors de l'export de la séquence. La fréquence de lecture est définie dans la partie *Playrate(fps)*.

Plusieurs formats sont possibles pour l'export des images : BMP, TIFF, TIFF 8bits (dynamique de l'image redéfinie sur 8 bits), RAW, PNG ou JPEG.

Le format RAW sauvegarde les données brutes sur le disque. Chaque fichier contient une entête de 8 octets indiquant respectivement la largeur, la hauteur, le nombre d'octets utilisés par pixels et le nombre de bits par pixels de l'image. Il est surtout utilisé pour sauvegarder des images de dynamique supérieure à 8 bits sans perte de donnée. Dans ce format, les images sont sauvegardées sans aucune modification (LUT, Bayer, Rotation).



L'option *Save as displayed* sauvegarde l'image comme elle est représentée dans l'affichage du conteneur.

L'option *ROI only* sauvegarde uniquement la région d'intérêt.

Le commentaire apparaît dans le fichier contenant les *TimeStamp* si la case est cochée. Les données temporelles sont au format csv (« comma separated values »), directement lisibles dans Excel ou dans un éditeur de texte.




Sauvegarde Image

Nb : Cette fonction est désactivée en mode démo.

Sauvegarde l'image courante dans un fichier. Une fois, la sauvegarde de l'image réalisée, elle active une option d'enregistrement semi-automatique par la touche ESPACE. Le nom des fichiers est automatiquement indexé, le formalisme est le suivant : *nomdufichier_xxxxx.ext*. *xxxxx* est l'index de l'image, *ext* l'extension du fichier. L'image sauvegardée est toujours l'image qui est affichée.



VI.1.9. Onglet Plugins



Depuis cet onglet vous avez accès aux modules d'**HIRIS**.

Modules matériels : *Hardware Tools*

Liste les modules Hardware disponibles.
(Voir documentations spécifiques.)


Modules de traitement : *Processing Tools*

Liste les modules Software disponibles.
(Voir documentations spécifiques.)

En sélectionnant un élément des listes affichent un descriptif rapide de la fonction du module. L'activation du module s'effectue par un clic dans la case en face du nom du module.



VI.2. Mode Séquence : Barre d'outils



Dans ce mode, le conteneur d'images affiche les images de la séquence sélectionnée dans le menu principal. Les boutons qu'il contient et la barre d'outils située en haut du conteneur proposent des fonctionnalités similaires à celles du mode caméra et décrites précédemment.

VI.2.1. Informations générales

Les informations générales relatives à la séquence chargée sont affichées : taille des images, nombre de bits par pixel, nombre d'images total, fréquence et durée de l'acquisition (-*1.000 s length* si cette valeur n'est pas disponible).

Le numéro et l'heure d'acquisition relativement à la première image de la séquence sont affichés dans les parties *Image* et *Time*.

VI.2.2. Player


Le player proposé ici est similaire à celui décrit au paragraphe VI 1.7.

VI.2.3. Export de la séquence


(voir paragraphe VI 1.8.)



VI.3. Fonctionnalités des boutons de la zone d'affichage du conteneur d'images



VI.3.1. Display



Display setup : La mise en page de l'image intégrant les LUTs, les orientations, les overlays, la calibrations peut être sauvegardée ou chargée. Les boutons Load/Save sont prévus à cet effet.

L'outil d'export automatique **BatchExport** peut exploiter ces fichiers pour générer des exports avec une/des mise(s) en page utilisateur.


Cette boîte de dialogue permet de modifier l'apparence de l'affichage, 2 fonctionnalités sont disponibles :

Orientation : Réalise des rotations ou symétrise l'affichage des images. Les images ne sont pas modifiées, seules leurs représentations.

Overlay : Ajout d'informations graphiques sur les images (n° d'images, temps, texte, formes géométriques,...).

Overlay disponibles :


- Timestamp (texte).
- N° d'image (texte)
- Texte utilisateur.
- Rectangle.
- Cercle.
- Courbe.
- Croix.
- Etalon.
- Image (BMP).






Procédure de mise en place des overlays :


Cliquer sur le bouton *Display*, sélectionner l'onglet *Overlay*. La fenêtre suivante s'affiche :



- Sélectionner l'overlay désiré soit en cliquant sur les boutons *Timestamp/Image/User* ou en choisissant le type de forme géométrique (*Rectangle/Circle/...*)
- Le bouton *Define position* s'active, il autorise le positionnement de l'overlay sur l'image. Lorsqu'on clique sur ce bouton une fenêtre s'affiche :




En acceptant, il est possible de placer sur l'image la position ou la taille de l'overlay.






- Dès que la position est définie le bouton *Add* s'active, en cliquant sur ce bouton on ajoute l'overlay à la liste des overlays à afficher :



Il est possible de modifier les propriétés de l'overlay (couleur, label, remplissage,...). Les modifications ne sont prises en compte qu'après avoir valider avec le bouton *Modify*.

Une fois l'ensemble des overlays défini le bouton *Apply* active l'incrustation dans l'image. Tant que ce bouton est actif les overlays sont rafraîchit et incrustés dans l'image. L'export des images contenant ces overlays est alors possible.

VI.3.2. Look Up Table (LUT)



L'affichage via une LUT fait correspondre à une valeur numérique d'un pixel une valeur d'affichage.

Les choix proposés dans cet onglet permettent de modifier l'affichage de l'image courante sans modifier les valeurs des pixels des images acquises. L'utilisation d'une LUT adaptée permet souvent de distinguer des détails lors de la phase de réglage.

Attention : la LUT ne modifie pas l'information contenue dans les images, mais aide seulement à mieux visualiser les images.

Nb : Ces fonctions ne sont pas disponibles pour les images couleur.


HIRIS gère les LUT au niveau d'une ROI ou bien de toute l'image.

Pixel Value indique la valeur du pixel défini par la position courante de la souris dans l'image.



Il existe deux types de LUT : les LUT statiques et les LUT dynamiques. Une LUT statique est définie quel que soit l'image en mémoire. Une LUT dynamique est actualisée à chaque image.




Stretch : Étire la dynamique des images de plus de 8bits pour une visualisation sur 256 niveaux de gris à l'écran. (LUT statique active seulement pour les images > 8 bits)




Spectrum : Utilise une table du bleu (minimum) au rouge (maximum) en passant par le vert et représentant le spectre visible. Cette LUT statique est utile pour afficher les images de dynamique supérieure à 8 bits.




Threshold : Les pixels dont la valeur est comprise entre les 2 seuils (min/max) sont affichés en bleu sur l'image (LUT statique). L'utilisation simultanée de l'histogramme facilite les réglages de cette LUT.






User Defined: Dans ce mode deux types de LUT utilisateur sont disponibles. La première consiste à modifier les points d'infexion du graphe (triangles de couleur). Ces valeurs peuvent être sauveées et restaurées via les boutons *Load* et *Save*. (LUT statique).

Les images ci-dessous présentent l'effet de l'application d'un *LUT user* pour la visualisation d'images 10 bits.



L'appui sur le bouton *Advanced* affiche une boîte de dialogue contenant un graphe représentant en abscisse les niveaux de gris de l'image et en ordonnée leur couleur d'affichage en fausse couleur (valeurs normées entre 0 et 1).



Les boutons *ADD* / *REMOVE* sont utilisés pour ajouter ou supprimer des points de référence.

Le bouton *RESET* efface tous les points.


Il est possible de charger et sauvegarder une LUT sous la forme d'un fichier excel (*LOAD* / *SAVE*).

La case *Gray lut* génère une lut en niveau de gris.


5% 95%: Cette LUT est dynamique. Elle est très utile pour adapter l'affichage à des conditions d'éclairement médiocres ou changeantes.

Le calcul consiste à extraire sur la ROI, le min et le max des niveaux de gris et ensuite répartir la dynamique d'affichage sur 256 niveaux de gris avec un affichage à 0 (noir) des pixels en dessous du (min + 5% de la dynamique) et à 255 (blanc) des pixels supérieurs au (max - 5% de la dynamique avec dynamique = max - min)


Les images ci-dessous présentent l'effet de l'utilisation de la LUT 5% 95%.



Saturation : La LUT saturation affiche en bleu les pixels possédant un niveau de gris à 0 et en rouge les pixels dont le niveau de gris est égal au maximum de la dynamique. Cette LUT statique est utile pour voir si les conditions de prise d'image sont optimales et si le capteur n'est pas surexposé.





Negative : Affichage inversé des valeurs de niveaux de gris de l'image.





Contrast: Les pixels dont le niveau de gris est compris dans l'intervalle [min/max] spécifié par l'utilisateur sont ré-échantillonnés sur la plage totale de niveaux de gris affichés (256 niveaux=NMax). En dessous de cet intervalle, les pixels sont affichés au minimum (noir = 0) et au dessus, ils sont affichés au maximum (blanc = 255). Cette opération peut être illustrée par la courbe suivante :






VI.3.3. Décodage BAYER (Look Up Table)



Le décodage Bayer est une opération qui transforme une image en niveaux de gris en image couleur. Cette opération est réalisée sur des capteurs possédant une matrice de Bayer pour générer l'information couleur (filtres colorés rouge/vert/bleu devant les pixels).

Certaines caméras possèdent des composants électroniques qui réalisent le décodage Bayer. Dans ces conditions les images arrivant vers **HIRIS** sont en couleurs et représentent trois fois plus d'information que les images en niveau de gris avant le décodage Bayer. Le bus de donnée transitant les images possède un débit maximum qui implique souvent une diminution de la cadence d'image de la caméra vers le PC lorsque les images sont en couleurs par rapport à des images monochromes. Pour éviter de limiter les performances de la chaîne d'acquisition, le décodage Bayer peut être réalisé directement par **HIRIS** lors de l'affichage des images. L'utilisateur choisit la géométrie du décodage Bayer qui doit être le même que l'implantation des filtres colorés sur le capteur. Les images sont enregistrées sans décodage Bayer pour un maximum de performances et affichées en couleur uniquement. Pour obtenir des images en couleur, il suffit de sélectionner l'option *Bayer* lors de l'export de la séquence.

L'option *Gray bayer* transforme l'image couleur en image en niveau de gris. La sauvegarde des images dans cette configuration crée des images au format 8 bits en niveau de gris.






VI.3.4. Correction d'images CCD (Shading)

Le signal de sortie d'une matrice CCD est la somme du courant d'obscurité et de l'intensité lumineuse traversant l'optique de la caméra convertie en électrons.

Le courant d'obscurité est dû à la fois aux effets thermiques qui créent des charges et aux biais possibles dans la chaîne de conversion :



L'optique utilisé peut introduire une non uniformité d'éclairage du capteur et ainsi provoqué un effet de vignetage :



Il est aussi possible que la réponse de chaque pixel ne soit pas identique sur la matrice ou que des poussières dégradent la sensibilité des pixels :



La correction d'images ou normalisation consiste à retrouver une mesure proportionnelle à l'intensité lumineuse incidente, c'est-à-dire l'image formée sur la matrice.

Cette normalisation s'effectue en appliquant des traitements de soustractions et de compensation de la sensibilité :

$$I_N(i, j) = \frac{I(i, j) - I_0(i, j)}{I_{FF}(i, j) - I_0(i, j)}$$

I_N = Image normalisée.

I = Image brute.

I_0 = Image de fond (dark).

I_{FF} = Image de fond uniforme (Flat field).




La procédure de correction des images se fait en 2 étapes :

Prise d'une image d'obscurité:

Obturer l'optique de la camera. Régler le temps d'exposition que vous souhaitez utiliser.

Dans la fenêtre de *LUT* Cliquer sur la case *Remove dark*

Des boutons s'affichent en dessous, *L* pour charger une image d'obscurité, *S* pour sauvegarder l'image courante du container d'image comme image de noir, *Get* pour acquérir l'image en cours et l'utiliser comme image de noir.



Tant que la case *Remove dark* est cochée la correction s'applique.

Prise d'une image en éclairage uniforme :

Eclairer le capteur de la camera par une source de lumière uniforme (sphère intégrante, écran diffuseur,...). Les niveaux de gris des pixels ne doivent pas être saturés.

Dans la fenêtre de *LUT* cliquez sur la case *Flat field*




Des boutons s'affichent en dessous, *L* pour charger une image de fond uniforme, *S* pour sauvegarder l'image courante du container d'image comme image de fond uniforme, *Get* pour acquérir l'image en cours et l'utiliser comme image de fond uniforme.

Tant que la case *Flat field* est cochée la correction s'applique.



VI.3.5. Calib. (Calibration spatiale).


La fonction de calibration spatiale offre la possibilité de transformer les coordonnées pixels de l'image en coordonnées réelles liés au système de prise de vue.



La calibration est définie par l'intermédiaire d'un modèle, de points de contrôles dans l'image et leurs coordonnées réelles.

Modèles : Différents modèles sont intégrés dans le logiciel. Chacun correspondant à une configuration géométrique.

- **Modèle de transformation affine à 2 points :** Calibration ne prenant en compte que le grandissement optique. Ce modèle nécessite 2 points dans l'image et la distance réelle correspondante à l'écart entre les 2 points.




Le calcul des coordonnées réelles est:

$$X_{\text{réel}} = G * X_{\text{pixel}}$$

$$Y_{\text{réel}} = G * Y_{\text{pixel}}$$

Avec une origine des coordonnées images située au coin en haut à gauche de l'image.

- **Modèle de transformation affine à 3 points :** Calibration prend en compte à la fois le grandissement ainsi que la rotation du repère réelle par rapport à la caméra. Ce modèle nécessite au minimum 3 points et leurs coordonnées réelles. Une matrice de passage des coordonnées image aux coordonnées réelles est déterminée avec l'ensemble des points définis (méthode de résolution : moindre carré).






Le calcul des coordonnées réelles est donc :

$$X_{\text{real}} = A * X_{\text{pixel}} + B * Y_{\text{pixel}}$$

$$Y_{\text{real}} = C * X_{\text{pixel}} + D * Y_{\text{pixel}}$$

- **Modèle perspective** : Calibration prenant en compte les effets de perspective due à une configuration de la chaîne optique non coplanaire. Ce modèle nécessite au minimum 4 points et leurs coordonnées réelles (idéalement décrivant un trapèze).



La transformation perspective est une homographie cette transformation peut être mise sous la forme d'une matrice 3x3 (méthode de résolution : back-projection error minimization).

$$X_{\text{real}} = H_{00} * X_{\text{pixel}} + H_{01} * Y_{\text{pixel}} + H_{02}$$

$$Y_{\text{real}} = H_{10} * X_{\text{pixel}} + H_{11} * Y_{\text{pixel}} + H_{12}$$

Sélection des points :

En mode **Manual**, les points sont définis par l'utilisateur en cliquant sur l'image.

En mode **Pattern recognition**, un certain nombre de motifs sont disponibles pour définir les points de contrôle. Ces motifs sont recherchés dans l'image pour définir les points de contrôle.



Dot : recherche de point dans l'image, ces points peuvent être soit blanc ou noir.



Cross : recherche de croix dans l'image, ces croix peuvent être soit blanches ou noires.




Chessboard : recherche des intersections dans un motif de type damier.



Custom pattern : Recherche de motif défini par l'utilisateur dans l'image.

En mode **User file**, les points sont lus à partir d'un fichier utilisateur avec un formalisme spécifique.

Une fois les points entrés, l'utilisateur doit donner les coordonnées des points dans le repère réel dans la zone de saisie des points de contrôle (Xr,Yr) :






Les points sont repérés par un indice, des coordonnées en pixels (X_i, Y_i) et des coordonnées réelles (X_r, Y_r). La zone des coordonnées réelles est éditable par l'utilisateur pour entrer leurs valeurs.

N°	Xi	Yi	Xr	Yr
0	704	397	0	0
1	1353	240	50	0
2	607	6	0	30


→


La sélection du point courant est indiquée en verte sur les labels des points sur l'image.



Une fois l'ensemble des points définis (coordonnées images et réelles) la calibration peut être calculée.

Le clic sur le bouton *Apply calibration* désactive les contrôles de configuration des points et active l'affichage des coordonnées réelles dans la barre d'informations sous l'image. Tant que ce bouton est activé les informations de positions réelles sont disponibles dans le **conteneur d'images**.





Il est possible de sauvegarder et de recharger des calibrations par l'intermédiaire du menu *File*.




VI.3.6. Tools

Ensemble d'outils d'analyse d'images, les fonctions d'histogramme et de tracé de profil de pixels sont pour le moment disponible.

VI.3.6.1. Histogram

L'histogramme de la ROI sélectionnée (ou son inverse) est affichée en temps réel.



Log

Affiche les valeurs de l'histogramme avec un axe des Y logarithmique, pour une meilleure visualisation des écarts importants.

Statistiques

Affiche des statistiques courantes sur la ROI utilisée ou sur l'image entière :

- Taille de la ROI (**Roi size**).
- Nombre total de pixels de la ROI. (**Count**).
- Effectif de la ROI en % compris entre les deux seuils. (**Count Thresh**).
- Minimum Value & Maximum Value de la ROI (**Min Max**).
- Moyenne (**Mean**).
- Ecart Type (**StdDev**).

Des options de sauvegardes sont disponibles. Le choix des données sauvegardées est sélectionnable par les cases en bas de l'interface. Les données de sorties qu'il est possible de sauver sont : l'image du graphique (**Graph**), les données du graphiques (**Data**), l'entête des données (**Header**), des calculs statistiques (moyenne, écart type, min, max) (**Stats**).


VI.3.6.2. Profile

Différents mode de tracer de profils sont disponible.

Line : Affiche le graphique de la valeur des pixels sur la ligne de pixels sélectionnée sur l'affichage de l'image.

Des informations statistiques sont affichées sous le graphique :


- Position et niveau courant du pixel repéré par la croix rouge sur l'image.
- Niveau minimum, maximum, moyen et l'écart type.



Les données des ces profils peuvent être sauvées (mêmes options que la sauvegarde des données de l'histogramme).



Projected area : Affiche le graphique des valeurs du cumul des pixels sur chaque ligne et chaque colonne d'une zone sélectionnée sur l'image. Cette fonction peut être utile pour évaluer la non uniformité d'éclairage ou un vignettage de l'optique.




Des informations statistiques sont affichées sous le graphique :

- Position et cumul horizontal et vertical de la ligne sélectionnée.
- Cumul minimum, maximum, moyen et l'écart type de la zone sélectionnée.

Les données des ces profils peuvent être sauvegardées (même option que la sauvegarde des données de l'histogramme)

3D area : Affiche une représentation 3D de la zone sélectionnée.




Dans ce mode, seul l'image du graphique peut être sauve.




VII. SYNCHRONISATION DES CONTAINERS D'IMAGES.

Lors de l'utilisation de plusieurs container, il est possible de piloter tous les containers à l'aide d'un seul panneau de commande. L'ensemble des actions réalisées sur un des containers est répercuté sur les autres. L'activation de cette fonctionnalité s'effectue par l'option *Synchronized image container* dans les préférences d'**HIRIS** (cf. chap. V.1) pour les cameras. Pour les séquences, il faut sélectionner les séquences que l'on souhaite synchroniser lors de la sélection des séquences (un message s'affiche pour demander si l'on souhaite la synchronisation).



VII.1. Menu de synchronisation des containers.

Un menu est accessible lors d'un clic droit sur le bandeau supérieur du container :



Master : le container courant pilote tous les autres containers.

Slave : container piloté par un master, désactive et cache le panneau de commande du container correspondant.

Lock : bloque les possibilités de changement de status des containers, cache le panneau de commande.


Unlock : débloque les possibilités de changement de status et réaffiche le panneau de commande du container.

Hide control : cache le panneau de contrôle des containers.




VII.2. Synchronisation des containers de caméras.

A l'ouverture des cameras, les containers ne sont pas synchronisés, un clic droit sur le bandeau au dessus de l'image affiche un menu pour sélectionner le type de synchronisation.



Cliquer sur master pour le container que vous souhaitez. Puis sur slave pour les autres, leur panneau de contrôle disparait.




Toutes actions sur le panneau maître se répercutent sur les autres containers.
Ainsi lors de l'enregistrement, les séquences sont sauvegardées dans le même répertoire.

A tout moment il est possible de modifier la configuration pour changer de maître ou d'esclave ou bien recalier les séquences lors de la lecture des séquences enregistrées.



Exemple de recalage de séquences désynchronisées :


Soit 2 séquences acquises en mode Maître/Eclave (Illustration même numéro d'image) :



- Caler le numéro de l'image définissant un T0 de la séquence :



- Sélectionner dans le menu des containers esclaves l'option *Unlock*.



- Réglér sur chacun des containers l'image correspondant au T0 :




- Rebloquer le ou les containers esclaves avec le menu (*Lock*) :




Les boutons next/previous et play laissent la possibilité de parcourir la séquence en restant synchrone. Les boutons retour à zéro ou fin désynchronisent les séquences.

VII.3. Synchronisation des containers de séquences.


Pour synchroniser des séquences enregistrées sur le disque il suffit de sélectionner les séquences lors de l'ouverture.



Une fenêtre s'affiche proposant de synchroniser les séquences :



Si on accepte alors 1 seul panneau de contrôle est présent et il pilote l'ensemble des séquences ouvertes. Les séquences s'ouvrent normalement si on décline.






VIII. UTILISATION DU MODE EXTERNAL D'HIRIS ET CONTROLE DE L'APPLICATION PAR DES APPLICATIONS TIERCES.

VIII.1. Mode EXTERNAL.

Le logiciel **HIRIS** propose des zones mémoires partagées qui donnent à une application externe un contrôle partiel sur HIRIS (cf. Chap III : Architecture d'HIRIS, partie Shared Memory et plugins).

Pour activer ce mode, il suffit de cocher la case *External* dans le *Setup* du container d'images :



Le logiciel bloque alors les contrôles du panneau de commande d'acquisition et lance un processus qui va contrôler les zones de partage.

Il est possible d'effectuer les actions principales suivantes :

- Démarrage de la réception des images.
- Arrêt des images.
- Préparation de l'enregistrement.
- Enregistrement d'une séquence.
- Lecture de la séquence.
- Enregistrement de l'image courante.

Ce mode de fonctionnement est compatible avec l'ensemble des programmes développés sous environnement Windows (C/C++, Java, Matlab, Labview, ...).

Un certain nombre d'applications utilisant ce principe ont été développées :

- Automate d'HIRIS.
- Batch Export.
- Logiciels dédiés (acquisition synchronisée par GPS, Odomètre,...).

Pour tout renseignement et informations sur ce fonctionnement n'hésitez pas à nous contacter.



IX. RACCOURCIS CLAVIER ET UTILISATION DE LA SOURIS.

IX.1. Utilisation des raccourcis clavier.

Un certain nombre d'actions sont possibles par l'intermédiaire des touches claviers :

T : Trigger d'enregistrement de séquence.

Espace : Sauvegarde l'image courante en incrémentant le nom du fichier. (cf. Chap VI.1.8.).

Haut : Affichage de la première image de la séquence.

Bas : Affichage de la dernière image de la séquence.


Gauche : Affichage de l'image précédente dans la séquence.

Droite : Affichage de l'image suivante dans la séquence.

P : Lancement de la lecture de la séquence.

IX.2. Utilisation de la souris.

Le **bouton droit** de la souris permet de sélectionner une zone sur l'image et ainsi définie les ROI pour les LUTs ou les calculs d'histogramme et de profils.





Un double clic bascule l'affichage de l'image en mode plein écran. Un deuxième double clic restore l'affichage.

Le bouton du milieu sert à cacher le panneau de contrôle de la caméra (clic) ou bien à zoomer sur l'image (molette).



Le bouton gauche de la souris actionne le zoom lors d'un maintien du bouton (affichage d'une loupe à la place du curseur). Un clic rapide dézoomé l'image. Par l'intermédiaire d'un clic dans la barre d'outils, il est possible d'afficher le menu du mode image container synchronisé.






X. FAQ

X.1. Problème de chargement d'une caméra.


Si vous rencontrez un message d'erreur « *Error loading image file!* », c'est que le chargement de la caméra via le driver CVB n'a pas pu s'effectuer correctement. Pour vous assurer que le problème n'est pas lié à **HIRIS** mais bien au driver CVB utilisez l'application *VCSizableDisplay.exe* située dans le répertoire *Hiris*.



Appuyez sur le bouton *Open Image* puis sélectionnez *CVB Drivers (*.vin)* dans le type de fichier.


Ensuite déplacez-vous dans l'arborescence vers le répertoire **Drivers** situé dans le répertoire **C:\ProgramFiles\Stemmer Imaging\Common Vision Blox**.

Selectionnez le driver correspondant à votre matériel puis validez votre choix en appuyant sur *Ouvrir*. Si une image apparaît dans la zone d'affichage du programme *VCSizableDisplay.exe* alors le problème n'est pas lié au driver mais à **HIRIS**. Si par contre vous obtenez le même message que dans **HIRIS** il est probable que le driver CVB de votre matériel soit mal installé.



Sur certaine configuration les problèmes d'installation peuvent provenir d'une valeur mal configurée dans la base de registre de windows. Vous pouvez vérifier cela en exécutant regedit (Démarrer/Exécuter/regedit).


Dans **HKEY_LOCAL_MACHINE / SOFTWARE / Common Vision Blox** vous avez les informations utilisées par CVB et **HIRIS** lors des chargements des drivers.



Attention, toute modification de la base de registre peut rendre instable le système. Il est préférable de réaliser les opérations de désinstallation puis installation avant d'avoir à modifier ces paramètres.



X.2. Problème de cadence d'image ou de perte d'images.



Dans la partie VI.1.2., nous vous indiquons que la cadence affichée par **HIRIS** est calculée à partir des moments d'arrivées des 10 dernières images. Si ce chiffre ne reflète pas la cadence de votre matériel, c'est que votre configuration matérielle (carte graphique/CPU) ne peut pas effectuer l'affichage de toutes les images. Dans ces conditions et compte tenu que l'œil humain ne voit pas plus de 25 i/s et pour soulager le système, une décimation de l'affichage (*Display Decimation*) est utile. Ce paramètre est modifiable dans le fichier de configuration du container courant (fichier ibc).

Les images non affichées ne sont pas perdues lors des acquisitions.

Si vous observez des pertes d'images dans une séquence il est probable que votre configuration matérielle soit trop modeste par rapport au flux d'images à traiter.

Réduire la taille de la zone d'affichage du conteneur d'images peut résoudre le problème.

Évitez de manipuler les fenêtres de Windows lors de l'acquisition peut aussi résoudre le problème.

Contactez nous pour que nous vous proposions des solutions d'optimisation en fonction de votre configuration.

Les drivers CVB utilisent un système de mise en mémoire d'un certain nombre d'images pour une meilleure gestion des flux d'images. Ce nombre d'images peut dans certains cas être réglé et ainsi améliorer les flux et limiter les pertes d'images.

Ce paramètre est situé dans les fichiers de configuration des driver CVB contenu dans le répertoire C:\Program Files\Stemmer Imaging\Common Vision Blox\Drivers.

Il s'agit de fichier ayant le même nom que le fichier VIN (driver CVB).

Exemple pour le driver AVT :

Fichier driver CVB : cvAVT1394.vin

Fichier de configuration : cvAVT1394.xini



Champ dans le fichier de configuration :


```
<integer description="Number of buffers for ring buffer" name="NumBuffer">
<value>9</value>
<default>9</default>
<min>3</min>
<max>999</max>
```

Chaque fichier de configuration a son propre formalisme, n'hésitez pas à nous contacter pour avoir des détails sur ce réglages.




X.3. Problèmes de chargement d'une séquence.

Pour optimiser le chargement de grandes séquences, une modification du formalisme des fichiers .seq a été réalisée. Si vous rencontrez un problème de chargement d'une utilisez l'utilitaire *seq2bin.exe* situé dans le répertoire *Hiris* pour transformer votre séquence au nouveau format.



Lors du chargement d'une séquence si les données relatives à cette séquence manquent, un message s'affiche :



Si la séquence n'a pas été déplacée alors cela indique que des fichiers de données sont manquants (problème de débit ou effacement des fichiers). Auquel cas choisir *Non* sur la dialogue pour actualiser les données de la séquence (repérage des images manquantes).



Si vous déplacez vos séquences sur votre disque dur vous devez spécifier les nouveaux chemins de localisation des fichiers bin dans le fichier .seq (*Bin directory* et *Bin repertoire*) par l'intermédiaire de la dialogue prévue à cette effet :



L'édition du fichier de séquence est aussi possible, l'ouvrir avec le bloc notes de windows. Modifier les 2 champs :

Bin directory=

Bin repertoire=



XI. NOTES PERSONNELLES
