





SingleGauge™, Single-Channel Measurement and Control Unit for Compact Gauges

Operating Instructions



Product Identification

In all communications with Pfeiffer Vacuum, please specify the information on the product nameplate. For convenient reference copy that information into the space provided below.



Validity

This document applies to products with part number PT G28 030.

The part number (No.) can be taken from the product nameplate.

This manual is based on firmware version 302-510-D. If your unit does not work as described in this document, please check that it is equipped with the above firmware version ($\rightarrow \blacksquare$ 58).

We reserve the right to make technical changes without prior notice.

All dimensions are indicated in mm.

Intended Use The TPG 261 is used together with Pfeiffer Vacuum Compact Gauges (in this document referred to as gauges) for total pressure measurement. All products must be operated in accordance with their respective Operating Instructions.

Scope of Delivery

The scope of delivery consists of following parts:

- 1 TPG 261 Single-Channel Measurement and Control Unit
- 1 Power cord
- 1 Connector for *control* connection
- 4 Collar screws and plastic sleeves
- 2 Rubber feet
- 1 Rubber bar
- 1 CD-ROM (Operating Instructions)
- 1 EC Declaration of Conformity
- 1 Installation Instructions
- 1 Safety Guide

Trademarks

SingleGauge™ INFICON AG FullRange™ INFICON GmbH



Contents

Product Identification Validity Intended Use Scope of Delivery Trademarks	2 2 3 3 3
 Safety Symbols Used Personnel Qualifications General Safety Instructions Liability and Warranty 	6 6 7 7 8
2 Technical Data	9
 3 Installation 3.1 Personnel 3.2 Installation, Setup 3.2.1 Rack Installation 3.2.2 Installation in a Control Panel 3.2.3 Use as Desk-Top Unit 3.3 Mains Power Connector 3.4 Gauge Connector sensor 3.5 control Connector 3.6 relay Connector 3.7 Interface Connector RS232 	14 14 14 17 18 19 20 21 22 23
 4 Operation 4.1 Front Panel 4.2 Turning the TPG 261 On and Off 4.3 Operating Modes 4.4 Measurement Mode 4.5 Parameter Mode 4.5.1 Switching Function Parameters 4.5.2 Gauge Parameters 4.5.3 Gauge Control 4.5.4 General Parameters 4.5.5 Test Parameters 	24 24 25 26 27 31 33 37 47 52 56

	05
5.1 RS232C Interface	65
5.1.1 Data Transmission	65
5.1.2 Communication Protocol	67
5.2 Mnemonics	69
5.2.1 Measurement Mode	70
5.2.2 Parameter Mode	76
5.2.2.1 Switching Function Parameters	76
5.2.2.2 Gauge Parameters	77
5.2.2.3 Gauge Control	82
5.2.2.4 General Parameters	83
5.2.2.5 Test Parameters	84
5.2.3 Example	90
6 Maintenance	91
7 Troubleshooting	92
8 Repair	93
8 Repair 9 Storage	93 94
8 Repair 9 Storage 10 Disposal	93 94 94
8 Repair 9 Storage 10 Disposal Appendix	93 94 94 95
 8 Repair 9 Storage 10 Disposal Appendix A: Conversion Tables 	93 94 94 95 95
 8 Repair 9 Storage 10 Disposal Appendix A: Conversion Tables B: Default Settings 	93 94 94 95 95 95
 8 Repair 9 Storage 10 Disposal Appendix A: Conversion Tables B: Default Settings C: Firmware Update 	93 94 94 95 95 96 97
 8 Repair 9 Storage 10 Disposal Appendix A: Conversion Tables B: Default Settings C: Firmware Update D: Literature 	93 94 94 95 95 96 97 100
 8 Repair 9 Storage 10 Disposal Appendix A: Conversion Tables B: Default Settings C: Firmware Update D: Literature E: Index 	93 94 95 95 96 97 100 103

For cross-references within this document, the symbol $(\rightarrow \square XY)$ is used, for cross-references to further documents, listed under "Literature", the symbol $(\rightarrow \square [Z])$.

1 Safety

1.1 Symbols Used

Symbols for residual risks



Information on preventing any kind of physical injury.

WARNING

Information on preventing extensive equipment and environmental damage.



Caution

Information on correct handling or use. Disregard can lead to malfunctions or minor equipment damage.

Further symbols



The lamp/display is lit.



The lamp/display flashes.



The lamp/display is dark.



Press the key (example: PARA key).



Do not press any key.

1.2 Personnel Qualifications

Skilled personnel

All work described in this document may only be carried out by persons who have suitable technical training and the necessary experience or who have been instructed by the end-user of the product.

1.3 General Safety Instructions

Adhere to the applicable regulations and take the necessary precautions for all work you are going to do and consider the safety instructions in this document.



Communicate the safety instructions to all other users.

1.4 Liability and Warranty

Pfeiffer Vacuum assumes no liability and the warranty becomes null and void if the end-user or third parties

- disregard the information in this document
- use the product in a non-conforming manner
- make any kind of interventions (modifications, alterations etc.) on the product
- use the product with accessories not listed in the corresponding product documentation.

2 Technical Data

Mains specifications	Voltage Frequency Power consumption Overvoltage category Protection class Connection	90 250 VAC 50 60 Hz ≤45 W II 1 European appliance connec- tor IEC 320 C14 (→ ≧ 19)
Ambiance	Temperature storage operation Relative humidity Use Pollution degree Protection type	-20 +65 °C + 5 +50 °C ≤80% up to +31 °C, decreasing to 50% at +40 °C indoors only max. altitude 2000 m NN II IP30
Compatible gauges	Number Compatible Compact Gauges Pirani Pirani Capacitance Cold Cathode FullRange™ CC Process Ion FullRange™ BA Capacitance Piezo	1 TPR 261, TPR 265, TPR 280, TPR281 PCR 260, PCR 280 IKR 251, IKR 261, IKR 270 PKR 251, PKR 261 IMR 265 PBR 260 CMR 261 CMR 375 APR 250 APR 267
Gauge connections	Number <i>sensor</i> connector	1 Amphenol C91B appliance connector, female, 6-pin (pin assignment →



Gauge supply	Voltage Current Power Fuse protection	+24 VDC ±5% 750 mA 18 W 900 mA with PTC element, self-resetting after turning the TPG 261 off or disconnecting the gauge. The supply con- forms to the requirements of a grounded protective extra low voltage (SELV).
Operation	Front panel Remote control	via 3 keys via RS232C interface
Measurement values	Measurement range Measurement error gain error offset error Measurement rate Display rate Filter time constant slow normal (nor) fast Measurement units Offset correction Calibration factor	depending on gauge $(\rightarrow \square [1] \dots [17])$ $\leq 0.01\%$ F.S. $\leq 0.01\%$ F.S. 50 / s 10 / s 1.2 s (f _g = 0.13 Hz) 400 ms (f _g = 0.4 Hz) 20 ms (f _g = 8 Hz) mbar, Pa, Torr for linear gauges $-5 \dots 110\%$ F.S. for logarithmic gauges $0.10 \dots 9.99$ for linear gauges $0.500 \dots 2.000$ resolution 0.001% F.S.
	A/D converter	resolution 0.001% F.S.



Switching functions	Number Reaction delay	2 ≤20 ms if switching threshold close to measurement value (for larger differences con- sider filter time constant)
	Adjustment range	depending on gauge $(\rightarrow \square [1] \dots [17])$
	Hysteresis	≥1% F.S. for linear gauges, ≥10% of measurement value for logarithmic gauges
Switching function relays	Contact type	floating changeover contact
	Load max.	30 VAC, 30 W (ohmic) 60 VDC, 1 A, 30 W (ohmic)
	Service life mechanic electric	5×10 ⁷ cycles 1×10 ⁵ cycles (at max. load)
	Contact positions	\rightarrow \cong 22
	<i>Relay</i> connector	D-Sub appliance connector, female, 15-pin (pin assignment \rightarrow 22)
Error signal	Number	1
	Reaction time	≤20 ms
	Contact type	floating normally open contact
Endi signa relay	Load max.	30 VAC, 30 W (ohmic) 60 VDC, 1 A, 30 W (ohmic)
	Service life mechanic electric	5×10 ⁷ cycles 1×10 ⁵ cycles (at max. load)
	Contact positions	→ 🖹 21
	Control connector	Amphenol C91B appliance connector, female, 7-pin (pin assignment $\rightarrow \mathbb{B}$ 21)

Gauge control	Manual via keys activation/deactivation External via <i>control</i> connector ON condition OFF condition Hotstart when mains power on Self control deactivation when pressure rises OFF threshold <i>Control</i> connector	Here $(\rightarrow \mathbb{B} \ 28, 49, 50)$ EFFE signal $\leq +0.8 \text{ VDC}$ signal $+2.0 \dots 5 \text{ VDC or input}$ open Here $(\rightarrow \mathbb{B} \ 49)$ EFFE adjustable $(\rightarrow \mathbb{B} \ 51)$ Amphenol C91B appliance connector, female, 7-pin (pin assignment $\rightarrow \mathbb{B} \ 21)$
Analog output	Number Voltage range Internal resistance Measuring signal vs. pressure <i>Control</i> connector	1 0 +10 VDC 660 Ω depending on gauge ($\rightarrow \square [1] [17]$) Amphenol C91B appliance connector, female, 7-pin (pin assignment $\rightarrow \square 21$)
Interface	Standard Protocol	RS232C ACK/NAK, ASCII with 3-character mnemonics, bi-directional data flow, 8 data bits, no parity bit, 1 stop bit
	RS232C	only TXD and RXD used
	Transmission rate	9600, 19200, 38400 baud
	RS232 connector	D-Sub appliance connector, male, 9-pin (pin assignment \rightarrow \cong 23)

Dimensions [mm]



Use

For incorporation into a rack or control panel or as desktop unit.

Weight 1.1 kg

3 Installation

3.1 Personnel



The unit may only be installed by persons who have suitable technical training and the necessary experience or who have been instructed by the end-user of the product.

3.2 Installation, Setup

The TPG 261 is suited for incorporation into a 19" rack or a control panel or for use as desk-top unit.



3.2.1 Rack Installation

The TPG 261 is designed for installation into a 19" rack chassis adapter according to DIN 41 494. For this purpose, four collar screws and plastic sleeves are supplied with it.



Guide rail

In order to reduce the mechanical strain on the front panel of the TPG 261, preferably equip the rack chassis adapter with a guide rail.



Slide rails

For safe and easy installation of heavy rack chassis adapters, preferably equip the rack frame with slide rails.



Height 3 U rack chassis adapter

• Sec

Secure the rack adapter in the rack frame.



The admissible maximum ambient temperature (\rightarrow \square 9) must not be exceeded neither the air circulation obstructed.





Slide the TPG 261 into the rack chassis adapter ...



... and fasten the adapter panel to the rack chassis adapter using the screws supplied with the TPG 261.

3.2.2 Installation in a Control Panel

STOP DANGER

DANGER: protection class of the rack If the product is installed in a control panel, it is likely to lower the protection class of the control panel (protection against foreign bodies and water) e.g. according to the EN 60204-1 regulations for switching cabinets.

Take appropriate measures for the control panel to meet the specifications of the protection class.

For mounting the TPG 261 into a control panel, the following cut-out is required:





The admissible maximum ambient temperature (\rightarrow B 9) must not be exceeded neither the air circulation obstructed.

For reducing the mechanical strain on the front panel, preferably support the unit.



Slide the TPG 261 into the cut-out of the control panel ...



... and secure it with four M3 or equivalent screws.

3.2.3 Use as Desk-Top Unit

The TPG 261 is also suited for use as desk-top unit. For this purpose, two self-adhesive rubber feet as well as a slip-on rubber bar are supplied with it.



Stick the two supplied rubber feet to the rear part of the bottom plate ...



... and slip the supplied rubber bar onto the bottom edge of the front panel.



Select a location where the admissible maximum ambient temperature ($\rightarrow \square 9$) is not exceeded (e.g. due to sun irradiation).

3.3 Mains Power Connector

STOP DANGER

DANGER: line voltage Products that are not professionally connected to ground can be extremely hazardous in the event of a fault

Connect the product according to the local regulations and ground it correctly.

The unit is supplied with a power cord. If the mains connector is not compatible with your system, use your own, suitable cable with protective ground $(3 \times 1.5 \text{ mm}^3)$.



If the unit is installed in a switching cabinet, the mains voltage should be supplied and turned on via a central distributor.



P

Pin assignment of the female 6-pin Amphenol C91B appliance connector:

3.4 Gauge Connector sensor

Connect the gauge to the *sensor* connector via a sensor cable set available from us (\rightarrow sales literature) or your own, screened (electromagnetic compatibility) sensor cable. Make sure the gauge you are connecting is compatible ($\rightarrow \blacksquare$ 9).

Pin assignment sensor



Pin	Signal	
1 6 2 3 4 5	Identification Supply Supply common Signal input Signal common Screening	+24 VDC GND (measuring signal+) (measuring signal–)

3.5 *control* **Connector** This connector allows to read the measuring signal, to evaluate the state of the floating contacts of the error relay, and to activate or deactivate the gauge ($\rightarrow \blacksquare 47$).



Connect the peripheral components to the *control* connector on the rear of the unit using your own, screened (electromagnetic compatibility) cable.

Pin assignment Contact positions *control*



A suitable connector is supplied with the TPG 261.

3.6 relay Connector

This connector allows to use the floating switching contacts for an external control system.

Connect the peripheral components to the *relay* connector on the rear of the unit using your own, screened (electromagnetic compatibility) cable.

Pin assignment Contact positions R 15 relav Pin assignment of the female 15-pin D-Sub appliance connector: Pin Signal Switching function 1 SP1 4 Pressure above Pressure below 3 threshold or power threshold 2 supply turned off Switching function 2 SP2 7 Pressure above Pressure below 6 threshold or power threshold 5 supply turned off 9 ... 14 Not connected Supply for relays with higher switching power Fuse-protected at 300 mA with PTC element, self-resetting after power 15 +24 VDC. 200 mA off or pulling the relay connector. 1 GND Meets the requirements of a 8 GND grounded protective extra low voltage (SELV).

3.7 Interface Connector RS232

The RS232C interface allows for operating the TPG 261 via a HOST or terminal ($\rightarrow \textcircled{B}$ 65). It can also be used for updating the firmware ($\rightarrow \textcircled{B}$ 97).

Connect the serial interface to the *RS232* connector on the rear of the unit using your own, screened (electromagnetic compatibility) cable.



Pin assignment RS232





4 Operation

4.1 Front Panel



4.2 Turning the TPG 261 On and Off

Make sure the TPG 261 is correctly installed and the specifications in the Technical Data are met.

Turning the TPG 261 on

The power switch is on the rear of the unit.

Turn the TPG 261 on with the power switch (or centrally, via a switched power distributor, if the unit is incorporated in a rack).



After power on, the TPG 261 ...

- · automatically performs a self-test
- identifies the connected gauge
- activates the parameters that were in effect before the last power off
- switches to the Measurement mode
- adapts the parameters if required (if another gauge was previously connected).

Turning the TPG 261 off

Turn the TPG 261 off with the power switch (or centrally, via a switched power distributor, if the unit is incorporated in a rack).



Wait at least 10 s before turning the TPG 261 on again in order for it to correctly initialize it-self.

4.3 Operating Modes

The TPG 261 works in the following operating modes:

- - General parameter group GERER for entering or displaying general parameters (→ ■ 52)

4.4 Measurement Mode

The Measurement mode is the standard operating mode of the TPG 261. Measurement values and statuses as well as the gauge identification are displayed in this mode.



ON

Turning the gauge on and off

Certain gauges can be turned on and off manually, if the gauge control is set to **HEAD** ($\rightarrow \equiv 50$).

Available for:

- D Pirani Gauge (TPR)
- □ Pirani Capacitance Gauge (PCR) ☑ Cold Cathode Gauge
- (IKR) ☑ FullRange[™] CC Gauge (PKR)
- Process Ion Gauge
- (IMR) ☑ FullRange[™] BA Gauge (PBR)
- □ Capacitance Gauge (CMR)
- □ Piezo Gauge (APR)

YAR/



- \Rightarrow Press key >1 s: The gauge is turned off. **FFFE** is displayed instead of the measurement value
- ⇒ Press key >1 s: The gauge is turned on. A status message may be displayed instead of the measurement value.



Measurement range

If the TPG 261 is operated with linear gauges (CMR 261 ... 375, APR 250 ... 267), negative pressures may be indicated. Possible causes:

- negative drift
- offset correction activated with positive offset.

Displaying the gauge identification





⇒ Press keys >0.5 s: The type of the connected gauge is automatically identified and displayed for 4 s:

Pirani Gauge (TPR 261, TPR 265, TPR 280, TPR 281) Pirani Capacitance Gauge¹⁾ (PCR 260, PCR 280)

Cold Cathode Gauge (IKR 251, IKR 261)

Cold Cathode Gauge (IKR 270)

FullRange™ CC Gauge (PKR 251, PKR 261)

Process Ion Gauge (IMR 265)

FullRange™ BA Gauge (PBR 260)

Capacitance Gauge (CMR 261 ... CMR 375)

Piezo Gauge (APR 250 ... APR 267)

No gauge connected (no Sensor)

Connected gauge cannot be identified (no Identifier)













¹⁾ TPR and PCR have identical identifiers. In the TPG 261, there is no distinction made on the display and in data evaluation, since pressure ranges of these gauges are approximately the same.

Getting to the Parameter mode





4.5 Parameter Mode The Parameter mode is used for displaying, editing and entering parameter values as well as for testing the TPG 261. For ease of operation, the parameters are divided into groups.



Selecting a parameter group



 $\begin{array}{l} \Rightarrow \ \ Switching function parameters \rightarrow \textcircled{b} 33\\ Gauge parameters \rightarrow \textcircled{b} 37\\ Gauge control \rightarrow \textcircled{b} 47\\ General parameters \\ \rightarrow \textcircled{b} 52\\ Test parameters \\ \rightarrow \textcircled{b} 56 \end{array}$

Selecting a parameter in a parameter group



Editing a parameter in a parameters group

Modifications of parameters come into effect immediately and are stored automatically. Exceptions are mentioned under the corresponding parameters.

4.5.1 Switching Function Parameters



The switching function parameter group (setpoint parameters) is used for displaying, entering and editing threshold values of the two switching functions.



The TPG 261 has two switching functions with two adjustable thresholds each. The status of the switching function is displayed on the front panel (\rightarrow 24, 21) and can be evaluated via the floating contacts at the *relay* connector.



Selecting a parameter



 \Rightarrow The name of the parameter,

e.g.: Switching function 1 lower setpoint

is displayed as long as the key is pressed or at least for 1.5 s.

Afterwards, the currently valid threshold value is displayed.





Editing the threshold value





 Press key <1 s: The value is increased/ decreased by 1 increment.

Press key >1 s: The value is increased/ decreased continuously.



ARA

We recommend setting the threshold $\frac{1}{2}$ decade above the lower or $\frac{1}{2}$ below the upper threshold limit.

Limits of the lower switching thresholds



Value

The lower switching threshold (Setpoint low) defines the pressure at which the switching function is activated when the pressure is dropping.

⇒ Gauge dependent (→ table). If another gauge type is connected, the TPG 261 automatically adjusts the switching threshold if required.

	lower threshold limit 58888	upper threshold limit 5888.6	
8 .8.8.8	5×10 ^{-4 *)}	1500	
P.E.9 .8.8	1×10-9	1×10 ⁻²	
8.6.8 .8.8	1×10 ⁻¹¹	1×10 ⁻²	
6.8.9.8.8	1×10 ⁻⁹	1000	
88888	1×10 ⁻⁶	1000	
8.8.8.8	5×10 ⁻¹⁰	1000	
8.8. 8 .8.8	F.S. / 1000	F.S.	

all values in mbar, CAL=1

*) 5×10^{-5} mbar, if PrE is activated ($\rightarrow B 46$)



The minimum hysteresis between the upper and lower switching threshold is at least 10% of the lower threshold or 1% of the set full scale value. If the value of the minimum hysteresis drops below these values, the upper threshold is automatically adjusted to a minimum hysteresis. This prevents unstable states.

ı.

Limits of the upper switching thresholds

			Va	alue	
5.8.8.8. <i>8</i>		Th (S su tio su	ne upper switching etpoint high) defir re at which the sv n is deactivated w re is rising.	threshold hes the pres- vitching func- vhen the pres-	
e.g.:	8	8	Ŷ	Gauge depender If another gauge nected, the TPG cally adjusts the required.	nt (→ table). type is con- 261 automati- threshold if
		lower threshold	limit	5 <i>P</i> 88 <i>H</i>	upper thershold limit 5886H
8 .8.8.8.8		+10%	% lo	wer threshold	1500
8.6.9 .8.8	+10	+109	% lo	wer threshold	1×10-2
8.6 .8.8.8	shold	+109	% lo	wer threshold	1×10-2
8.8.9 .8.8	threa	+10%	% lo	wer threshold	1000
88888	lower	+109	% lo	ower threshold	1000
8.8.8.8		+109	% lo	wer threshold	1000
8.8.8.8.8		+1% ra	me ang	easurement e (F.S.)	F.S.

all values in mbar, CAL=1



The minimum hysteresis between the upper and lower switching threshold is at least 10% of the lower threshold or 1% of the set full scale value. This prevents unstable states.
4.5.2 Gauge Parameters



The Gauge parameter group (**sen**sor **p**arameters) is used for displaying, entering and editing parameters of the connected gauge.



Selecting a parameter



 \Rightarrow The name of the parameter,



is displayed as long as the key is pressed or at least for 1.5 s.

Afterwards, the currently valid parameter value is displayed.

Some parameters are not available for all gauges and thus not always displayed.



*) depending on pressure

Measurement value filter

The measurement value filter permits a better evaluation of unstable or disturbed measuring signals.



The measurement value filter does not affect the analog output ($\rightarrow \square$ 21).





Calibration factor

The calibration factor allows the measured value to be calibrated for other gases than $N_2 \ (\rightarrow \ characteristic$ curves in [1] ... [13]).

Available for:

র র র র র র	Pirani Gauge Pirani Capacitanc Cold Cathode Gau FullRange™ CC (Process Ion Gaug FullRange™ BA (Capacitance Gau	e Gauge uge Gauge je ^{*)} Gauge ^{**)}	(TPR) (PCR) (IKR) (PKR) (IMR) (PBR) (CMR)	
$\overline{\mathbf{A}}$	Piezo Gauge	90	(APR)	
	*) only for pressures * **) only for pressures *	<1×10 ⁻² mb <1×10 ⁻¹ mb	bar. bar.	
		Value		
E	. 8 .8.8.8			CAL
e.ç		⇔ No c	orrection	
e.ę	88 .5 88	⇒ Meas corre of 0.1 (loga)	surement value cted by a factor 10 9.99 rithmic gauges).	

Measurement value corrected by a factor of 0.500 ... 2.000

(linear gauges).





⇒ Press key <1 s: The value is increased/ decreased by 1 increment.

Press key >1 s: The value is increased/ decreased continuously.

Measurement range (F.S.) of linear gauges

For linear gauges, the full scale (F.S.) value has to be defined according to the connected gauge type. For logarithmic gauges it is automatically recognized.

Available for:

	Pirani Gauge	(TPR)
	Pirani Capacitance Gauge	(PCR)
	Cold Cathode Gauge	(IKR)
	FullRange™ CC Gauge	(PKR)
	Process Ion Gauge	(IMR)
	FullRange™ BA Gauge	(PBR)
\checkmark	Capacitance Gauge	(CMR)
$\mathbf{\nabla}$	Piezo Gauge	(APR)

☑ Piezo Gauge



Offset correction

The offset value is displayed and readjusted according to the actual measurement value (in the range of $-5 \dots +110\%$ of the set full scale value).

Available for:

- D Pirani Gauge (TPR)
- D Pirani Capacitance Gauge (PCR)
- □ Cold Cathode Gauge (IKR)
- □ FullRange[™] CC Gauge (PKR)
- □ Process Ion Gauge (IMR)
- □ FullRange[™] BA Gauge (PBR)
- ☑ Capacitance Gauge (CMR)
- Piezo Gauge (APR)

The offset correction affects:

- ☑ the displayed measurement value
- □ the displayed threshold value of the switching functions
- \Box the analog output at the *control* connector ($\rightarrow \square 21$)

	Value
8.8.5 .8.8	OFS
8.6.6 .8.8	⇒ Offset correction deactivated
e.g.: 8.9.9 .8	⇔ Offset correction activated
PARA	⇒ Press key >1.5 s: The offset value is read- justed. The actual measure- ment value is accepted as new offset value.
PARA	⇒ Reset the offset value.





When the zero of the gauge is readjusted, the offset correction must be deactivated.

Underrange control Behavior in the event of an underrange with Cold Cathode Gauges (Penning underrange control).

Available for:

- □ Pirani Gauge (TPR)
- D Pirani Capacitance Gauge (PCR)
- ☑ Cold Cathode Gauge (IKR)
- □ FullRange[™] CC Gauge (PKR)
- Process Ion Gauge (IMR)
- □ FullRange[™] BA Gauge (PBR)
- □ Capacitance Gauge (CMR)
- □ Piezo Gauge (APR)

There is a number of possible causes of an underrange:

- the pressure in the vacuum system is lower than the measurement range
- the measurement element has not ignited (yet)
- the discharge has failed
- a defect has occurred



Caution

Caution: relay is switching

An underrange can lead to unintended reactions of the connected control system.

Prevent false control signals and messages by disconnecting the sensor and control cables.

	Value
8.8.8 .8.8	
8.6.6 .8.8	 Underrange state is interpreted as admissible measurement value. Interpreted is displayed. The switching function remains ON.
86 8.8.8	 ⇒ Underrange state is interpreted as inadmissible measurement value. ■ Instant ■ Instant
	Activate/deactivate the underrange control.
PARA	

L.

If chances are that the pressure in the vacuum system drops below the measurement range of the gauge, it is advisable to select **DEFER**.

If **CALCE** is selected, the evaluation of the switching function is suppressed for approx. 10 seconds when the gauge is turned on and each time after an underrange has occurred. During this time, the switching function remains OFF. Degas Contamination deposits on the electrode system of hot cathode gauges may cause instabilities of the measurement values. The Degas function allows to clean the electrode system.

Available for:

- D Pirani Gauge (TPR)
- Pirani Capacitance Gauge (PCR)
- □ Cold Cathode Gauge (IKR)
- □ FullRange[™] CC Gauge (PKR)
- □ Process Ion Gauge (IMR) ☑ FullRange[™] BA Gauge (PBR)
- □ Capacitance Gauge (CMR)
- □ Piezo Gauge



Pirani range extension

The display and setpoint adjustment range of the Pirani Capacitance Gauge can be extended.

Available for:

			Measurement range
	Pirani Gauge	(TPR)	
\checkmark	Pirani Capacitance Gauge	(PCR)	5×10 ⁻⁵ …1500 mbar
	Cold Cathode Gauge	(IKR)	
	FullRange™ CC Gauge	(PKR)	
	Process Ion Gauge	(IMR)	
	FullRange™ BA Gauge	(PBR)	
	Capacitance Gauge	(CMR)	
	Piezo Gauge	(APR)	





⇒ Normal operation.

⇒ Display and setpoint adjustment range extended to 5×10⁻⁵ mbar.



Activate/deactivate the Pirani range extension.

4.5.3 Gauge Control



The Gauge control group (control parameters) is used for displaying, entering and editing parameters which define the activation/ deactivation of the connected gauge.



If the connected gauge cannot be controlled $(\rightarrow \mathbb{B} 49)$, this group is not available.



Selecting a parameter



 \Rightarrow The name of the parameter,

is displayed as long as the key is pressed or at least for 1.5 s.

Afterwards, the currently valid parameter value is displayed.

Some parameters are not available for all gauges and thus not always displayed.



→ 🖹 49 50 51 Gauge activation Certain gauges can be activated by different means. The following gauges can be controlled: D Pirani Gauge (TPR) Pirani Capacitance Gauge (PCR) ☑ Cold Cathode Gauge (IKR) ✓ FullRange™ CC Gauge (PKR) Process Ion Gauge (IMR) Ø FullRange™ BA Gauge (PBR) □ Capacitance Gauge (CMR) □ Piezo Gauge (APR) Value ⇒ Manual activation: The gauge can be activated by pressing the Δ key. ⇒ External activation: Ern The gauge is activated by an input signal fed via the *control* connector ($\rightarrow \blacksquare 21$). ⇒ Hotstart: $H \cap F$ The gauge is automatically activated when the TPG 261 is turned on. Measurement is thus automatically resumed after a power failure. Gauge deactivation $\rightarrow \equiv 50$. ⇒ Increase/decrease the value by the defined increments.



Gauge deactivation

Certain gauges can be deactivated by different means.

The following gauges can be controlled:

- □ Pirani Gauge
- (TPR) □ Pirani Capacitance Gauge (PCR)
- ☑ Cold Cathode Gauge (IKR)
- ✓ FullRange[™] CC Gauge^{*)} (PKRx)
- ☑ Process Ion Gauge ^{*}) (IMR)
- ✓ FullRange[™] BA Gauge^{*)}
- □ Capacitance Gauge
- □ Piezo Gauge

(PBR) (CMRx) (APR)

*) except for self control

	Value
5.8.8.8.8	
HARBB	➡ Manual deactivation: The gauge is deactivated by pressing the key.
88888	⇒ External deactivation: The gauge is deactivated by an input signal fed via the control connector (→ [®] 21).
Additionally for Cold Cathode Gauge:	
58.8.8.B	 ⇒ Self control: The gauge deactivates itself when the pressure rises (→
PARA V	⇒ Increase/decrease the value by the defined increments.
PARA	

OFF threshold Definition of the OFF threshold for the gauge to be deactivated by itself (self control).

Available for:

- □ Pirani Gauge
- □ Pirani Capacitance Gauge (PCR)
- ☑ Cold Cathode Gauge (IKRx)
- □ FullRange[™] CC Gauge (PKR)
- □ Process Ion Gauge (IMR)
- □ FullRange[™] BA Gauge (PBR) □ Capacitance Gauge
- (CMR) D Piezo Gauge
 - (APR)



decreased continuously.

(TPR)

4.5.4 General Parameters



The General parameter group (**general parameters**) is used for displaying, entering and editing generally applicable system parameters.





Selecting a parameter



⇒ The name of the parameter



is displayed as long as the key is pressed or at least for 1.5 s.

Afterwards, the currently valid parameter value is displayed.

The parameters are available for all gauge types and thus always displayed.



Editing a parameter



⇒ Increase/decrease the value by the defined increments. Measurement unit

Unit of measured values, thresholds etc. See Appendix (\rightarrow B 95) for conversion.

	Value	
8.8.8.8.8		•••
6.8. 8.8.8	⇔ mbar/bar	mbar Torr Pa
88888	➡ Torr (only available if Torr lock is not activated i.e. Torr is not suppressed →	mbar Torr Pa
8856 8	⇔ Pascal	mbar Torr Pa

Transmission rate

Transmission rate of the RS232C interface.

	Value
6808 e.g.: 9600	 ⇒ 9600 baud 19200 baud
	38400 baud



4.5.5 Test Parameters



The Test parameter group is used for displaying the firmware version, entering and editing special parameter values, and for running test programs.



This group is only available if the key was pressed while the TPG 261 was turned on.





Selecting a parameter





⇒ The name of the parameter

e.g.: Firmware version is displayed.

The parameters are available for all gauge types and thus always displayed.



The name of the parameter is displayed as long as the key is pressed or at least for 1.5 s.

The firmware version is continuously displayed.



The name of the test program is displayed until it is started.

Editing a parameter



Available for

⇒ Increase/decrease the value by the defined increments. Starting the test program



 \Rightarrow Start test program.

Firmware version

The firmware version (program version) is displayed.

	Version
8 .8.8.8.8	
8.8.8 .8.8	The two parts of the firmware number are displayed alter- nately.
5888	
The last character indicates the modifi- cation index (-, A Z). Please mentior	

cation index (-, A ... Z). Please mention this index when contacting Pfeiffer Vacuum in the event of a problem.

Watchdog control	Behavior of the system control (watchdog) in the event of an error.		
		Setting	
	8 .8.8.8.8		
	88888	The system automatically ac- knowledges error messages of the watchdog after 2 s.	
	8.6.6 .8.8	Error messages of the watch- dog have to be acknowledged by the operator.	



Keylock

The entry lock function prevents inadvertent entries in the Parameter mode and thus malfunctions.



- \Rightarrow Entry lock function disabled.
- Entry lock function enabled.
 Is displayed when the user attempts to edit a setting in the Parameter mode.

RAM test

Test of the main memory.

	Test sequence	
8. 8 .8.8.8	The test runs automatically one time:	
8.8.8 .8.8	\Rightarrow Test in process (very briefly).	
PRSS8	⇒ Test finished, no error found.	
E .P.B.B.B	➡ Test finished, error(s) found. The Error lamp flashes.	
	If the error message persists after several test sequences have been run, please contact your local Pfeiffer Vacuum service center.	

EPROM test

Test of the program memory.

	Test sequence	
8.8 .8.8.8	The test runs automatically one time:	
8. 8. 8.8.8	⇒ Test in process	
PRSS 8	Test finished, no error found. After the test, a four-digit checksum (hexadecimal for- mat) is displayed.	
6 2.8.8.8	 Test finished, error(s) found. After the test, a four-digit checksum (hexadecimal for- mat) is displayed. The Error lamp flashes. 	
	If the error message persists after several test sequences have been run, please contact your local Pfeiffer Vacuum service center.	

EEPROM test	Test of the parameter memory.		
	Test sequen		
	8.8 .8.8.8	The test runs automatically one time:	
	8.8.8 .8.8	⇒ Test in process (very briefly).	
	PASS8	⇒ Test finished, no error found.	
	E .2.8.8.8	➡ Test finished, error(s) found. The Error lamp flashes.	
		If the error message persists after several test sequences have been run, please contact your local Pfeiffer Vacuum service center.	

Display test

Test of the display.

	Test sequence
8.8.8.8.8	The test runs automati- cally one time ^{*)} :
Error PARA E+/B rear - B B B B B B B B B B - ON DEG CAL OFS SP1 SP2 - ON DEG CAL OFS SP3 SP4	First, all display ele- ments are lit at the same time,
	⇒ and then, each ele- ment is lit individually.
1 ON DEG CAL OFS SP1 SP2 2 ON DEG CAL OFS SP3 SP4	
	Stop the test sequence and activate one element after another by pressing the key once per element.

- A/D converter test 0 Test of channel 0 of the analog/digital converter (with a reference voltage at the signal input of the *sensor* connector ($\rightarrow \square 20$)).
 - If the signal input is open, the TPG 261 displays a default value that may easily fluctuate because of the high sensitivity of the open measurement circuit.



A/D converter test 1

Test of channel 1 of the analog/digital converter (with a reference voltage at the signal input of the sensor connector (\rightarrow \cong 20)).



If the signal input is open, the TPG 261 displays a default value that may easily fluctuate because of the high sensitivity of the open measurement circuit.

	Test sequence
8.8 .8.8.8	
e.g.: 8.8.8.8.8	⇒ Gauge identification voltage.
5.8888	⇒ No gauge connected.

I/O test

Test of the relays of the TPG 261. The program tests their switching function.



The relays switch on and off cyclically. The switching operations are indicated optically and can be heard.

The contacts of the switching functions 1 ... 4 are connected to the *relay* connector ($\rightarrow \blacksquare$ 22), the contacts of the error relay to the *control* connector ($\rightarrow \blacksquare$ 21) on the rear of the housing. Check their function with an ohmmeter.





 RS232C test
 Test of the RS232C interface. The TPG 261 repeats each sign transmitted by the communicating HOST.

 Image: transmitted by the communicating HOST.
 Image: transmitted by the communicating HOST.

 Image: transmitted by the communicating HOST.
 Image: transmitted by the communicating HOST.

 Image: transmitted by the communicating HOST.
 Image: transmitted by the communicating HOST.

 Image: transmitted by the computer only (→ Image: trans

5 Communication (Serial Interface)

5.1	RS232C Interface	The serial interface is used for communication between the TPG 26x ¹⁾ and a computer. A terminal can be connected for test purposes.
		When the TPG 26x is put into operation, it starts transmitting measured values in intervals of 1 s. As soon as the first character is transferred to the TPG 26x, the automatic transmission of measured values stops. After the necessary inquiries or parameter modifications have been made, the transmission of measured values can be started again with the COM command ($\rightarrow \square$ 72).
	Connection diagram connection cable	Pin assignment of the 9-pin D-Sub connector and RS232 interface cable \rightarrow \blacksquare 23.
5.1.	1 Data Transmission	The data transmission is bi-directional, i.e. data and control commands can be transmitted in either direction.
	Data format	1 start bit 8 data bits No parity bit 1 stop bit No hardware handshake
		¹⁾ Communication structure and procedures are identi-

cal for both controllers TPG 261 and TPG 262. Therefore the term TPG 26x is used in this chapter.

Definitions	The follo	The following abbreviations and symbols are used:			
	Symbol	Meaning			
	HOST	Computer or terminal			
	[]	Optional elements			
	ASCII	American Standard Code for Information Interchange		ion	
		_	Dec.	Hex.	
	<etx></etx>	END OF TEXT (CTRL C) Reset the interface	3	03	
	<cr></cr>	CARRIAGE RETURN Go to beginning of line	13	0D	
	<lf></lf>	LINE FEED Advance by one line	10	0A	
	<enq></enq>	ENQUIRY Request for data transmission	5	05	
	<ack></ack>	ACKNOWLEDGE Positive report signal	6	06	
	<nak></nak>	NEGATIVE ACKNOWLEDGE Negative report signal	21	15	
	"Transm "Receive	it": Data transfer from HOST ": Data transfer from TPG 2	to TPC 6x to F	G 26x IOST	
Flow Control	After ea signal (< The inpu least 32	ch ASCII string, the HOST must ACK> <cr><lf> or <nak> <ci ut buffer of the HOST must have bytes.</ci </nak></lf></cr>	wait fo R> <lf a capa</lf 	r a report >). acity of at	

5.1.2 Communication Protocol

Transmission format Messages are transmitted to the TPG 26x as ASCII strings in the form of mnemonic operating codes and parameters. All mnemonics comprise three ASCII characters.

Spaces are ignored. <ETX> (CTRL C) clears the input buffer in the TPG 26x.

Transmission	HOST	TPG 26x	Explanation
protocol	Mnemonics [and paramete <cr>[<lf>]</lf></cr>	ers]>	Receives message with "end of mes- sage"
	<	<ack><cr><lf></lf></cr></ack>	Positive acknowledg- ment of a received message

Reception format When requested with a mnemonic instruction, the TPG 26x transmits the measurement data or parameters as ASCII strings to the HOST.

<ENQ> must be transmitted to request the transmission of an ASCII string. Additional strings, according to the last selected mnemonic, are read out by repetitive transmission of <ENQ>.

If <ENQ> is received without a valid request, the ERROR word is transmitted.

Reception protocol	HOST TPG 26x	Explanation		
	Mnemonics [and parameters]	Receives message with "end of mes- sage"		
	< <ack><cr><lf></lf></cr></ack>	Positive acknowledg- ment of a received message		
	<enq>></enq>	Requests to transmit data		
	<pre>< Measurement values or parameters < <cr><lf></lf></cr></pre>	Transmits data with "end of message"		
	:	:		
	<enq>></enq>	Requests to transmit data		
	< Measurement values or parameters	Transmits data with "end of message"		
-	< < < <	I 		
Error processing	The strings received are verified in error is detected, a negative ackno output.	n the TPG 26x. If an owledgment <nak> is</nak>		
Error recognition	HOST TPG 26x	Explanation		
protocol	Mnemonics [and parameters]	Receives message with "end of mes- sage"		
	***** Transmission or programming error *****			
	< <nak><cr><lf></lf></cr></nak>	Negative acknowl- edgment of a re- ceived message		
	Mnemonics [and parameters] ————> <cr>[<lf>] ————></lf></cr>	Receives message with "end of mes- sage"		
	< <ack><cr><lf></lf></cr></ack>	Positive acknowl- edgment of a re- ceived message		

5.2 Mnemonics

		\rightarrow \square
ADC	A/D converter test	87
BAU	Baud rate (transmission rate)	83
COM	Continuous mode	72
CAL	Calibration factor	78
DCD	Display control digits (display resolution)	83
DGS	Degas	80
DIC	Display control (display changeover)	84
DIS	Display test	86
EEP	EEPROM test	86
EPR	EPROM test	86
ERR	Error status	74
FIL	Filter time constant (measurement value filter)	77
FSR	Full scale range (measurement range of linear gauges)	78
IOT	I/O test	88
LOC	Keylock	85
OFC	Offset correction (linear gauges)	79
OFD	Offset display (linear gauges)	79
PNR	Program number (firmware version)	84
PRE	Pirani range extension	81
PR1	Pressure measurement (measurement data) gauge 1	70
PR2	Pressure measurement (measurement data) gauge 2	70
PRX	Pressure measurement (measurement data) gauge 1 and 2	71
PUC	Penning underrange control (underrange control)	80
RAM	RAM test	86
RES	Reset	75
RST	RS232 test	89
SAV	Save parameters to EEPROM	84
SC1	Sensor control 1 (gauge control 1)	82
SC2	Sensor control 2 (gauge control 2)	82
SCT	Sensor channel change (measurement channel change)	74
SEN	Sensors on/off	73
SP1	Setpoint 1 (switching function 1)	76
SP2	Setpoint 2 (switching function 2)	76
SP3	Setpoint 3 (switching function 3)	76
SP4	Setpoint 4 (switching function 4)	76
SPS	Setpoint status (switching function status)	77
TID	Transmitter identification (gauge identification)	73
	(continued)	

	(concluded)	
ТКВ	Keyboard test (operator key test)	89
TLC	Torr lock	85
UNI	Pressure unit	83
WDT	Watchdog control	85

5.2.1 Measurement Mode

Measurement data gauge	Transmi	t: PRx <cr>[<lf>]</lf></cr>
1012		└─ Measurement value x = 1 -> Gauge 1 2 -> Gauge 2
	Receive Transmi	: <ack><cr><lf> t: <enq></enq></lf></cr></ack>
	Receive	x,sx.xxxxEsxx <cr><lf></lf></cr>
		Measurement value ¹⁾ [in current pressure unit] Status, x = 0 -> Measurement data okay 1 -> Underrange 2 -> Overrange 3 -> Sensor error 4 -> Sensor off (IKR, PKR, IMR, PBR) 5 -> No sensor (output: 5,2.0000E-2 [mbar]) 6 -> Identification error
		¹⁾ Values always in exponential format. For logarithmic gauges, the 3 rd and 4 th decimal are always 0.





For logarithmic gauges, the 3rd and 4th decimal are always 0.

Continuous output of measurement values	Transmit:	COM [,x] <cr>[<lf>]</lf></cr>
(RS232)		└─ Mode x = 0 -> 100 ms
		1 -> 1 s (default) 2 -> 1 min.
	Receive:	<ack><cr><lf></lf></cr></ack>
		<ack> is immediately followed by the con- tinuous output of the measurement value in the desired interval.</ack>
	Receive:	x,sx.xxxxEsxx,y,sy.yyyyEsyy <cr><lf></lf></cr>
		Measurement value gauge 2 ¹⁾ [in current pressure unit] Measurement value gauge 2 Measurement value gauge 1 ¹⁾ [in current pressure unit] Status gauge 1, x = 0 -> Measurement data okay 1 => Underrange
		2 -> Overrange
		3 -> Sensor error 4 -> Sensor off (IKR PKR IMP PRP)
		$5 \rightarrow$ No sensor
		(output: 5,2.0000E-2 [mbar]) 6 -> Identification error
	1) Va	lues always in exponential format

¹⁷ Values always in exponential format. For logarithmic gauges, the 3rd and 4th decimal are always 0.


of these gauges are approximately the same.

channel change	Transmit.	SCI [,x] <cr>[<lf>] Display channel, x = 0 -> Gauge 1 1 -> Gauge 2</lf></cr>
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	x <cr><lf> └── Display channel</lf></cr>
Error status	Transmit: Receive: Transmit: Receive:	ERR <cr>[<lf>] <ack><cr><lf> <enq> xxxx <cr><lf> xxxx = 0000 -> No error 1000 -> Error Controller error (See display on front panel) No by No Protection (See display) Output (See displa</lf></cr></enq></lf></cr></ack></lf></cr>
		0010 -> PAR Inadmissible parameter 0001 -> SYN Syntax error



The ERROR word is cancelled when read out. If the error persists, it is immediately set again.

Reset	Transmit: RES [,x] <cr>[<lf>]</lf></cr>		
		x = 1 -> Cancels currently active error and returns to measurement mode	
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>	
	Receive:	[x]x,[x]x, <cr><lf></lf></cr>	
		List of all present error messages, xx = 0 -> No error 1 -> Watchdog has responded 2 -> Task fail error 3 -> EPROM error 4 -> RAM error 5 -> EEPROM error 6 -> DISPLAY error 7 -> A/D converter error 9 -> Gauge 1 error (e.g. filament rupture, no supply) 10 -> Gauge 2 error (e.g. filament rupture, no supply) 12 -> Gauge 2 identification error	

5.2.2 Parameter Mode

5.2.2.1 Switching Function Parameters







1 -> on

5.2.2.2 Gauge Parameters

Measurement value filter	Transmit:	FIL [,x,x] <cr>[<lf>] </lf></cr>	
		└── Gauge 2 x = 	0 -> fast 1 -> medium (default) 2 -> slow
		└─ Gauge 1	
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>	
	Receive:	x,x <cr><lf> </lf></cr>	
		Filter time constant	gauge 2
		Filter time constant ga	auge 1



Measurement range gauge 1











5.2.2.3 Gauge Control





5.2.2.4 General Parameters

Pressure unit	Transmit:	UNI [,x] <cr>[<lf>]</lf></cr>
		└ └── Pressure unit, x = 0> mbar/bar (default) 1> Torr 2> Pascal
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	x <cr><lf> │ └── Pressure unit</lf></cr>
Transmission rate	Transmit:	BAU [,x] <cr>[<lf>]</lf></cr>
		 ↓ Transmission rate, x = 0 -> 9600 baud (default) 1 -> 19200 baud 2 -> 38400 baud
	As s tere trans	oon as the new baud rate has been en- d, the report signal is transmitted at the new smission rate.
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	x <cr><lf> Transmission rate</lf></cr>
Display resolution	Transmit:	DCD [,x] <cr>[<lf>]</lf></cr>
		Resolution, x = 2 → Display x.x (2 digits) (default) 3 → Display x.xx (3 digits)
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	x <cr><lf></lf></cr>
	When the Pri range p<1.0E Gauge is red	E (\rightarrow B 46) is ON and the pressure is in the E-4 mbar the display resolution of the PCR uced by one decimal digit.

Save parameters to EEPROM	Transmit:	SAV [,x] <cr>[<lf>] x = 0 -> Save default parameters 1 -> Save user parameters</lf></cr>
	Receive:	<ack><cr><lf></lf></cr></ack>
Display changeover	Transmit:	DIC [,x] <cr>[<lf>] Measurement display behavior when a Pirani gauge or a Pirani Capacitance gauge is combined with a linear gauge with 1000 mbar F.S., x = 0 ->manual (default) 1 ->automatic</lf></cr>
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	x <cr><lf> │ └─ Measurement display behavior</lf></cr>
Test Parameters	(For service p	ersonnel)
Firmware version	Transmit:	PNR <cr>[<lf>]</lf></cr>
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>
	Receive:	302-510-x <cr><lf></lf></cr>

- Firmware number

5.2.2.5



Watchdog control	Transmit:	WDT [,x] <cr>[<lf>]</lf></cr>			
		x = 0 -> Manual error acknowledgement 1 -> Automatic error acknowledgement ¹⁾ (default)			
	¹⁾ If the watchdog has responded, the er automatically acknowledged and cancelleter 2 s.				
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>			
	Receive:	x <cr><lf> Watchdog control</lf></cr>			
Torr lock	Transmit:	TLC [,x] <cr>[<lf>]</lf></cr>			
		1 -> on			
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>			
	Receive:	x <cr><lf></lf></cr>			
		Torr lock status			
Keylock	Transmit:	LOC [,x] <cr>[<lf>] \downarrow x = 0 -> off (default) 1 -> on</lf></cr>			
	Receive: Transmit:	<ack><cr><lf> <enq></enq></lf></cr></ack>			
	Receive:	x <cr><lf> Keylock status</lf></cr>			









Caution: The relays switch irrespective of the pressure. Starting a test program may cause unwanted effects in connected control systems. Disconnect all sensor cables and control system lines to ensure that no control commands or messages are triggered by mistake.

Transmit: **IOT** [,x,yy] <CR>[<LF>] L Relay status (in hex format), yy = 00 -> All relays deactivated 01 -> Switching function relay 1 activated 02 -> Switching function relay 2 activated 04 -> Switching function relay 3 activated 08 -> Switching function relay 4 activated 10 -> Gauge relay CH1 activated 20 -> Gauge relay CH2 activated 40 -> Error relav activated 7F -> All relays activated 0 -> Test stopped - x = 1 -> Test runs Receive: <ACK><CR><LF> Transmit: <ENQ> Receive: x.vv <CR><LF> Relay status I/O test status





RS232 test

Transmit: Receive: Transmit: RST <CR>[<LF>]

<ACK><CR><LF> <ENQ> Starts the test (repeats each character, test is interrupted

with <CTRL> C)

5.2.3 Example

"Transmit (T)" and "Receive (R)" are related to Host.

- S: TID <CR> [<LF>]
- E: <ACK> <CR> <LF>
- S: <ENQ>
- E: TPR,CMR <CR> <LF>
- S: **SEN** <CR> [<LF>]
- E: <ACK> <CR> <LF>
- S: <ENQ>
- E: 0,0 <CR> <LF>
- S: SP1 <CR> [<LF>]
- E: <ACK> <CR> <LF>
- S: <ENQ>
- E: 0,1.0000E-09,9.0000E-07 <CR> <LF>
- S: SP1,1,6.80E-3,9.80E-3 <CR> [<LF>]
- E: <ACK> <CR> <LF>
- S: FOL,1,2 <CR> [<LF>]
- E: <NAK> <CR> <LF>
- S: <ENQ>
- E: 0001 <CR> <LF>
- S: FIL,1,2 <CR> [<LF>]
- E: <ACK> <CR> <LF>
- S: <ENQ>
- E: 1,2 <CR> <LF>

Request for gauge identification Positive acknowledgement Request for data transmission Gauge identifications

Request for gauge statuses Positive acknowledgement Request for data transmission Gauge statuses

Request for parameters of switching function 1 (setpoint 1) Positive acknowledgement Request for data transmission Thresholds

Modification of parameters of switching function 1 (setpoint 1) Positive acknowledgement

Modification of filter time constant (syntax error) Negative acknowledgement Request for data transmission ERROR word Modification of filter time constant Positive acknowledgement Request for data transmission Filter time constants

6 Maintenance

The product requires no maintenance.

Cleaning the TPG 261 For cleaning the outside of the TPG 261, a slightly moist cloth will usually do. Do not use any aggressive or scouring cleaning agents.



7 Troubleshooting

Signalization of errors	Error a	nd the error relay opens (\rightarrow 🗎 21).
Error messages		Possible cause and remedy/ acknowledgement
	5.8 .8.8.8	Interruption or instability in sensor line or connector (Sensor error).
		Acknowledge with the [™] . key If the problem persists, 105E6 or 1000 is displayed.
		Possible cause and remedy/ acknowledgement
	8.8 .8.8.8	The TPG 261 has been turned on too fast after power off.
		Acknowledge with the [™] key. If the watchdog is set to DEEE , the TPG 261 acknowledges the message automatically after 2 s (→ [™] 58).
		The watchdog has tripped because of a severe electric disturbance or an oper- ating system error.
		Acknowledge with the key. If the watchdog is set to be be be, the TPG 261 acknowledges the message automatically after 2 s (→ ■ 58).
		Possible cause and remedy/ acknowledgement
	RARRA	Main memory (RAM) error.
		\Rightarrow Acknowledge with the \mathbf{m} key.
		Possible cause and remedy/ acknowledgement
	8.8 .8.8.8	Program memory (EPROM) error.
		⇒ Acknowledge with the ^{PMA} key.



	Possible cause and remedy/ acknowledgement
FFFFFFFFFFFFF	Parameter memory (EEPROM) error.
	\Rightarrow Acknowledge with the AAA key.
	Possible cause and remedy/ acknowledgement
Raaaa	Display driver error.
	\Rightarrow Acknowledge with the PARA key.
	i de la constante d
	Possible cause and remedy/ acknowledgement
88999	Possible cause and remedy/ acknowledgement A/D converter error.
A 8 8.8.8	Possible cause and remedy/ acknowledgement A/D converter error. ⇒ Acknowledge with the [™] key.
A 8 8.8.8	Possible cause and remedy/ acknowledgement A/D converter error. ⇒ Acknowledge with the [™] key. Possible cause and remedy/ acknowledgement
88 888	Possible cause and remedy/ acknowledgement A/D converter error. ⇒ Acknowledge with the weak key. Possible cause and remedy/ acknowledgement Operating system (Task Fail) error.

Technical support



If the problem persists after the message has been acknowledged for several times and/or the gauge has been exchanged, please contact you local Pfeiffer Vacuum service center.

8 Repair

Return defective products to your nearest Pfeiffer Vacuum service center for repair.

Pfeiffer Vacuum assumes no liability and the warranty becomes null and void if repair work is carried out by the end-user or third parties.

9 Storage

. Caution

Caution: electronic component Inappropriate storage (static electricity, humidity etc.) can damage electronic components.

Store the product in an antistatic bag or container. Observe the corresponding specifications in the technical data (\rightarrow) 9).

10 Disposal

WARNING: substances detrimental to the environment
Products or parts thereof (mechanical and electric components, operating fluids etc.) can be detrimental to the environment.
Dispose of such substances in accordance with the relevant local regulations.

Separating the components	After disassembling the product, separate its components according to the following criteria:
Non-electronic components	Such components must be separated according to their materials and recycled.
Electronic components	Such components must be separated according to their materials and recycled.

Appendix

A: Conversion Tables

Weights

	ŀ	kg	lb	slug	oz
kg	1	1	2.205	68.522×10 ⁻³	35.274
lb	C	0.454	1	31.081×10 ⁻³	16
slug	1	14.594	32.174	1	514.785
oz	2	28.349×10 ⁻³	62.5×10 ⁻³	1.943×10 ⁻³	1

Pressures

	N/m ² , Pa	bar	mbar	Torr	at
N/m ² , Pa	1	10×10 ⁻⁶	10×10 ⁻³	7.5×10 ⁻³	9.869×10 ⁻⁶
bar	100×10 ³	1	10 ³	750.062	0.987
mbar	100	10 ⁻³	1	750.062×10 ⁻³	0.987×10 ⁻³
Torr	133.322	1.333×10 ⁻³	1.333	1	1.316×10 ⁻³
at	101.325×10 ³	1.013	1.013×10 ³	760	1

Pressure units used in the vacuum technology

	mbar	Pascal	Torr	mmWs	psi
mbar	1	100	750.062×10 ⁻³	10.2	14.504×10 ⁻³
Pascal	10×10 ⁻³	1	7.5×10 ⁻³	0.102	0.145×10 ⁻³
Torr	1.333	133.322	1	13.595	19.337×10 ⁻³
mmWs	9.81×10 ⁻²	9.81	7.356×10 ⁻²	1	1.422×10 ⁻³
psi	68.948	6.895×10 ³	51.715	703	1

Linear measures

	mm	m	inch	ft
mm	1	10 ⁻³	39.37×10 ⁻³	3.281×10 ⁻³
m	10 ³	1	39.37	3.281
inch	25.4	25.4×10 ⁻³	1	8.333×10 ⁻²
ft	304.8	0.305	12	1

Temperature

	Kelvin	Celsius	Fahrenheit
Kelvin	1	°C+273.15	(°F+459.67)×5/9
Celsius	K-273.15	1	5/9×°F-17.778
Fahrenheit	9/5×K-459.67	9/5×(°C+17.778)	1

B: Default Settings

The following values are activated when the default settings are loaded (\rightarrow ${\ensuremath{\mathbb B}}$ 55):

	default	user	
5.8.8.8. <i>8</i>	1×10 ⁻¹¹ mbar		
5 <i>8.8.8.</i> H	9×10 ⁻¹¹ mbar		
68888	normal		
8.8.8.8.8	1.00 (log) 1.000 (lin)		
8. 5 .8.8.8	1000 mbar		
8. 6.5 .8.8	off 0×10 ⁻² mbar		
8.8.8 .8.8	off		
88.8 .8.8	off		
B.B.B.B .B	mbar		
68688	9600		
88688	2 Digit		
88.88	Auto		
8.8.8.8 .8	off		
8.8.8.8.8	off		

C:	Firmware Update	G	If your TPG 261 firmware needs updating, e.g. for implementing a new gauge type, please contact your local Pfeiffer Vacuum service center.
	User parameters	Most rame ware befor	t of the settings you may have defined in the Pa- eter and Test mode will not be affected by a firm- e update. To be sure, note your parameter settings re upgrading the firmware ($\rightarrow \square$ 96).
	Preparing the TPG 261 for a program transfer	0	Turn the TPG 261 off.
		0	Connect the TPG 261 with the serial COM1 (COM2) interface of your PC via a 9-pin D-Sub extension cable (\rightarrow 23) (the firmware of the TPG 261 cannot be loaded from a Mac).



 \bullet With a pin (ø<2 mm), depress the switch on the top of the unit, under the housing, and turn the TPG 261 on.



After power on, the display remains dark.

Program transfer

In the following instructions, the index $\cdot \mathbf{n}$ is used instead of the actual index.



Unpack the self extracting file SingleDualGauge 302-510-n.exe.





If you have not connected the TPG 261 to the COM1 interface:

• Open the batch file Update 302-510-n.bat ...

🗐 SingleDualGauge 302-5	10-n.exe	
Update 302-510-n.bat	Open	
302510n.bin	Edit	
👼 Flash166.ini	Print	
Flash166.exe	<u>-</u>	
Flash166.ovl		

... edit the interface ...



• ... and save the new setting.



Start batch file Update 302-510-n.bat.



ightarrow The new firmware is transmitted to the TPG 261.

Beendet - Update 302-510-n
D:\TPG26X\5\Update>FLASH166 /P 302510n.BIN /COM1 /DEVICE=PSD833F2 FLASH166 Utility for 80C166, C16x and ST10 using bootstrap Copyright (C) FS FORTH-SYSTEME GmbH, Breisach Version 3.03 of 06/14/2000, limited OEM Version (21279)
Restarting target monitor Target monitor located to OOFA40H Infineon Cl6JPI CPU clock = 24.098.133 MHz Configuration loaded from file FLASH166.INI Target: SINGLE-/DUALGAUGE, PFEIFFER VACUUM
WSI PSD833F2 detected Loading flash algorithm (138 Bytes) Erasing Flash-EPROM Block #:0 1 2 3 4 5 6 7 Programming File 302510n.BIN (131072 Bytes) 131072 Bytes programmed programming ok
Erase Time : 3.7 sec Programming Time: 36.5 sec

Starting the TPG 261 with the updated firm-ware

If the program transfer was successful, quit the Update mode by turning the TPG 261 off.



Wait at least 10 s before turning the TPG 261 on again in order for it to correctly initialize itself.

The TPG 261 is now ready for operation. To be sure, check that the current parameter settings are identical with the previously defined settings $(\rightarrow B 96)$.

- D: Literature
- [1] www.pfeiffer-vacuum.de Instruction Sheet Compact Pirani Gauge TPR 261 BG 5105 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- Www.pfeiffer-vacuum.de
 Operating Instructions
 Compact Pirani Gauge TPR 265
 BG 5177 BEN
 Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [3] www.pfeiffer-vacuum.de Operating Instructions
 Pirani-Messröhre TPR 280, TPR 281
 BG 5178 BEN
 Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [4] www.pfeiffer-vacuum.de Operating Instructions Compact Pirani Capacitance Gauge PCR 260 BG 5180 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- □ [5] www.pfeiffer-vacuum.de Operating Instructions Compact Pirani Capacitance Gauge PCR 280 BG 5181 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [6] www.pfeiffer-vacuum.de Operating Instructions Compact Pirani Capacitance Gauge PCR 280 BG 5182 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- □ [7] www.pfeiffer-vacuum.de Instruction Sheet Compact Cold Cathode Gauge IKR 251 BG 5110 BN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland

- [8] www.pfeiffer-vacuum.de Instruction Sheet Compact Cold Cathode Gauge IKR 261 BG 5113 BN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [9] www.pfeiffer-vacuum.de Instruction Sheet Compact Cold Cathode Gauge IKR 270 BG 5115 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- □ [10] www.pfeiffer-vacuum.de Instruction Sheet Compact FullRange™ Gauge PKR 251 BG 5119 BN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [11] www.pfeiffer-vacuum.de Instruction Sheet Compact FullRange™ Gauge PKR 261 BG 5122 BN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [12] www.pfeiffer-vacuum.de Instruction Sheet
 Compact Process Ion Gauge IMR 265
 BG 5132 BEN
 Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- □ [13] www.pfeiffer-vacuum.de Instruction Sheet Compact FullRange™ BA Gauge PBR 260 BG 5131 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- I4] www.pfeiffer-vacuum.de Instruction Sheet Compact Capacitance Gauge CMR 261 ... CMR275 BG 5133 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland

- [15] www.pfeiffer-vacuum.de Operating Instructions Compact Capacitance Gauge CMR 361 ... CMR365 BG 5136 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [16] www.pfeiffer-vacuum.de Operating Instructions Compact Capacitance Gauge CMR 371 ... CMR375 BG 5138 BEN Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland
- [17] www.pfeiffer-vacuum.de Instruction Sheet
 Compact Piezo Gauge APR 250 ... APR 267
 BG 5127 BN
 Pfeiffer Vacuum GmbH, D–35614 Asslar, Deutschland

E: Index

– A –
A/D converter test

– B –

Baud rate

– C –

– D –

Default settings Degas Display resolution test Disposal 55,

55,

2,

– E –

EEPROM test EPROM test Error messages Example

– F –

Factory settings	
Filter	
Firmware	
update	
version	

– G –

62	Gauge connector	20
	Gauge control	47
	gauge activation	49
54	gauge deactivation	50
	OFF threshold	51
	Gauge identification	30
40	Gauge parameters	37
01	calibration factor	40
65	Degas	45
65	measurement range	41
105	measurement value filter	38
105	offset	42
21	Pirani range extension	46
19		43
22	General parameters	52
23	denault settings	55
20	measurement units	50
	transmission rate	54
21		04
22	-1-	
4	∎ I/O tost	63
21	Identification of gauges	20
95	Intended Lies	30
		3
	connector	23
5. 96	test	64
45	transmission rate	54
55	– K –	
61	Kovlock	50
94	Reylock	39
	- L -	
	Liability	8
61	Literature	100
60		
92	– M –	
90	Mains power connector	19
	Maintenance	91
	Measurement mode	27, 70
5, 96	gauge identification	30
38	status messages	28
	turning the gauge on/off	28
97	Measurement range	41
2, 58	Measurement units	54
	conversion	95
	Measurement value filter	38
	Mnemonics	69

- 0 -

-	
OFF threshold	51
Offset	42
Operating modes	
Measurement mode	27
overview	26
Parameter mode	31
Program transfer mode	97
Operation	
power off	25
power on	25

– P –

Parameter mode	31, 76
Gauge control	47
Gauge parameters	37
General parameters	52
Switching function para	-
meters	33
Test parameters	56
Pin assignment	
control	21
relay	22
RS232	23
Pirani range extension	46
Power connector	19
Power off	25
Power on	25
Pressure units	54
conversion	95
Program	
update	97
version	2, 58

- R -RAM test *relay* connector Repair *RS232* connector RS232C test

– S –

•	
Safety	6
Scope of delivery	3
sensor connector	20
Serial interface	
connector	23
Status messages	28
Storage	94
Switching function pa	ra-
meters	33
Switching functions	22, 35, 36
Symbols	6

⁶ – T –

Test parameters	56
	50
lest program	56
A/D converter test	62
display test	61
EEPROM test	61
EPROM test	60
firmware version	58
I/O test	63
keylock	59
RAM test	60
RS232C test	64
Torr lock	59
watchdog	58
Thresholds	35, 36
Torr lock	59
Transmission rate	54
Troubleshooting	92
ricubiconicoting	02
– U –	
Underrange control	43
l Inite	
conversion	05
	07
Opdate	97
V	
- v -	
Validity	2
– W –	
Warranty	8
	Test parameters Test program A/D converter test display test EEPROM test EPROM test firmware version I/O test keylock RAM test RS232C test Torr lock Watchdog Thresholds Torr lock Transmission rate Troubleshooting -U - Underrange control Units conversion Update -V - Validity -W - Warranty

Watchdog

58

EC Declaration of Conformity

CE	We, Pfeiffer Vacuum, hereby mentioned below complies v rective relating to electrical e within certain voltage limits 2 Directive relating to electrom 2004/108/EC.	y declare that the equipment with the provisions of the Di- equipment designed for use 2006/95/EC and the agnetic compatibility
Product	Single-Channel Meas Unit TPG 261	urement and Control
Part number	PT G28 030	
Standards	 Harmonized and international specifications: EN 61000-3-2:2006 (EM emissions) EN 61000-3-3:1995 + A1 (EMC: limitation of voltage cha flicker) EN 61000-6-2:2005 (EMC: generic immunity stand. EN 61000-6-3:2007 (EMC: generic emission stand. EN 61010-1:2001 (Safety requirements for electr control and laboratory use) 	al/national standards and C: limits for harmonic current :2001 + A2:2005 nges, voltage fluctuations and ard) ard) ical equipment for measurement,
Manufacturer / Signatures	Pfeiffer Vacuum GmbH, Ber 30 September 2010 M. M. J. J. J. J. Manfred Bender	liner Str. 43, D-35614 Asslar 30 September 2010 ∭. ᡬ. cm ↔ Dr. Matthias Wiemer

Manfred Bender Managing Director

Managing Director

A PASSION FOR PERFECTION





www.pfeiffer-vacuum.net

PFEIFFER VACUUM